

Foreword

First of all, thank you for purchasing the V9 series products of SHENZHEN V&T TECHNOLOGIES CO., LTD.

This manual is used for the model selection, installation, parameter setting, commissioning and fault diagnosis of the AC drive.

To guarantee safe operation of the equipment, please read this manual carefully before connecting power to the AC drive. Keep this manual at hand and distribute it to all users for reference.

When using the drive together with optional accessories, also read the option manual. Note that this manual and the option manual should be delivered to the end users.

If you have any questions, please consult our technical support personnel or distributors for help.

Due to continuous improvement of products, the information provided by our company is subject to change without notice.

Abundant and Flexible Function

■ System control mode

- ◆ Position loop.
- ◆ Speed loop.
- ◆ Torque loop.

■ Speed reference source

- ◆ Modbus communication.
- ◆ Keypad.
- ◆ Analog input.
- ◆ Multi-step speed reference.
- ◆ External digital inputs UP/DN.
- ◆ Process close loop PID reference.
- ◆ Main speed reference and auxiliary speed reference calculation.
- ◆ Simple PLC.
- ◆ High-speed pulse.
- ◆ CAN/CANopen, PROFIBUS-DP, PROFINET, etc.

■ Run command reference source

- ◆ Modbus communication.
- ◆ Keypad.
- ◆ External digital input.
- ◆ CAN, PROFIBUS DP, PROFINET.

■ Pulse input

- ◆ Orthogonal pulse.
- ◆ Pulse + Direction.
- ◆ Single-phase pulse.

■ LED Keypad and LCD Keypad

- ◆ Modbus communication.
- ◆ The keypad and control board can be connected by standard network cable.
- ◆ The keypad has the functions of parameters upload and download.
- ◆ A password can be set on the keypad and/or the keys can be locked to avoid the non-professional personnel from changing the parameters by mistake.

■ Communication mode

- ◆ Modbus-RTU, CAN, CANopen, PROFIBUS DP, PROFINET.
- ◆ Host controller has the functions of parameters upload and download.

Safety Precautions



DANGER: Dangerous warning warns of high voltage which can cause physical injury and/or damage to the equipment, even could be lethal. Extreme care is necessary at all times when working with or adjacent to the drive.



WARNING: General warning warns about conditions, other than those caused by electricity, which can result in physical injury and/or damage to the product.

■ USE



DANGER

- This series of drive is used to control the operation of three-phase motor. It cannot be used to control single-phase motor or for other purpose, otherwise it may cause drive fault or fire.
- This series of drive cannot be easily applied to applications such as medical device that are directly related to personal safety.
- This series of drive is manufactured under a strict quality management system. If a drive fault occurs, it may cause a major accident or loss, safety measures such as redundancy or bypass need to be set, just in case.

■ Arrival Inspection



WARNING

- The drive cannot be installed if the drive is damaged or missing parts, otherwise an accident may occur.

■ Installation



WARNING

- When handling and installing, please hold the bottom of the product. Do not hold the enclosure only, otherwise, your feet may be injured and/or the drive may be damaged.
- The drive should be mounted on the fire-retardant surface such as metal, and keep away from flammable objects and heat producer.
- Do not drop drilling residue into the drive during installation work. Otherwise the drive may be damaged and/or trip on a fault.
- When the drive is installed in an electrical control cabinet, the electrical control cabinet shall be equipped with a fan and ventilation port. In addition, air-cooling duct shall be constructed in the cabinet to facilitate heat dissipation.

■ Wiring



DANGER

- Wiring must be performed by a qualified electrical engineer, otherwise there is a risk of electric shock or damage to the drive.
- Must cut off the power before wiring; otherwise, there is a risk of electric shock or fire.
- The grounding terminal PE must be grounded reliably, otherwise, the drive enclosure may become live.
- Do not touch the main circuit terminals. The main circuit terminals wiring of the drive must not be contacted to the enclosure, otherwise, risk of electric shock may occur.
- The connection terminals of the brake resistor are “+2/B1” and “B2” (from 11kW to 110kW products are “+” and “BR”). Do not connect to other terminals; otherwise, risk of fire may occur.
- The leakage current of the drive is higher than 3.5mA, and the specific value is determined by the conditions of use. For safety, the drive and the motor must be firmly grounded.



WARNING

- The three – phase power supply cannot be connected to the output terminals U, V, W; otherwise, the drive will be damaged.
- It is absolutely prohibited to connect a capacitor or phase lead LC/RC noise filter to the output terminal of the drive, otherwise the internal components of the drive will be damaged.
- Please confirm the number of power phases and rated input voltage match the nameplate, otherwise the drive may be damaged.
- The withstand voltage test cannot be performed to the drive; otherwise the drive may be damaged.
- The main circuit terminal wiring and control circuit terminal wiring of the drive should be arranged separately or vertically, otherwise the control signal will be interfered.
- For the cable of the main circuit terminal, use the cable lug with an insulating sleeve.
- The sectional area of input and output cables selecting should according to the drive rated current.
- When the cable length between the drive and the motor exceeds 100 meters, it is recommended to use an output reactor to avoid over – current fault caused by excessive distributed capacitance.
- The terminal connection of the main circuit must be reliable; otherwise, it may cause fire and/or short circuit.

■ Operation



DANGER



- Only after the drive wiring is completed and covered well, the drive can be powered up. It is forbidden to remove the cover when the power is on; otherwise, there is a risk of electric shock.
- Before running, confirm that the mechanical installation is reliable; otherwise, it may cause physical injury and/or damage to the equipment.
- Before running, must confirm all personnel are in safe position, otherwise, it may cause physical injury and/or damage to the equipment.
- If automatic fault reset or automatic start after next time powered up function is active, safety isolation measures should be taken for mechanical equipment, otherwise, it may cause physical injury and/or damage to the equipment.
- After the drive is powered, even if it is in the stop status, the terminals of the drive are still charged. It is forbidden to touch the terminals, otherwise it may cause electric shock.
- Before reset the drive, confirm the run command has been switch off, otherwise it may cause physical injury and/or damage to the equipment.




WARNING

- Do not start or stop the drive by turning the power supply on or off; otherwise, the drive may be damaged.
- Before start, please confirm whether the motor and machinery are within the allowable range of use, otherwise the equipment may be damaged.
- Before start, please set the motor parameters correctly and start motor parameters auto-tune, otherwise, if the default parameter values are not match the motor will cause over-current fault or motor vibration, even damage to the equipment.
- Do not touch heat sink and brake resistor, otherwise there is a danger of burns and/or electric shock.
- When the drive is used on a lifting machine, such as crane, escalator, elevator, please also configure a mechanical brake.
- Do not change the drive parameters at will. Most of the parameters' default value can meet the operation requirements. Just need to change some necessary parameters, and arbitrarily modify the parameters may cause damage to the mechanical equipment. Only some necessary parameters need to be set. Modify the parameters at will may result in damage to the mechanical equipment.

■ Maintenance and Inspection

<div style="text-align: center;">  DANGER </div>
<ul style="list-style-type: none"> ● Do not touch the terminals of the drive while the power is on, otherwise there is a danger of electric shock. ● Make sure cut off the power supply before remove the cover. ● Wait at least 10 minutes after cut off the power, or confirm that the charging CHARGE indicator is off before performing maintenance and inspection to prevent the residual voltage of the main circuit capacitor from injuring people. ● Please designate qualified electrical engineers to do the maintenance, inspection and replace parts for the drive.
<div style="text-align: center;">  WARNING </div>
<ul style="list-style-type: none"> ● There are CMOS large-scale integrated circuits on the circuit board. Do not touch the PCB with your hands to prevent static electricity from damaging the circuit board.

■ Others

<div style="text-align: center;">  DANGER </div>
<ul style="list-style-type: none"> ● It is forbidden to modify the drive hardware; otherwise, it will cause personal injury. ● The power of interphone used when close to the drive shall not exceed 8W. ● It is forbidden to use the screws not provided by the manufacturer or specified by the manufacturer, otherwise the structural parts of the drive or the circuit will be damaged due to factors such as too long or too large screws.


CONTENTS

Safety Precautions	3	5.3 ACC/DEC Time (P2)	55
Chapter 1 Product Information	1	5.4 Digital Inputs and Outputs (P3)	57
1.1 Model Description	1	5.5 Analog Input and Output (P4)	68
1.2 Nameplate Description	1	5.6 Start and Stop (P5)	78
1.3 Ratings	2	5.7 Motor Parameters (P6)	81
1.4 Technical Specifications	4	5.8 V/F Control (P7)	83
1.5 Product Component Name	6	5.9 PMSM Sensor-less Control (P8)	86
1.6 Dimensions	6	5.10 Vector Control (P9)	88
1.7 Keypad Outline and Dimensions	8	5.11 Torque Control (PA)	91
1.8 Pallet Outline Dimensions	8	5.12 Advanced Parameter (PB)	93
1.9 Brake Resistor	9	5.13 Process PID Control (PC)	97
Chapter 2 Mechanical Installation	10	5.14 Encoder Parameters (A0)	104
2.1 Installation Environment	10	5.15 Position Controller (B0)	106
2.2 Installation Direction and Clearances	10	5.16 Pulse Input and Output (B1)	113
2.3 Remove and Install the Front Cover	11	5.17 Modbus (C0)	116
Chapter 3 Electrical Installation	15	5.18 CAN (C1)	119
3.1 Peripheral Devices Connection	15	5.19 EtherCAT (C2)	119
3.2 Peripheral Devices Description	16	5.20 Keypad Parameters (D0)	120
3.3 Peripheral Devices Models	17	5.21 Protection Configuration (E0)	124
3.4 Terminal Configuration	18	5.22 Status Monitoring Parameters (F0)	129
3.5 Main Circuit Terminal Description	19	5.23 Software Version (F1, F2)	136
3.6 Attention for Main Circuit Wiring	20	5.24 Trip History (F3)	137
3.7 Terminal Wiring 1	22	Chapter 6 Diagnostics	139
3.8 Terminal Wiring 2	23	6.1 Fault Indications	139
3.9 Control Circuit Description	24	Appendix A Modbus Communication	143
3.10 Digital inputs and Outputs	26	1 Support Protocol	143
3.11 Control Circuit Peripheral Devices	27	2 Interface Mode	143
3.12 Jumper Description	27	3 Protocol Format	143
Chapter 4 Keypad Operation	28	4 Function Interpretation	144
4.1 Keypad Model	28	5 Register Address	145
4.2 Keypad Keys	29	6 Modbus Communication Example	146
4.3 Keypad Indicator	30	7 CRC16 Function	146
4.4 LCD Keypad Interface	31	8 Network Construction	147
4.5 LCD Keypad Operation	32	Appendix B Speed Feedback Card	148
4.6 LED Keypad Operation	34	1 Introduction	148
4.7 Password Setting	35	2 DIP Setting	148
4.8 Menu Mode	36	3 Wiring	149
4.9 First Commissioning and Auto Tune	38	Appendix C Communication Card	151
Chapter 5 Parameter List	40	1 Introduction	151
5.1 Basic Parameters (P0)	41	2 Wiring	151
5.2 Speed Reference (P1)	48		


Chapter 1 Product Information

1.1 Model Description

The model field on the drive nameplate uses numbers and letters to indicate information such as product series, input voltage, power, software version and hardware version.



1.2 Nameplate Description



1.3 Ratings

■ V9-H-4T□□□G Three phase 400V constant torque / heavy load application

Rated Power (kW)		0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110
Applicable motor (kW)		0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110
Output	Voltage (V)	Three-phase 0 to rated input voltage																
	Rated current (A)	2.5	3.8	5.5	9	13	17	24	30	39	45	60	75	91	112	150	176	210
	Overload capability	150% for 60s, 180% for 10s, 200% for 0.5s, interval: 10 minutes (Inverse time characteristic)																
Input	Voltage / frequency	Three-phase 380V/480V; 50Hz/60Hz																
	Allowable voltage	323V ... 528V; voltage imbalance ≤3%; allowable frequency fluctuation: ±5%																
	Rated current (A)	2.8	4.2	6.1	10	15	19	26	33	43	50	66	83	100	123	165	194	231
DC reactor		No built-in									Built-in as option							
Brake chopper		Built-in as standard									Built-in as option							
Protection level		IP20																
Cooling mode		Self cooling			Force air cooling													

Rated Power (kW)		132	160	185	200	220	250	280	315	355	400	450	500	560	630
Applicable motor (kW)		132	160	185	200	220	250	280	315	355	400	450	500	560	630
Output	Voltage (V)	Three-phase 0 to rated input voltage													
	Rated current (A)	253	304	350	380	426	470	520	600	650	690	775	860	950	1100
	Overload capability	150% for 60s, 180% for 10s, 200% for 0.5s, interval: 10 minutes (Inverse time characteristic)													
Input	Voltage / frequency	Three-phase 380V/480V; 50Hz/60Hz													
	Allowable voltage	323V ... 528V; voltage imbalance ≤3%; allowable frequency fluctuation: ±5%													
	Rated current (A)	232	282	326	352	385	437	491	580	624	670	755	840	920	1050
DC reactor		Built-in as standard		External as standard										Built-in AC input reactor as standard	
Brake chopper		External													
Protection level		IP20													
Cooling mode		Force air cooling													

Notes:

- Higher power products are customizable.
- Products with 220V, 690V and other supply voltage are customizable.

■ V9-H-4T□□□L Three phase 400V variable torque / light load application

Rated Power (kW)		1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	
Applicable motor (kW)		1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132	
Output	Voltage (V)	Three-phase 0 to rated input voltage																	
	Rated current (A)	3.3	5.0	7.5	11	17	22	29	35	45	57	70	91	110	144	180	216	242	
	Overload capability	150% for 60s, 180% for 10s, 200% for 0.5s, interval: 10 minutes (Inverse time characteristic)																	
Input	Voltage / frequency	Three-phase 380V/480V; 50Hz/60Hz																	
	Allowable voltage	323V ... 528V; voltage imbalance ≤3%; allowable frequency fluctuation: ±5%																	
	Rated current (A)	3.6	5.5	8.3	12	19	25	32	39	50	61	77	100	121	158	198	238	266	
DC reactor		No built-in									Built-in as option								
Brake chopper		Built-in as standard									Built-in as option								
Protection level		IP20																	
Cooling mode		Self cooling			Force air cooling														

Rated Power (kW)		160	185	200	220	250	280	315	355	400	450	500	560	630	710
Applicable motor (kW)		160	185	200	220	250	280	315	355	400	450	500	560	630	710
Output	Voltage (V)	Three-phase 0 to rated input voltage													
	Rated current (A)	325	365	405	440	495	547	610	695	770	866	950	1100	1200	1300
	Overload capability	150% for 60s, 180% for 10s, 200% for 0.5s, interval: 10 minutes (Inverse time characteristic)													
Input	Voltage / frequency	Three-phase 380V/480V; 50Hz/60Hz													
	Allowable voltage	323V ... 528V; voltage imbalance ≤3%; allowable frequency fluctuation: ±5%													
	Rated current (A)	282	326	352	385	437	491	580	670	755	840	920	1050	1150	1250
DC reactor		Built-in as standard		External as standard										Built-in AC input reactor as standard	
Brake chopper		External													
Protection level		IP20													
Cooling mode		Force air cooling													

Notes:


- Higher power products are customizable.
- Products with 220V, 690V and other supply voltage are customizable.

1.4 Technical Specifications

Control characteristics	Control mode	Sensor less vector control	Sensor vector control
	Applicable motor type	Synchronous motor, asynchronous motor	
	Maximum speed	600Hz, Note: Higher frequency products are customizable.	
	Starting torque	<ul style="list-style-type: none"> Asynchronous motor: 200% of rated torque at 0.25Hz. Synchronous motor: 150% of rated torque at 1.5% of rated speed 	200% of rated torque at 0 speed
	Speed regulation range	1:200	1:5000
	Steady speed precision	± 0.5%	± 0.02%
	Torque control	Y	Y
	Torque control precision	±5%	±3%
	Torque response time	<20ms	<10ms
	Positioning control	N	Y
	Positioning precision	N	±1 pulse
Product function	Key function	Speed loop, torque loop, position loop, orientation control, current limit, torque limit, motor auto tune, inertia auto tune, deep flux-weakening control, over-voltage control, under-voltage control, motor flying start, droop control, oscillation suppression, random carrier frequency, master follower control, etc.	
	Speed reference source	Modbus communication, keypad, external digital input, analog input AI1/AI2/AI3, pulse input, simple PLC, PID, CAN/CANopen, PROFIBUS-DP, PROFINET, etc.	
	Dynamic brake	Brake chopper action voltage: 650 ... 750V. The brake chopper of products 0.75kW to 110kW can be built-in: <ul style="list-style-type: none"> 0.75...15kW: brake chopper is built-in as standard. 18.5...110kW: brake chopper is built-in as option. 	
	Communication	Built-in Modbus-RTU communication, the maximum distance up to 500 meters.	
	Keypad	LED keypad and LCD keypad are available. The keypad can be used as remote-control box by a net cable.	
	Common DC bus	Full series product support common DC bus directly.	
	Independent air duct	All series product adopts independent duct design.	

Protection	Power supply under-voltage, over-current protection, over-voltage protection, auto-tune fault, module protection, heat-sink over-temperature protection, drive overload protection, motor overload protection, peripheral protection, current abnormal detection, output short-circuit to ground protection, EEPROM abnormal detection, temperature sampling disconnection, encoder disconnection, analog input abnormal detection, motor over-temperature, communication fault, hardware overload protection, etc.	
Efficiency	At rating condition: <ul style="list-style-type: none"> • 0.75kW to 7.5kW: ≥93% • 11kW to 45kW: ≥95% • 55kW and higher power class: ≥98% 	
Environment	Operating site	<ul style="list-style-type: none"> • Install vertically in a well-ventilated electrical cabinet. Horizontal or other installation methods are not allowed. • The cooling medium is air. • Installed in an environment free from direct sunlight, dust, corrosive gases, flammable gases, oil mist, steam, dripping.
	Ambient temperature	<ul style="list-style-type: none"> • -10 ... +40°C • Derate the output current by 1% for each 1 °C to install the drive in ambient temperature between 40 to 50 °C.
	Humidity	5 ... 95%, no condensation is allowed.
	Altitude	<ul style="list-style-type: none"> • 0 ... 4000 meters • Derate the output current by 1% for each 100 meters to install the drive in altitudes between 1000 to 4000 meters.
	Vibration	<ul style="list-style-type: none"> • 3.5 m/s², 2 ... 9Hz • 10 m/s², 9 ... 200Hz • 15 m/s², 200 ... 500Hz
	Storage temperature	-40 ... +70°C.

1.5 Product Component Name




V9-H-4T0.75G/1.5L ... V9-H-4T7.5G/11L


V9-H-4T11G/15L ... V9-H-4T630G/710L

Figure 1-1 Product component name

1.6 Dimensions



V9-H-4T0.75G/1.5L ... V9-H-4T7.5G/11L



V9-H-4T11G/15L ... V9-H-4T630G/710L

Figure 1-2 Product outline and mounting dimensions

Product mounting dimensions

Voltage	Model	Outline and mounting dimensions (mm)							Weight (kg)
		W	H	D	W1	H1	T1	Mounting hole diameter d	
400V	V9-H-4T0.75G/1.5L	118	190	155	105	173	3	5.5	1.5
	V9-H-4T1.5G/2.2L	118	190	175	105	173	4	5.5	2.6
	V9-H-4T2.2G/3.7L								
	V9-H-4T3.7G/5.5L								
	V9-H-4T5.5G/7.5L	155	249	185	136	232	8	5.5	3
	V9-H-4T7.5G/11L								
	V9-H-4T11G/15L	198	299	190	160	283	1.2	6	8
	V9-H-4T15G/18.5L								
	V9-H-4T18.5G/22L	223	348	208	195	335	1.5	6	10
	V9-H-4T22G/30L								
	V9-H-4T30G/37L	264	430	235	230	418	1.5	7	18
	V9-H-4T37G/45L								
	V9-H-4T45G/55L	305	545	270	245	523	1.5	10	35
	V9-H-4T55G/75L								
	V9-H-4T75G/90L	338	580	310	270	560	1.5	10	52
	V9-H-4T90G/110L								
	V9-H-4T110G/132L								
	V9-H-4T132G/160L	400	917	323	320	890	3.0	12	75
	V9-H-4T160G/185L								
	V9-H-4T185G/200L	540	890	385	370	855	4.0	14	85
	V9-H-4T200G/220L								
	V9-H-4T220G/250L	540	890	416	370	855	4.0	14	85
	V9-H-4T250G/280L	700	1010	385	520	977	4.0	14	125
	V9-H-4T280G/315L								
	V9-H-4T315G/355L	700	1010	418.5	520	977	4.0	14	125
	V9-H-4T355G/400L	810	1358	425	520	1300	4.0	14	215
	V9-H-4T400G/450L	810	1358	425	520	1300	4.0	14	215
	V9-H-4T450G/500L								
	V9-H-4T500G/560L								

Note: Higher power products are customized products

1.7 Keypad Outline and Dimensions




Figure1-3 Keypad outline and mounting dimensions

1.8 Pallet Outline Dimensions

V9-DP05 is a mounting accessory can help the keypad installed on the external control cabinet. The outline and dimensions are as follows:




Figure1-4 Pallet outline and mounting dimensions

1.9 Brake Resistor

Drive model	Brake chopper	Brake resistor				Braking torque %
		Power (kW) (10% ED)	Resistance value (Ω)	Minimum resistance (Ω)	Qty.	
V9-H-4T0.75G/1.5L	Built-in as standard	110W	750 Ω	125 Ω	1	130
V9-H-4T1.5G/2.2L		260W	400 Ω	100 Ω	1	125
V9-H-4T2.2G/3.7L		320W	250 Ω	100 Ω	1	135
V9-H-4T3.7G/5.5L		550W	150 Ω	40 Ω	1	135
V9-H-4T5.5G/7.5L		800W	100 Ω	40 Ω	1	135
V9-H-4T7.5G/11L		1070W	75 Ω	40 Ω	1	130
V9-H-4T11G/15L		1600W	50 Ω	40 Ω	1	135
V9-H-4T15G/18.5L		2000W	40 Ω	30 Ω	1	125
V9-H-4T18.5G/22L	Built-in as option	4800W	32 Ω	20 Ω	1	125
V9-H-4T22G/30L		4800W	27.2 Ω	20 Ω	1	125
V9-H-4T30G/37L		6000W	20 Ω	14 Ω	1	125
V9-H-4T37G/45L		9600W	16 Ω	14 Ω	1	125
V9-H-4T45G/55L		9600W	13.6 Ω	10 Ω	1	125
V9-H-4T55G/75L		6000W	20 Ω	7 Ω	2	135
V9-H-4T75G/90L		9600W	13.6 Ω	5 Ω	2	145
V9-H-4T90G/110L		11000W	9.6 Ω	3.5 Ω	2	145
V9-H-4T110G/132L		11000W	9.6 Ω	3.5 Ω	2	145

Notes:

- The resistance value of brake resistor must be higher than the minimum resistance value of the above table; otherwise, the built-in brake chopper will be damaged.
- The higher power of the brake resistor, the better. The brake resistor power in the table is calculated with the braking duration within 30s. If the braking duration is longer, the brake resistor power must be higher. Please select the appropriate brake resistor power according to the actual situation.
- The selection of brake resistor and brake chopper should according to system inertia, deceleration time, descent distance and time (i.e. potential energy), etc. If there is a large inertia in the system, requires a short deceleration time, and braking works very frequently, the brake resistor needs higher power and smaller resistance value.
- The connection mode for multiple braking resistors is parallel connection. For example, V9-H-4T55G/75L, the braking resistor is suggest to select two 6000W 20 Ω braking resistor in parallel connection, amount to braking resistor is 12000W, 10 Ω .
- It is require external brake chopper for the drive power higher than 132kW.

Chapter 2 Mechanical Installation

2.1 Installation Environment

- Install the drive in an area without dust, metal powder, oil, water, or other unwanted materials.
- Install the drive in an area without oil mist, corrosive gas, or flammable gas, explosive gas.
- Install the drive in an area without radioactive or flammable materials; keep wood and other flammable materials away from the drive.
- Install the drive in an area without harmful gas or fluids.
- Install the drive in an area without salt.
- Install the drive in an area without direct sunlight.
- Do not leave drilling residues inside the drive when installation.
- Install the drive vertically for sufficient airflow to cool the drive in the electric control cabinet, use a cooling fan or air conditioner to keep the internal air temperature in the permitted range.
- It is recommended to install the heat sink outside the cabinet for harsh installation environments.

2.2 Installation Direction and Clearances

As shown in the following figure, install the drive vertically for sufficient airflow to cool the drive. Make sure that there is sufficient space for wiring and airflow to cool the drive.




Figure2-1 Installation direction and clearance for V9-H-4T7.5G/11L and below power class

Note: When the V9-H-4T7.5G/11L and below power class drives are installed side by side in the control cabinet, please remove the upper dust guard and the lower leading board.




Figure 2-2 Installation direction and clearance for V9-H-4T11G/15L and above power class

2.3 Remove and Install the Front Cover

2.3.1 Remove and Install the Keypad

■ Remove the keypad

As shown in the Figure 2-3, push down the tab on the top of the keypad, then pull the keypad forward and remove it from the drive.

■ Install the keypad

As shown in the Figure 2-4, put the bottom of the keypad into position first, then carefully push on the top of the keypad until the hook clicks into place. Do not install the keypad in any other direction; otherwise, the keypad will have poor contact.




Figure 2-3 Remove the keypad




Figure 2-4 Install the keypad

2.3.2 Remove and Install the Cover (Products 0.75 to 7.5kW)

- **Remove the keypad**

Please refer to “2.3.1 Remove and Install the Keypad”.

- **Remove the lower cover**

After removing the mounting screws of the cover, press the left and right sides of the cover forcefully in direction 1 and lift the cover in direction 2, as shown in the Figure 2-5.

- **Remove the upper cover**

As shown in the Figure 2-6, press the left and right sides of the cover forcefully in direction 1, and lift the cover in direction 2.

- **Install the upper cover**

After finish the wiring of main circuit and control circuit, insert the upper claw grab of the upper cover into the groove of the product body, as shown in position 1 in the Figure 2-7, and then press the lower part in direction 2 as shown in the Figure 2-7, until the “crack” sound is heard.

- **Install the lower cover**

Insert the upper claw grab on the lower cover into the groove of the upper cover, as shown in position 1 in the Figure 2-8, and then press the lower part in direction 2 in the Figure 2-8, until hear the “crack” sound. Then, tighten the cover screws.

- **Install the keypad**

Please refer to “2.3.1 Remove and Install the Keypad”.




Figure 2-5 Remove the lower cover




Figure 2-6 Remove the upper cover




Figure 2-7 Install the upper cover




Figure 2-8 Install the lower cover

2.3.3 Remove and Install the Cover (Products 11kW to 160kW)

- **Remove the keypad**

Please refer to “2.3.1 Remove and Install the Keypad”.

- **Remove the cover**

Remove the mounting screws on the lower part of the cover, lift the cover in direction 1 as shown in the Figure2-9, and then remove the cover in direction 2.

- **Install the cover**

After the wiring of the main circuit terminals and control circuit terminals is completed, clamp the cover in direction 1 as shown in the Figure2-10, press down the cover in direction 2 and then tighten the cover screws.

- **Install the keypad**

Please refer to “2.3.1 Remove and Install the Keypad”.

Note: Please do not directly mount the cover with the keypad; otherwise, the keypad will have poor contact.




Figure2-9 Remove the cover




Figure2-10 Install the cover

2.3.4 Open and Close the Cover (Products 185kW ... 710kW)

◆ Open the door

Press the latch follow the direction 1 in the Figure2-11 and open the door follow the direction 2.

◆ Remove the keypad

The keypad is connected to the control board through the network cable and will not interfere with the open and close the door. For remove the keypad, refer to “2.3.1 Remove and Install the Keypad”.

◆ Install the cover

After the connection of main circuit terminals and control circuit terminals is completed, close the door follow the direction 1 in Figure2-12, and then press down the latch follow direction 2 to close and lock the door.




Figure2-11 Open the door




Figure2-12 Close the cover

Chapter 3 Electrical Installation

3.1 Peripheral Devices Connection




Figure 3-1 Connection diagram of the product and peripheral devices


3.2 Peripheral Devices Description

Device	Model selection reference
Circuit breaker	<p>The circuit breaker capacity should be 1.5 to 2 times of the drive rated current.</p> <p>The time characteristics of the circuit breaker must fully consider the time characteristics of the drive overload protection.</p>
RCCB (Residual current circuit breaker)	<p>The drive output is high-frequency pulse so as generates leakage current to ground. When a RCCB is installed at the input end, please use a specialized RCCB. It is suggested to choose type B RCCB and set the leakage current higher than 300mA.</p>
Contactor	<p>Frequent contactor action will cause drive failure, the maximum frequency for the open and close the contactor shall not exceed 10 times/min.</p> <p>When use a brake resistor, in order to avoid the brake resistor over-temperature and be damaged, a thermal protection relay with brake resistor over-temperature detection should be installed to disconnect the contactor of power supply.</p>
Input AC reactor or DC reactor	<ol style="list-style-type: none"> 1. The power supply capacity is more than 600kVA or 10 times of the drive capacity. 2. If there is a switch-type reactive compensation capacitor or a thyristor phase-controlled load on the same power supply node. There will be a large peak current flowing into the input power circuit, which will cause damage to the rectifier. 3. When the voltage imbalance of drive's three-phase power supply exceeds 3%, it may cause interference to the system or cause damage to the rectifier. 4. The input power factor of the drive is required higher than 90%, and the input AC reactor can improve the power factor of the input side. 5. Improve the input side of the high-order harmonic; prevent distortion of voltage waveform from causing damage to other equipment. 6. Improve the impact of high order harmonics on the input side of the drive and reduce external conducted and radiated interference. <p>When exists the above situations, an AC reactor at the drive input side or a DC reactor should be installed.</p>
Input noise filter	<p>It can reduce the interference from power supply to the drive and improve the anti-interference ability of the drive.</p> <p>It can reduce the external conduction and radiation interference of the drive.</p>
Thermal protection relay	<p>Although the drive has its own motor overload protection function, when a drive drives two or more motors or drives a multi-poles motor, a thermal protection relay shall be installed between the drive and each motor.</p>
Output noise filter	<p>It can reduce the external conduction and radiation interference of the drive.</p>
Output AC reactor	<p>When the cable from the drive to the motor exceeds 100 meters, an AC output reactor should be installed to suppress high-frequency oscillation, avoid motor insulation damage, prevent excessive leakage current and drive protection.</p>

3.3 Peripheral Devices Models


Drive model	Circuit breaker (A)	Contactor (A)	R/L1, S/L2, T/L3, $\oplus 1$, $\oplus 2/B1$, B2, Θ , U/T1, V/T2, W/T3			Grounding PE \oplus		
			Terminal screw	Tightening torque (N·m)	Cable (mm ²)	Terminal screw	Tightening torque (N·m)	Cable (mm ²)
V9-H-4T0.75G/1.5L	10	10	M4	1.2 ... 1.5	2.5	M4	1.2 ... 1.5	2.5
V9-H-4T1.5G/2.2L	16	10	M4	1.2 ... 1.5	2.5	M4	1.2 ... 1.5	2.5
V9-H-4T2.2G/3.7L	16	10	M4	1.2 ... 1.5	2.5	M4	1.2 ... 1.5	2.5
V9-H-4T3.7G/5.5L	25	16	M4	1.2 ... 1.5	4	M4	1.2 ... 1.5	4
V9-H-4T5.5G/7.5L	32	25	M4	1.2 ... 1.5	6	M4	1.2 ... 1.5	6
V9-H-4T7.5G/11L	40	32	M4	1.2 ... 1.5	6	M4	1.2 ... 1.5	6
V9-H-4T11G/15L	63	40	M5	2.5 ... 3.0	6	M5	2.5 ... 3.0	6
V9-H-4T15G/18.5L	63	63	M5	2.5 ... 3.0	6	M5	2.5 ... 3.0	6
V9-H-4T18.5G/22L	100	63	M6	4.0 ... 5.0	10	M6	4.0 ... 5.0	10
V9-H-4T22G/30L	100	100	M6	4.0 ... 5.0	16	M6	4.0 ... 5.0	16
V9-H-4T30G/37L	125	100	M6	4.0 ... 5.0	25	M6	4.0 ... 5.0	16
V9-H-4T37G/45L	160	100	M6	4.0 ... 5.0	25	M6	4.0 ... 5.0	16
V9-H-4T45G/55L	200	125	M8	9.0 ... 10.0	35	M8	9.0 ... 10.0	16
V9-H-4T55G/75L	315	250	M8	9.0 ... 10.0	50	M8	9.0 ... 10.0	25
V9-H-4T75G/90L	350	330	M8	9.0 ... 10.0	60	M8	9.0 ... 10.0	35
V9-H-4T90G/110L	315	250	M8	9.0 ... 10.0	70	M8	9.0 ... 10.0	35
V9-H-4T110G/132L	350	330	M8	9.0 ... 10.0	100	M8	9.0 ... 10.0	50
V9-H-4T132G/160L	400	330	M12	31.4 ... 39.2	150	M12	17.6 ... 22.5	75
V9-H-4T160G/185L	500	400	M12	31.4 ... 39.2	185	M12	17.6 ... 22.5	50×2
V9-H-4T185G/200L	630	500	M12	48.6 ... 59.4	240	M12	31.4 ... 39.2	60×2
V9-H-4T200G/220L	630	500	M12	48.6 ... 59.4	240	M12	31.4 ... 39.2	60×2
V9-H-4T220G/250L	800	630	M12	48.6 ... 59.4	150×2	M12	31.4 ... 39.2	75×2
V9-H-4T250G/280L	1000	630	M12	48.6 ... 59.4	185×2	M12	31.4 ... 39.2	100×2
V9-H-4T280G/315L	1000	630	M12	48.6 ... 59.4	185×2	M12	31.4 ... 39.2	100×2
V9-H-4T315G/355L	1000	800	M14	48.6 ... 59.4	250×2	M14	31.4 ... 39.2	125×2
V9-H-4T355G/400L	1200	800	M14	48.6 ... 59.4	325×2	M14	31.4 ... 39.2	150×2
V9-H-4T400G/450L	1500	1000	M14	48.6 ... 59.4	325×2	M14	31.4 ... 39.2	150×2
V9-H-4T450G/500L	2000	1500	M14	48.6 ... 59.4	350×2	M14	31.4 ... 39.2	175×2
V9-H-4T500G/560L	2000	1500	M14	48.6 ... 59.4	350×2	M14	31.4 ... 39.2	175×2

3.4 Terminal Configuration



V9-H-4T0.75G/1.5L ... V9-H-4T7.5G/11L

V9-H-4T11G/15L ... V9-H-4T15G/18.5L



V9-H-4T18.5G/22L ... V9-H-4T160G/185L

V9-H-4T185G/200L ... V9-H-4T500G/560L

Figure 3-2 Terminal Configuration

3.5 Main Circuit Terminal Description

◆ V9-H-4T0.75G/1.5L ... V9-H-4T7.5G/11L: Built-in brake chopper as standard.

									Terminal Symbol	Description
R/L1	S/L2	T/L3	+1	+2/B1	B2	—	U/T1	V/T2	W/T3	Three-phase AC input
POWER			OPTION			MOTOR			+1, +2/B1	DC reactor connecting terminal, short circuited with copper bus by default
									+2/B1, B2	Connecting terminal of brake resistor
									+2/B1, —	DC power input terminal; DC input terminal of external brake chopper
									U/T1, V/T2, W/T3	Three-phase AC output terminal
									⊕	Grounding terminal PE

◆ V9-H-4T11G/15L ... V9-H-4T15G/18.5L: Built-in brake chopper as standard.

									Terminal Symbol	Description
R	S	T	BR	+	—	U	V	W	R, S, T	Three-phase AC input
POWER			OPTION			MOTOR			BR, +	Connecting terminal of brake resistor
									+, —	DC power input terminal, DC input terminal of external brake chopper.
									U, V, W	Three-phase AC output terminal
									⊕	Grounding terminal PE

◆ V9-H-4T18.5G/22L ... V9-H-4T37G/45L: Built-in brake chopper as option

									Terminal Symbol	Description
R	S	T	BR	+	—	U	V	W	R, S, T	Three-phase AC input
POWER			OPTION			MOTOR			BR, +	Connecting terminal of brake resistor
									+, —	DC power input terminal, DC input terminal of external brake chopper
									U, V, W	Three-phase AC output terminal
									⊕	Grounding terminal PE

◆ V9-H-4T45G/55L ... V9-H-4T110G/132L: Built-in brake chopper as option

									Terminal Symbol	Description
R	S	T	BR	+	—	U	V	W	R, S, T	Three-phase AC input
POWER			OPTION			MOTOR			BR, +	Connecting terminal of brake resistor
									+, —	DC power input terminal, DC input terminal of external brake chopper
									U, V, W	Three-phase AC output terminal
									⊕	Grounding terminal PE

◆ V9-H-4T132G/160L ... V9-H-4TG160G/185L: Without built-in brake chopper

									Terminal Symbol	Description
R	S	T	+	—	U	V	W		R, S, T	Three-phase AC input
POWER						MOTOR			+, —	DC power input terminal, DC input terminal of external brake chopper
									U, V, W	Three-phase AC output terminal
									⊕	Grounding terminal PE

◆ V9-H-4T185G/200L ... V9-H-4T500G/560L: Without built-in brake chopper

									Terminal Symbol	Description
R/L1	S/L2	T/L3				U/T2	V/T2	W/T3	R/L1, S/L2, T/L3	Three-phase AC input
POWER									+1, +2	DC reactor connecting terminal The drive will no display after power on if not connect the DC reactor.
									+2, —	DC power input terminal, DC input terminal of external brake chopper.
									U/T1, V/T2, W/T3	Three-phase AC output terminal
									⊕	Grounding terminal PE

3.6 Attention for Main Circuit Wiring

3.6.1 Power Supply

- ◆ Do not connect the power supply cable to the output terminal; it can cause damage to the internal components of the drive.
- ◆ For input side over-current protection and maintenance conveniently, the drive should be connected to the power supply through a breaker or RCCB and contactor.
- ◆ Please confirm whether the number of power phases and rated voltage are consistent with the nameplate of the product, otherwise the drive may be damaged.

3.6.2 Motor

- ◆ Do not connect terminals to the ground terminal. If you connect these terminals to earth ground, it can cause damage to the drive or serious injury or death.
- ◆ Avoid output cables (U/V/W) short circuit or short circuit to enclosure, otherwise there is a risk of electric shock.
- ◆ It is strictly forbidden to connect a capacitor or phase lead LC/RC noise filter to the output of the drive, otherwise the drive will be damaged.
- ◆ When a contactor is installed between the drive and the motor, the switching action of the output contactor cannot be performed (ON or OFF) during the operation of the drive, otherwise a large current will flow into the drive to and the drive will trip on a fault, even cause damage to the drive.
- ◆ Cable length between drive and motor: When the cable between the drive and the motor is too long, the high-order harmonic leakage current at the output will adversely affect the drive and peripheral devices. It is recommended to install an output AC reactor when the motor cable exceeds 100 meters, and contact the manufacturer to inquire whether the carrier frequency needs to be modified.

3.6.3 Grounding

- ◆ The drive generates leakage current, and the larger the carrier frequency, the more the leakage current. The leakage current of the drive is higher than 3.5mA. The leakage current is determined by the conditions of use. To ensure safety, the drive and motor must be grounded.
- ◆ The grounding resistance should be less than $10\ \Omega$. For the wire diameter requirements of the grounding cable, please refer to "3.3 Peripheral Devices Models".
- ◆ Do not share the grounding wire with welding machines and other power equipment.
- ◆ When using two or more drives, the grounding wire should not form a loop.




Figure 3-4 Grounding wiring

3.6.4 Countermeasures for Conduction and Radiation Interference




Figure 3-4 Noise current illustration

- ◆ If an input noise filter is installed, the wiring from the filter to the input power supply of the drive should be as short as possible.
- ◆ The outer casing of the filter and the mounting cabinet should be reliably connected over a large area to reduce the return impedance of the noise current I_g .
- ◆ The cable distance between the drive and the motor should be as short as possible, and the motor cable should use 4-core cable. One end of the ground cable is grounded to the drive side, the other end is connected to the motor enclosure, and the motor cable is inserted into a metal tube.
- ◆ The input power cable and output motor cable should be as far away as possible.
- ◆ The susceptible equipment and signal cables should be installed as far away as possible from the drive.
- ◆ Critical signal cables should use shielded cables. It is recommended that the shield layer be grounded by a 360-degree grounding method and inserted into the metal tube. Keep away from the input power cable and output motor cable. If a signal cable must cross the input power cable or the output motor cable, they should be orthogonal.
- ◆ When the frequency reference source is analog input (voltage or current signal), use a double-stranded shielded cable and connect the shield layer to the grounding terminal PE of the drive. The signal cable length must less than 50 meters.
- ◆ The wiring of the control circuit relay output signal and other control circuit signal should be separate.
- ◆ It is strictly forbidden to short-circuit the shield layer with other signal cables and equipment.
- ◆ When the drive is connected to an inductive load device (magnetic contactor, relay, solenoid valve, etc.), be sure to use a surge suppressor on the load device coil as shown below.




Figure 3-5 Application of inductive load surge suppressor

3.7 Terminal Wiring 1




Figure3-6 Terminal wiring diagram (take V9-H-4T5.5G/7.5L as an example)

3.8 Terminal Wiring 2




Figure3-6 Terminal wiring diagram (take V9-H-4T15G/18.5L as an example)


Notes:

- This control board support resolver signal input.
- This control board is equipped with drive above 11kW as standard, 5.5 kW and 7.5kW products equipped are optional, if necessary, please indicate when ordering.
- This control board with motor temperature detection part is in the 9 pin DB head, and the analog AI3 does not support the motor temperature detect function.
- X6 and X7 of this control board used as high speed pulse input terminal are not support.

3.9 Control Circuit Description

Terminal	Symbol	Function description	Technical specifications
Modbus	485+	RS485 positive end	<ul style="list-style-type: none"> Baud rate: 4800/9600/19200/38400/57600/57600bps Up to 32 units are connected in parallel. If more than 32 units are used, repeaters are required.
	485-	RS485 negative end	
	GND	Modbus ground terminal	
Keypad	CN7	RS485 port of keypad	The maximum distance for keypad is 15 m (network cable)
Digital inputs	+24V	+24V	24V \pm 10%, internal isolated with GND Maximum output current: 200mA
	PLC	Power supply of DI	Short to +24V by default
	X1 ... X7	Digital inputs 1 ... 7	Input specification: 24VDC \pm 20%, 5mA Frequency range: 0 ... 1KHz
	COM	Digital inputs common	The interior isolated from GND
Digital outputs	Y1	Open collector output 1	Voltage range: 24V \pm 20% Maximum output current: 50mA
	Y2	Open collector output 2	
	COM	Y1 and Y2 common	The interior isolated from GND
Relay outputs	RA/RB/RC	Relay output 1	RA—RB: Normally closed RA—RC: Normally open Contact capacity: 250VAC/1A, 30VDC/1A
	RA1/RC1 (≥ 11 kW)	Relay output 2	RA1—RC1: Normally open Contact capacity: 250VAC/1A, 30VDC/1A
	RA2/RC2 (≥ 11 kW)	Relay output 3	RA2—RC2: Normally open Contact capacity: 250VAC/1A, 30VDC/1A
Analog inputs	+10V	AI reference voltage	10V \pm 3%, internal isolated with COM Maximum output current: 10mA
	AI1	Analog input 1	-10V...10V: Input impedance 20k Ω , max. voltage: \pm 15V 0...20mA: Input impedance 500 Ω , max. current: 30mA Resolution: 12 bits (0.025%) Note: AI3 input current 0...20mA is not supported.
	AI2	Analog input 2	
	AI3	Analog input 3	
	GND	Analog GND	The interior isolated from COM
Analog outputs	AO1	Analog output 1	Select analog voltage or current output by jumper 0 ... 20mA: Output allowable impedance 200 to 500 Ω 0 ... 10V: Output allowable impedance ≥ 10 k Ω
	AO2	Analog output 2	
	GND	Analog ground terminal	The interior isolated from COM
Resolver (≥ 11 kW)	1	REF-	Resolver signal REF1
	2	REF+	Resolver signal REF+
	3	SIN+	Resolver signal SIN+
	4	SIN-	Resolver signal SIN-
	5	COS+	Resolver signal COS+
	6	PT100	PT100 temperature sensor
	7	COM	PT100 gnd
	8	None	
	9	COS-	Resolver signal COS-


1. The arrangement sequence of the control circuit terminals is as follows ($\geq 11\text{kW}$):



Notes:

- This control board support resolver signal input.
- This control board is equipped with drive above 11kW as standard.
- 5.5 kW and 7.5kW drives equipped this control board are optional, if it is required, please indicate when ordering.
- This control board with motor temperature detection part is in the 9 pin DB head, and the analog AI3 does not support the motor temperature detection function.
- X6 and X7 of this control board used as high-speed pulse input terminal are not support.

2. The arrangement sequence of the control circuit terminals is as follows ($\leq 7.5\text{kW}$):




Notes:

- This control board is equipped with drive $\leq 7.5\text{kW}$ as standard.
- The drives power higher than and equal to 11kW equipped this control board are optional; if it is required, please indicate when ordering.


3.10 Digital inputs and Outputs

■ Internal +24V power supply, NPN sinking mode




■ External power supply, NPN sinking mode

Note: Must remove short wire between +24V and PLC.




■ Internal +24V power supply, PNP sourcing mode

Note: Remove short wire between +24V and PLC and short terminals PLC and COM





■ External power supply, PNP sourcing mode

Note: Must remove short wire between +24V and PLC



■ The wiring modes of the digital outputs use internal +24V power supply and external power supply




Note: Must ensure the polarity of external diode is correct, otherwise, will damage Y1/Y2 terminal.

3.11 Control Circuit Peripheral Devices

Terminal number	Terminal screw	Tightening torque (N·m)	Cable mm ²	Cable type
+10V, AI1, AI2, AI3, 485+, 485-, AO1, AO2, GND	M3	0.5 ... 0.6	0.75	Shielded twisted pair cable
+24V, PLC, X1, X2, X3, X4, X5, X6, X7/DI, COM, Y1, Y2, COM, RA, RB, RC, RA1, RC1, RA2, RC2	M3	0.5 ... 0.6	0.75	Shielded cable

3.12 Jumper Description



Note:




Figure 3-7 Jumper and DIP switch

Jumper	PIN	Default
S1(AI1)	V: Voltage input 0...10V	V
	I: Current input 0/4mA ...20mA	
S2(AI2)	V: Voltage input 0...10V	I
	I: Current input 0/4mA ...20mA	
S8(AI3)	AI3: Voltage input -10...10V (Note: S8, S9, S5 combined use)	AI3
	TEMP: Using AI3 as motor temperature detection	
S6(AO1)	V: Voltage output 0...10V	V
	I: Current output 0...20mA	
S7(AO2)	V: Voltage output 0...10V	I
	I: Current output 0...20mA	
S3(485)	ON: Connect 100 Ω termination resistor	OFF
	OFF: Disconnect 100 Ω termination resistor	
S4(PE)	ON: Grounding	ON
	OFF: No grounding	
S5(PT/KTY)	PT100: AI3 use as PT100 input terminal	KTY84
	KTY84: AI3 use as KTY84 input terminal	
S9	AI3 use as analog input: AI3-AD1: ON, TEMP: OFF.	AI3-AD1
	AI3 use as temperature sensor input: AI3-AD1: OFF, TEMP: ON.	

Note: If the control board with resolver is selected, the control board without S8 and S9 jumpers and AI3 cannot be used for motor temperature sampling. The motor temperature detect input in the 9 pin DB head of the encoder port.

Chapter 4 Keypad Operation

4.1 Keypad Model











Figure4-1 Keypad model

The keypad has the following features:

- Set parameters – the parameters can be change by keypad.
- Motor parameters auto tune – use the keypad to set the motor parameters auto-tune mode and start auto-tune.
- Monitoring function – use the keypad to monitor the parameters value, running state, fault record, etc.
- Start and stop the drive when the run command source is keypad.
- Reset faults after fault report.
- Copy function – parameters value can be copied to the keypad memory for later transfer to other drives or for backup.
- The keypad can be used to reset the parameters to default values.
- Check which parameters are different from the default values, it is convenient to check whether the parameters are changed correctly.
- Remote control box – the keypad can be used as remote-control box functions via net cable.
- External installing pallet – external installing pallet is available; it is convenient to help the keypad be installed on the electrical cabinet.
- The keypad and drive can be disconnected and connected at any time.
- Chinese and English Language are available for the LCD keypad.

4.2 Keypad Keys

Key	Name	Function
	Program Key	<ol style="list-style-type: none"> 1. Enter the sub-menu. 2. Enter the parameter setting menu. 3. Data storage confirmation.
	Escape Key	<ol style="list-style-type: none"> 1. Return to the previous menu. 2. Abandon the modification of the data.
	Increase / Decrease Key	<ol style="list-style-type: none"> 1. Change the speed reference in monitoring state when speed reference channel is keypad. 2. Change the parameters group number or parameter numbers in parameters display menu. 3. Change the parameter's value in parameter's value setting menu.
	Shift Right / Shift Left Key	<ol style="list-style-type: none"> 1. Switch display monitored value in turn in monitoring menu. 2. Change the parameter group No. or parameter No. in parameters display menu. 3. Change the current edit bit in parameter's value setting menu.
	Run Key	<ol style="list-style-type: none"> 1. Press RUN key to start the motor when run command is keypad. 2. Press RUN key to start motor data identification after setting motor data identification function.
	Stop / Reset Key	<ol style="list-style-type: none"> 1. Press STOP key to stop the motor when run command selection is keypad. 2. Press STOP key to reset the fault when the drive has fault. 3. Press M key and STOP key at the same time to stop the drive by coast to stop immediately.
	Multifunctional Key	<ol style="list-style-type: none"> 1. Press M key and STOP key at the same time to stop the drive by coast to stop immediately.

4.3 Keypad Indicator

V9-DP01 indicator description:

Indicator status			Color	Description
Unit indicator	Hz	Frequency indicator	Green	On: Current displayed parameter is running frequency Flash: Current displayed parameter is setting frequency
	A	Current indicator	Green	On: Current displayed parameter is output current
	V	Voltage indicator	Green	On: Current displayed parameter is voltage
	HZ+A	Rotating speed indicator	Green	On: Current displayed parameter is rotating speed Flash: Current displayed parameter is setting rotating speed
	HZ+V	Percentage % indicator	Green	On: The current display parameter is percentage
	A+V	Time indicator	Green	On: The current display parameter is time
Status indicator	RUN	Running indicator	Red	On: Running status Off: Stop status
	FWD	Forward indicator	Red	On: In stop status, receive a run forward command In running status, in forward running status OFF: Changing from forward to reverse running or in stop status.
	REV	Reverse indicator	Red	ON: In stop status, receive a run reverse command In running status, in reverse running status OFF: Changing from reverse to forward running or in stop status.
	/	Fault indicator	/	All the status indicators are in flash: Fault status

V9-DP02 indicator description: V9-DP02 with a status indicator to indicate the drive in running state, stop state, or fault state.

Indicator status	Description
Off	Stop state
Green, keep on	Running state
Red, keep on	Fault state

4.4 LCD Keypad Interface






Figure 4-2 Description of LCD keypad display interface

4.5 LCD Keypad Operation


Change display language. (Set P0-000 = 1: display language is English)




Change a parameter, set P1-005 to 50.00.



Reset to Default Value, Set D0-002 to 2.




Check which parameters is changed




Change the monitoring parameters in default pages?


There are 5-page parameters can be display on the main menu mode and three parameters can be selected to display on every page. Each page can be switchover by right key (▶) or left key (◀) on the keypad. For example, if I want to display output speed on the first position of first page:



Back up parameters to LCD keypad



Download parameters from LCD keypad



4.6 LED Keypad Operation

4.6.1 Display Status Classification

- The keypad display status is divided into five types:

No.	Name of status	Meaning
1	Parameter display status	The default display interface during standby. The display parameters can be switched by the left shift key "◀" or the right shift key "▶".
2	Fault and alarm display status	This state is entered directly when the drive has a fault alarm.
3	First level menu display status	Press the PRG key in the first menu state to enter directly.
4	Secondary menu editing status	Press the PRG key to enter in the first menu display state.
5	Modify parameter status	After entering the current user parameters, when the current edit bit is flashing, you can use the ▲, ▼ keys to modify the parameter value.

4.6.2 Display Status and Operation Process

Automatic switch the status.

After 30 seconds without key operation, it automatically returns to the stop parameter display state or the operation parameter display state.

After 1 minute without key operation, clear the PX–YZ menu editing status and return to P0–000.

If there is password setting or key lock setting, the password protection and keypad lock status will be automatically entered after 5 minutes without button operation.

Display status and operation flow






Figure 4-3 Status Display and Operation Flow

4.6.3 LED Keypad Operation

Reset to Default Value, Set d0-002 to 2



Change parameter: set P1-005 to 50.00.



4.7 Password Setting

◆ Set password

Enter d0-00 and set the same parameters (non-zero values) twice in succession. After "P-SEt" is displayed, the password is set successfully

◆ Verify password

- ① Press ESC+▶+▼ at the same time till the keypad display unLoC to unlock .
- ② Enter d0-00, enter the password correctly, all parameters can be seen.

◆ Clear password

After the verification password is passed, enter d0-00 and set 00000 twice in succession. After the display of "P-CLa", the password is successfully cleared

◆ Methods for password protection take effect

- ① Press the ESC+PRG +▲ key at the same time to display "P-LoC", then the keypad is locked.
- ② No key operation for 5 minutes.
- ③ Power on again.

4.7.1 Lock and Unlock the keypad Keys

◆ The keys on the keypad can be locked, the locking range is defined by the parameter d0-007.

- 0: All keys are effective.
- 1: All keys are locked, have no effective.
- 2: All keys are locked except the RUN and STOP keys.

◆ Methods for key locking to take effect.

1. Press the ESC+PRG +▲ key at the same time to display "loc-1"(select to lock all keys) or "Loc-1" (RUN, STOP is not locked, other keys are locked), then the keypad keys is locked.
2. No key operation for 5 minutes.

◆ Press ESC+▶+▼ at the same time to unlock the keys locking.

4.8 Menu Mode

Two level menu style is adopted in menu display. The first level menu is parameter index, and the second level menu is parameter value.

4.8.1 First Level Menu




Figure 4-4 The Format of the First Level Menu

◆ The structure of the first level menu




Figure 4-5 The structure of the first level menu

4.8.2 The Second Level Menu




Figure 4-6 The Format of the second level menu

◆ Format of second level menu data display / setting

Decimalism display/setting:

The data bits 1 – 5 can be displayed/set with symbols of 0, 1, ...9

When the display data is greater than 5 digits, the truncation method is used.

For example, when the data is -12345, the operation panel displays “-1234.”.

Hexadecimal display/setting:

The data bits 1 – 4 can be displayed/set with symbols of 0, 1, ...9, A, B, C, D, E, F.

4.8.3 LED Keypad Parameter Access Level

Parameter access level	Option	Parameter visible range
0	Basic menu	Show all parameters
1	Non-factory value menu	Only show modified and read-only parameters

4.8.4 LED Keypad Display Symbols

In addition to the parameter the first and second level menus, some prompt characters will also be displayed in the keypad in the table below:

Symbol	Meaning	Symbol	Meaning
8.8.8.8.8.	When the drive is powered up, it display for a short time before communication is normal.	-DEFT	Restore default value operation
E-XXX	Means the drive trips on a fault.	DEFXX	Restoring default value, XX represents progress, display range 00 to 99
--dc--	Drive DC braking	P-CLA	Password has cleared
ATUnE	Auto-tune	P-SEt	The password has been set successfully
LodXX	Parameters are uploaded to the keypad. XX stands for progress, showing from 00-99.	P-LoC	Password protection has taken effect.
CPyXX	Parameters are downloaded to the drive. XX stands for progress, showing from 00-99.	unLoc	Keypad has unlocked.
pGood	Successful copy of parameters.	Loc-1	All Keys are locked.
EWRFH	Parameter failed to upload to keypad.	Loc-2	Keys are locked except RUN and STOP keys.
EEFSH	Parameter failed to download to drive.		
E-CPy	Parameter download to drive out of range.		
CoErr	Communication error of keypad and drive.		

4.8.5 Recognition of LED display symbols

The corresponding relationship between LED display symbols and characters/numbers:

LED	Meaning	LED	Meaning	LED	Meaning	LED	Meaning
	0		9		H		T
	1		A		J		t
	2		B		j		U
	3		C		L		u
	4		c		N		y
	5		d		n		-
	6		E		o		.
	7		F		p		
	8		G		r		

4.9 First Commissioning and Auto Tune





Figure 4-7 Auto-tune for the first time


Auto-tune selection:

P6-017	Asynchronous motor	Synchronous motor
0	No action	No action
1	Static auto tune	Static auto tune 1
2	Rotate auto tune	Rotate auto tune 1
3		Static auto tune 2
4		Rotate auto tune 2

Auto tune steps for LED keypad:



Auto tune steps for LCD keypad:



Notes:

- If the drive trips a fault after auto tune, it means the auto tune has failed. It is necessary to re check the cable connection, parameter settings and analyze the cause of failure before start auto tune again.
- When start motor rotate auto tune, the motor speed will accelerate to 70% of motor rated speed, please pay attention to the safety.
- When start motor rotate auto tune, please set appropriate acceleration and deceleration time.
- Must set to rotate tune for sensor control to get the encoder other information, such as encoder direction, position of the rotor poles, etc. Before starting auto tune, please ensure the correctness of the wiring and the setting of the necessary parameters for the encoder.

Chapter 5 Parameter List



Parameter groups

Group area	Group	Group description	Group area	Group	Group description
Group P	P0	Basic parameters	Group A	A0	Encode parameters
	P1	Speed reference	Group B (b)	B0 (b0)	Position control
	P2	Acceleration and deceleration time		B1 (b1)	Pulse input and output
	P3	Digital inputs and outputs	Group C	C0	Modbus
	P4	Analog inputs and outputs		C1	CAN / PROFIBUS-DP / ROFINET
	P5	Start and stop		C2	EtherCAT
	P6	Motor parameters	Group D (d)	D0 (d0)	Keypad parameters
	P7	V/F control	Group E	E0	Protection configuration
	P8	Synchronous motor sensor-less control	Group F	F0	Status monitoring parameters
	P9	Vector control		F1	Software version
	PA	Torque control		F2	Product bar code
	PB(Pb)	Advanced control parameters		F3	Trip history
	PC	PID control parameters			

Description of each meaning in the parameter list

Item	Explanation
Parameter	<p>Indicates the number of the parameter, such as P0-000.</p> <p>Notes:</p> <ul style="list-style-type: none"> ➤ The parameter display on the LED keypad is 4 digits, such as P1-23. ➤ The parameter display on the LCD keypad is 5 digits, such as P1-023, the default display mode of this manual is the LCD keypad display mode.
Name	The name of parameter, which explains the parameter's meanings.
Default	The parameter value after reset the default value
Range	Allowable setting range.
Unit	V: voltage; A: current; °C: degrees Celsius; Ω: ohm; rpm: rev/min; %: percentage; bps: baud rate; Hz, kHz: frequency; mH: milli-henry; kW: power; ms, s, min, h, kh: time; /: no unit.
Attribute	○: The parameter can be changed while the drive is running. ×: The parameter only can be changed in stop status. *: The parameter is a read-only parameter and cannot be changed. <u>Text with shadow and underlined means that this function is not supported.</u>
Description	Describe the parameters and values.

5.1 Basic Parameters (P0)

Parameter	Name	Default	Range	Unit	Attribute
P0-000	Language	0	0 ... 1	/	×
<p>Selects the language of the parameter interface and other displayed information when viewed on the LCD keypad.</p> <ul style="list-style-type: none"> ● 0: Chinese ● 1: English <div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Notes:</p> <ul style="list-style-type: none"> ➤ The parameter is only effective for LCD keypad. ➤ This parameter only can be changed manually and cannot be restored by parameter D0-002 					
P0-001	Parameters display mode	0	0 ... 5	/	○
<p>Selects parameters display mode by LED keypad.</p> <ul style="list-style-type: none"> ● 0: Display all the parameters. ● 1: Only display the modified parameters. ● 2 ... 5: Reserved. <p>Note: The parameter is only effective for LED keypad.</p>					
P0-002	Motor control mode	3	0 ... 5	/	×
<p>Selects the motor control mode.</p> <ul style="list-style-type: none"> ● 0: Synchronous motor sensor vector control. The drive controls a synchronous motor in sensor vector control mode. In this control mode, torque control, speed control and position control are available and a speed feedback signal (encoder or resolver) from the motor is necessary. The motor parameters, encoder parameters need to be set correctly and rotate auto tune is required to obtain other motor parameters, encoder phase direction and rotor magnetic pole position, etc. ● 1: Synchronous motor sensor less vector control The drive controls a synchronous motor in sensor less vector control mode. In this control mode, torque control and speed control are available. The motor parameters need to be set correctly and auto tune is required to obtain other motor parameters. ● 2: Asynchronous motor sensor vector control The drive controls an asynchronous motor in vector control mode. In this control mode, torque control, speed control and position control are available and a speed feedback signal (encoder or resolver) from the 					

Parameter	Name	Default	Range	Unit	Attribute
	<p>motor is necessary. The motor parameters and encoder parameters need to be set correctly and rotate auto tune is required to obtain other motor parameters and encoder phase direction.</p> <ul style="list-style-type: none"> ● 3: Asynchronous motor V/F control The drive controls an asynchronous motor in VF control mode. V/F control is generally applicable to control asynchronous motors without encoder speed feedback and not sufficient data to set the motor parameters. VF control also applicable to the applications such as multi-motor applications, the motor rated current is less than 1/6 of the drive rated current, the drive is used with no motor connected and variable frequency power supply, etc. ● 4: Asynchronous motor sensor less voltage vector control The drive controls an asynchronous motor in sensor less voltage vector control mode. In this control mode, a feedback signal from the motor is not necessary. This control mode is sensitive to motor parameters, need to input motor parameters correctly and auto tune is required, it has higher speed control performance than V/F control. ● 5: Asynchronous motor sensor less current vector control The drive controls an asynchronous motor in sensor less current vector control mode. In this control mode, a feedback signal from the motor is not necessary. This control mode is sensitive to motor parameters, need to input motor parameters correctly and auto tune is required, it has higher speed control performance and torque accuracy than sensor less voltage type vector control. <p>Note: The parameter setting should according to the motor and if exist a speed feedback signal from the motor.</p>				
P0-003	System control mode	2	1 ... 3	/	×
	<p>Selects the system control mode.</p> <ul style="list-style-type: none"> ● 1: Position loop The drive controls the motor running in position loop mode. Applicable to orientation and pulse train input position control applications. ● 2: Speed loop The drive controls the motor running in speed loop mode. The speed (or frequency) reference is defined by parameter P0-005. The motor follows a speed reference given to the drive. Speed loop can operate without a speed feedback signal, or with an encoder or resolver for better speed control accuracy. ● 3: Torque loop The drive controls the motor torque in torque loop mode. Motor torque follows a torque reference given to the drive. Torque control is possible without feedback, but is much more dynamic and accurate when used in conjunction with a feedback device such as an encoder or a resolver. Torque loop mode applicable to applications such as winders, unwinders, conveyors and where a particular tension needs to be maintained in the mechanical system. When there is no more material and the machine suddenly has no load, the motor speed will continue to increase until the speed limit. <p>Notes:</p> <ul style="list-style-type: none"> ➤ Position loop control mode is only available in sensor control (P0-002 = 0 or 2), has no effect when sensor less control. ➤ Torque control is available in vector control, has no effect when VF control (P0-002 = 3). 				

Parameter	Name	Default	Range	Unit	Attribute
P0-004	Run command selection	1	0 ... 5	/	×
	<p>Selects the source of run command.</p> <ul style="list-style-type: none"> ● 0: Modbus communication Start and stop through Modbus communication (The Modbus address of the control word is 0x8000; please refer to Appendix A for more information). ● 1: Keypad Start and stop through RUN key and STOP key on the keypad. ● 2: External digital input terminal Start and stop through digital input, refer to parameter P3-001... P3-007 and P3-016 for more information. ● 3...5: Reserved 				
P0-005	Speed reference selection	1	0 ... 11	/	×
	<p>Selects the source of speed (frequency) reference.</p> <ul style="list-style-type: none"> ● 0: Modbus The speed (frequency) reference is given to the drive through Modbus (The Modbus address of the Modbus communication speed reference is 0x8001; please refer to Appendix A for more information). ● 1: Keypad The speed (frequency) reference is given by through √ and ∧ key on the keypad or parameter P1-000 to change the speed (or frequency) reference. Please refer to parameter P1-000 for more information. ● 2: AI1 The speed (frequency) reference is given through analog input AI1. 10V/20 mA = maximum speed P0-012. ● 3 ... 4: Reserved ● 5: PID The speed (frequency) reference is given through PID controller. Refer to group PC for more information. ● 6: AI2 The speed (frequency) reference is given through analog input AI2. 10V/20 mA = maximum speed P0-012. ● 7: AI3 The speed (frequency) reference is given through analog input AI3. 10V = maximum speed P0-012. ● 8: Simple PLC The speed (frequency) reference is given through simple PLC logic, multi constant speeds can be predefined and an operation time can be defined for each constant speed; refer to parameters P1-033 ... P1-069 for more information. ● 9: Multi-step speed (frequency) reference The speed (frequency) reference is given through predefined constant speeds (frequency). It is possible to define up to 16 predefined speeds (frequency) that can be quickly activated through digital inputs, refer to parameters P1-005 ... P1-020 and P3-001 ... P3-007 for more information. ● 10: Digital input terminal UP/DN The digital input(s) is used to increase and decrease speed reference. Please refer to parameter P1-021 for more information. ● 11 ... 14: Reserved 				

Parameter	Name	Default	Range	Unit	Attribute
P0-006	Speed unit	0	0 ... 1	/	×
	<p>The speed unit and upper limit are defined by parameters P0-006 and P0-007.</p> <p>When P0-006 = 0 and P0-007 = 0, the maximum speed range is 0.00 ... 655.35 Hz.</p> <p>When P0-006 = 0 and P0-007 = 1, the maximum speed range is 0.0 ... 6553.5 Hz.</p> <p>When P0-006 = 0 and P0-007 = 2, the maximum speed range is 0... 65535 Hz.</p> <p>When P0-006 = 1, the maximum speed range is 0... 65535 RPM</p> <ul style="list-style-type: none"> ● 0: Motor speed in Hz ● 1: Motor speed in rpm <p>Notes: The parameter only can be changed manually and cannot be restored by parameter D0-002.</p>				
P0-007	Frequency display units	0	0 ... 2	/	×
	<p>Defines the frequency display units when P0-006 = 0. Refer to parameter P0-006 for more information.</p> <ul style="list-style-type: none"> ● 0: 0.01Hz. ● 1: 0.1Hz. ● 2: 1Hz. <p>Note: The parameter is only effective when P0-006 = 0.</p>				
P0-008	Forward speed limit selection	0	0 ... 3	/	×
	<p>Selects the source of the maximum allowed forward speed for the drive.</p> <ul style="list-style-type: none"> ● 0: Parameter P0-010 The parameter P0-010 is used as forward speed limit. 100.0% corresponds to maximum speed P0-012. ● 1: AI1 AI1 voltage/current is converted to a forward running speed limit value. Maximum AI1 input corresponds to the maximum speed P0-012. ● 2: AI2. Same as AI1. ● 3: AI3. Same as AI1. 				
P0-009	Reverse speed limit selection	0	0 ... 3	/	×
	<p>Selects the source of the maximum allowed reverse speed for the drive.</p> <ul style="list-style-type: none"> ● 0: Parameter P0-011 The parameter P0-011 is used as reverse speed limit. 100.0% corresponds to maximum speed P0-012. ● 1: AI1 AI1 voltage/current is converted to a reverse running speed limit value. Maximum AI1 input corresponds to maximum speed P0-012. ● 2: AI2. Same as AI1. ● 3: AI3. Same as AI1. 				
P0-010	Forward speed limit	100.0	0.0 ... 100.0	%	○
	Effective when P0-008 = 0, 100% corresponds to the maximum speed P0-012.				
P0-011	Reverse speed limit	100.0	0.0 ... 100.0	%	○
	Effective when P0-009 = 0, 100% corresponds to the maximum speed P0-012.				

Parameter	Name	Default	Range	Unit	Attribute
P0-012	Maximum speed	50.00	P0-013 ... 655.35	Hz	×
		50.0	P0-013 ... 6553.5	Hz	
		50	P0-013 ... 65535	Hz	
		1500	P0-013 ... 65535	RPM	
	Defines the allowed maximum speed. The range and unit is defined by the parameters P0-006 and P0-007. Note: This parameter lower limit is limited by the minimum speed (parameter P0-013).				
P0-013	Minimum speed	0.00	0.00 ... P0-012	Hz	×
		0.0	0.0 ... P0-012	Hz	
		00	0 ... P0-012	Hz	
		0	0 ... P0-012	RPM	
	Defines the allowed minimum speed. The range and unit is defined by the parameters P0-006 and P0-007. Note: This parameter upper limit is limited by the maximum speed (parameter P0-012).				
P0-014	Forward current limit selection	0	0 ... 3	/	×
	Selects the source of the forward maximum allowed motor current. <ul style="list-style-type: none">● 0: Parameter P0-016 The parameter P0-016 is used as forward maximum allowed motor current.● 1: AI1 AI1 is used as forward maximum allowed motor current. Maximum AI1 input corresponds to 2-times minimum of motor rated current (parameter P6-004) and drive rated output current (defined by drive model).● 2: AI2. Same as AI1.● 3: AI3. Same as AI1.				
P0-015	Reverse current limit selection	0	0 ... 3	/	×
	Selects the source of the reverse maximum allowed motor current. <ul style="list-style-type: none">● 0: Parameter P0-017 The parameter P0-017 is used as reverse maximum allowed motor current.● 1: AI1 AI1 is used as reverse maximum allowed motor current. Maximum AI1 input corresponds to 2-times minimum of motor rated current (parameter P6-004) and drive rated output current (defined by drive model).● 2: AI2. Same as AI1.● 3: AI3. Same as AI1.				
P0-016	Forward current limit	150.0	0.0 ... 300.0	%	○
	Forward maximum allowed motor current. Effective when parameter P0-014 = 0. 100.0% corresponds to the minimum of motor rated current (parameter P6-004) and drive rated output current (defined by the drive model).				
P0-017	Reverse current limit	150.0	0.0 ... 300.0	%	○
	Reverse maximum allowed motor current. Effective when parameter P0-015 = 0. 100.0% corresponds to the minimum of motor rated current (parameter P6-004) and drive rated output current (defined by the drive model).				

Parameter	Name	Default	Range	Unit	Attribute
P0-018	User macro	0	0 ... 3	/	×
	<p>In most cases, the default value is appropriate. Other options are customized parameters for customers.</p> <ul style="list-style-type: none"> ● 0: Standard macro. ● 1 ... 3: Reserved. 				
P0-019	Forward torque limit	180.0	–300.0 ... 300.0	%	○
	<p>Effective when parameter P0-021 = 0.</p> <p>The parameter P0-019 is used as forward torque limit when parameter P0-021 = 0.</p> <p>100.0% corresponds to the motor rated torque.</p>				
P0-020	Reverse torque limit	180.0	–300.0 ... 300.0	%	○
	<p>Effective when parameter P0-022 = 0.</p> <p>The parameter P0-020 is used as reverse torque limit when parameter P0-022 = 0.</p> <p>100.0% corresponds to the motor rated torque.</p>				
P0-021	Forward torque limit selection	0	0 ... 3	/	×
	<p>Selects the source of the forward torque limit for the drive.</p> <ul style="list-style-type: none"> ● 0: Parameter P0-019 The parameter P0-019 is used as forward torque limit. 100.0% corresponds to the motor rated torque. ● 1: AI1 AI1 is used as forward torque limit. Maximum AI1 input corresponds to 2–times the motor rated torque. ● 2: AI2 Same as AI1. ● 3: AI3 Same as AI1. 				
P0-022	Reverse torque limit selection	0	0 ... 3	/	×
	<p>Selects the source of the reverse torque limit for the drive.</p> <ul style="list-style-type: none"> ● 0: Parameter P0-020 The parameter P0-020 is used as reverse torque limit. 100.0% corresponds to the motor rated torque. ● 1: AI1 AI1 is used as reverse torque limit. Maximum AI1 input corresponds to 2–times the motor rated torque. ● 2: AI2 Same as AI1. ● 3: AI3 Same as AI1. 				

Parameter	Name	Default	Range	Unit	Attribute																			
P0-023	Control location mode selection	0	0 ... 1	/	×																			
	<p>Selects the control location mode.</p> <ul style="list-style-type: none">● 0: Control location mode 1 Run command is defined by parameter P0-004 and speed reference is defined by parameter P0-005, in this control location mode, the parameters P0-024 ... P0-027 have no effect.● 1: Control location mode 2 There are three control location in this control location mode: LOCAL control location, EXTERNAL 1 control location and EXTERNAL 2 control location, the control location can be switched by digital inputs. Run command is defined by keypad, parameters P0-024 and P0-026; speed reference is defined by parameters P0-005, P0-025 and P0-027. For example: digital input X3 is used to select EXTERNAL 1 control location and digital input X4 is used to select EXTERNAL 2 control location. Parameters setting: P3-003 = 64, P3-004 = 65. <table><tr><td>X4 state</td><td>X3 state</td><td>Run command selection</td><td>Speed reference selection</td></tr><tr><td>0</td><td>0</td><td>Keypad</td><td>Parameter P0-005</td></tr><tr><td>0</td><td>1</td><td>Source selected by P0-024</td><td>Source selected by P0-025</td></tr><tr><td>1</td><td>0</td><td>Source selected by P0-026</td><td>Source selected by P0-027</td></tr><tr><td>1</td><td>1</td><td>Source selected by P0-026</td><td>Source selected by P0-027</td></tr></table>					X4 state	X3 state	Run command selection	Speed reference selection	0	0	Keypad	Parameter P0-005	0	1	Source selected by P0-024	Source selected by P0-025	1	0	Source selected by P0-026	Source selected by P0-027	1	1	Source selected by P0-026
X4 state	X3 state	Run command selection	Speed reference selection																					
0	0	Keypad	Parameter P0-005																					
0	1	Source selected by P0-024	Source selected by P0-025																					
1	0	Source selected by P0-026	Source selected by P0-027																					
1	1	Source selected by P0-026	Source selected by P0-027																					
P0-024	External 1 selection	2	0 ... 5	/	×																			
	Refer to parameter P0-004.																							
P0-025	External reference 1 selection	2	0 ... 14	/	×																			
	Refer to parameter P0-005.																							
P0-026	External 2 selection	2	0 ... 5	/	×																			
	Refer to parameter P0-004.																							
P0-027	External reference 2 selection	6	0 ... 14	/	×																			
	Refer to parameter P0-005.																							

5.2 Speed Reference (P1)

Parameter	Name	Default	Range	Unit	Attribute
P1-000	Keypad speed reference	10.00	-327.67 ... 327.67	Hz	○
		300	-32767 ... 32767	rpm	
	Defines the speed reference when P0-005 = 1.				
	P0-006	P0-007	Range		
	0	0	-P0-012 maximum speed ... 0.00 Hz ... P0-012 maximum speed		
	0	1	-P0-012 maximum speed ... 0.0 Hz... P0-012 maximum speed		
0	2	-P0-012 maximum speed ... 0 Hz...P0-012 maximum speed			
1	/	-P0-012 maximum speed ... 0 RPM...P0-012 maximum speed			
Note: The range is limited by maximum speed P0-012 and the unit is defined by the parameters P0-006 and P0-007. Refer to parameters P0-006 and P0-007for more information.					
P1-001	Speed reference invert	0	0 ... 1	/	×
	Inverts the speed reference value. <ul style="list-style-type: none">● 0: Maintain the speed reference direction Speed reference direction is not inverted.● 1: Invert the speed reference direction The speed reference direction is inverted.				
P1-002	Run reverse selection	0	0 ... 1	/	×
	Selects whether to allow the motor to rotate in reverse direction. Disable reverse operation in some applications where reverse rotation is dangerous or the equipment will be damaged. When P1-002 = 1 and the speed reference is a reverse value, the actual running speed is zero. <ul style="list-style-type: none">● 0: Run reverse is allowed.● 1: Run reverse is not allow.				
P1-003	Jog speed reference	5.00	0.00 ... 655.35	Hz	×
		150	0 ... 65535	rpm	
	The parameter defines the jogging speed when the jogging function is in use. Jogging function can be activated by digital inputs only when the parameter P0-004 is 2 (Start and Stop by digital input). For example, digital input X3 is used to activate forward jogging and X4 is used to activate reverse jogging, set the parameters: P0-004 = 2, P3-003 = 31, P3-004 = 32. Note: The range is limited by maximum speed P0-012 and the unit is defined by the parameters P0-006 and P0-007. Refer to parameter P0-006 for more information.				
	X4	X3	Jogging direction	Jogging speed	
	0	0	STOP	STOP	
	0	1	FWD	P1-003	
1	0	REV	P1-003		
1	1	REV	P1-003		
P1-004	Jog speed priority	0	0 ... 1	/	×
	<ul style="list-style-type: none">● 0: Jogging function has higher priority.● 1: Jogging function has lower priority.				

Parameter	Name	Default	Range	Unit	Attribute
P1-005	Constant speed reference 1	5.00	-327.67 ... 327.67	Hz	○
		150	-32767 ... 32767	rpm	
P1-006	Constant speed reference 2	8.00	-327.67 ... 327.67	Hz	○
		240	-32767 ... 32767	rpm	
P1-007	Constant speed reference 3	10.00	-327.67 ... 327.67	Hz	○
		300	-32767 ... 32767	rpm	
P1-008	Constant speed reference 4	15.00	-327.67 ... 327.67	Hz	○
		450	-32767 ... 32767	rpm	
P1-009	Constant speed reference 5	18.00	-327.67 ... 327.67	Hz	○
		540	-32767 ... 32767	rpm	
P1-010	Constant speed reference 6	20.00	-327.67 ... 327.67	Hz	○
		600	-32767 ... 32767	rpm	
P1-011	Constant speed reference 7	25.00	-327.67 ... 327.67	Hz	○
		750	-32767 ... 32767	rpm	
P1-012	Constant speed reference 8	28.00	-327.67 ... 327.67	Hz	○
		840	-32767 ... 32767	rpm	
P1-013	Constant speed reference 9	30.00	-327.67 ... 327.67	Hz	○
		900	-32767 ... 32767	rpm	
P1-014	Constant speed reference 10	35.00	-327.67 ... 327.67	Hz	○
		1050	-32767 ... 32767	rpm	
P1-015	Constant speed reference 11	38.00	-327.67 ... 327.67	Hz	○
		1140	-32767 ... 32767	rpm	
P1-016	Constant speed reference 12	40.00	-327.67 ... 327.67	Hz	○
		1200	-32767 ... 32767	rpm	
P1-017	Constant speed reference 13	42.00	-327.67 ... 327.67	Hz	○
		1260	-32767 ... 32767	rpm	
P1-018	Constant speed reference 14	45.00	-327.67 ... 327.67	Hz	○
		1350	-32767 ... 32767	rpm	
P1-019	Constant speed reference 15	48.00	-327.67 ... 327.67	Hz	○
		1440	-32767 ... 32767	rpm	
P1-020	Constant speed reference 16	50.00	-327.67 ... 327.67	Hz	○
		1500	-32767 ... 32767	rpm	

When P0-005 = 8 or 9, it is possible to predefine 15 constant speeds in parameters P1-005 ... P1-020. Constant speeds are selected through digital inputs. For example, digital inputs X3, X4, X5 and X6 are used to activate constant speeds, set P3-003 = 16, P3-004 = 17, P3-005 = 18, P3-006 = 19, the speed reference as follows (0 indicates digital input OFF or not selected, 1 indicates digital input ON):

Parameter	Name				Default	Range	Unit	Attribute
	X6	X5	X4	X3	Speed reference active			
	0	0	0	0	Constant speed reference 1 (P1-005)			
	0	0	0	1	Constant speed reference 2 (P1-006)			
	0	0	1	0	Constant speed reference 3 (P1-007)			
	0	0	1	1	Constant speed reference 4 (P1-008)			
	0	1	0	0	Constant speed reference 5 (P1-009)			
	0	1	0	1	Constant speed reference 6 (P1-010)			
	0	1	1	0	Constant speed reference 7 (P1-011)			
	0	1	1	1	Constant speed reference 8 (P1-012)			
	1	0	0	0	Constant speed reference 9 (P1-013)			
	1	0	0	1	Constant speed reference 10 (P1-014)			
	1	0	1	0	Constant speed reference 11 (P1-015)			
	1	0	1	1	Constant speed reference 12 (P1-016)			
	1	1	0	0	Constant speed reference 13 (P1-017)			
	1	1	0	1	Constant speed reference 14 (P1-018)			
	1	1	1	0	Constant speed reference 15 (P1-019)			
	1	1	1	1	Constant speed reference 16 (P1-020)			


Note: The range of parameters P1-005 ... P1-020 are limited by maximum speed P0-012 and the unit is defined by the parameters P0-006 and P0-007. Refer to the parameter P0-006 for more information.

P1-021	UP/DN function selection	0000	0000 ... FFFF	/	○
<p>Defines the mode of speed (frequency) reference increase and decrease by digital inputs.</p> <p>bit1...bit0: UP/DN mode selection</p> <ul style="list-style-type: none"> ● 00: UP/DN mode 1. <p>The speed reference increase and decrease by the state of digital inputs. For example, digital input X3 is used to increase the speed reference and X4 is used to decrease the speed reference.</p> <p>Set P3-003 = 27, P3-004 = 28, then:</p> <ol style="list-style-type: none"> ① If X3 = ON, the reference increases from initial value until reaches the maximum speed P0-012. ② If X4 = ON, the reference decreases until reaches the lower limit P1-023. ● 01: UP/DN mode 2. <p>The speed reference increase and decrease by the rising edge of digital inputs. For example, digital input X3 is used to increase the speed reference and X4 is used to decrease the speed reference, set P3-003 = 27, P3-004 = 28, then:</p> <ol style="list-style-type: none"> ① If X3: OFF → ON, reference increase from initial value ,the increased value is defined by parameter P1-024 for each rising edge . The reference will increase once at each rising edge until reaches the maximum speed P0-012. ② If X4: OFF → ON, reference decrease, the decreased value is defined by parameter P1-024 for each rising edge. The reference value will decrease once at each rising edge until reaches the lower limit P1-023. 					

Parameter	Name	Default	Range	Unit	Attribute
	<div>● 10: UP/DN mode 3.</div> <div>This mode is only available in running state. The speed increase by a digital input, the speed decrease by stop command. For example, digital input X3 is used to increase the speed and X1 is used to start the motor, set P3-001 = 03, P3-003 = 27, then:</div> <div>① If X1 = ON and X3 = ON, actual speed increase, the actual speed increases from initial value until reaches the maximum speed P0-012.</div> <div>② If X1 = OFF and X3 = OFF, actual speed decrease until stop. If in deceleration process, then X1 = ON, the actual speed will be keep at the current speed.</div> <div>bit2...bit3: Reserved.</div> <div>bit4: UP/DN initial value selection.</div> <div>● 0: P1-022 is used as initial value for the UP/DN mode.</div> <div>● 1: AI1 is used as initial value for the UP/DN mode.</div> <div>bit5...bit7: Reserved.</div> <div>bit8...bit9: UP/DN minimum speed</div> <div>● 00: Zero speed.</div> <div>● 01: UP/DN minimum speed P1-023.</div> <div>● 10: UP/DN adjustment can reverse the direction.</div> <div>bit10...bit11: Reserved.</div> <div>bit12...bit13: UP/DN adjustment in stop state</div> <div>● 00: Clear the adjusted value in stop state, UP/DN adjustment is disabled in stop state.</div> <div>● 01: Keep the adjusted value in stop state, but UP/DN adjustment is disabled in stop state.</div> <div>● 10: Keep the adjusted value in stop state, UP/DN adjustment is enabled in stop state.</div> <div>bit14: Save after power off</div> <div>● 0: Clear the adjusted value after power off.</div> <div>● 1: Save the adjusted value after power off.</div> <div>bit15: Reserved</div>				
P1-022	UP/DN initial value	10.00	0.00 ... 655.35	Hz	○
		300	0 ... 65535	rpm	
	Defines the initial value for the UP/DN mode when bit4 of P1-021 is zero. Note: The range is limited by maximum speed P0-012 and the unit is defined by the parameters P0-006 and P0-007. Refer to parameter P0-006 for more information.				
P1-023	UP/DN minimum speed	5.00	0.00 ... 655.35	Hz	○
		Defines the UP/DN minimum speed. UP/DN function cannot adjust the frequency lower than this value. Note: The range is limited by maximum speed P0-012 and the unit is defined by the parameters P0-006 and P0-007. Refer to parameter P0-006 for more information.			
P1-024	UP/DN adjust step length	1.00	0.00 ... 655.35	Hz	○
		30	0 ... 65535	rpm	
	Defines the step length for each UP/DN adjust value. Note: The range is limited by maximum speed P0-012 and the unit is defined by the parameters P0-006 and P0-007. Refer to parameter P0-006 for more information.				

Parameter	Name	Default	Range	Unit	Attribute
P1-025	UP/DN adjust rate	0.100	0.000 ... 32.000	s	○
	Defines the UP/DN adjust time interval.				
P1-026	Keypad UP/DN step length	1.00	0.00 ... 655.35	Hz	○
		30	0 ... 65535	rpm	○
	Note: The range is limited by maximum speed P0-012 and the unit is defined by the parameters P0-006 and P0-007. Refer to parameter P0-006 for more information.				
P1-027	Keypad UP/DN minimum speed	0	0 ... 2	/	×
	<ul style="list-style-type: none">● 0: Keypad UP/DN can adjust to reverse direction● 1: Zero speed● 2: UP/DN minimum speed P1-023				
P1-028	Speed reference selection 2	1	0 ... 13	/	×
	Speed reference 2 is activated by a digital input. For example, digital input X3 is used to activate speed reference 2, set P3-003 = 49, then: <ul style="list-style-type: none">● If X3 is OFF, source selected by P0-005.● If X3 is ON then source selected by parameter P1-028. For the selection information, refer to parameter P0-005 for more information.● For the selections, same as P0-005, refer to parameter P0-005 for more information.				
P1-029	Jump frequency 1	0.00	0.00 ... 655.35	Hz	×
P1-030	Jump frequency 2	0.00	0.00 ... 655.35	Hz	×
P1-031	Jump frequency 3	0.00	0.00 ... 655.35	Hz	×
P1-032	Jump frequency band	0.00	0.00 ... 655.35	Hz	×

The jump frequency function is available for applications where it is necessary to avoid certain motor speeds or speed bands because of e.g. mechanical resonance problems.



Parameter	Name	Default	Range	Unit	Attribute
P1-033	Simple PLC operation mode	0	0 ... 3	/	×
	<ul style="list-style-type: none"> ● 0: Stop after one process operation. ● 1: Keep the final speed running after one process operation. ● 2: Cycle operation. ● 3: Cycle operation and stop after the number of cycles reach the pre-defined value (defined by parameter P1-069). 				
P1-034	Simple PLC power-off save selection	0000	0000 ... FFFF	/	×
	<p>One position: Power-off save selection</p> <ul style="list-style-type: none"> ● 0: Reset after power off. ● 1: Save after power off. <p>Tens position: Stop status save selection</p> <ul style="list-style-type: none"> ● 0: Reset in stop state. ● 1: Save in stop state. 				
P1-035	The 1st step speed reference selection	0	0 ... 5	/	×
	<ul style="list-style-type: none"> ● 0: Parameter P1-005 ● 1: Modbus ● 2: Parameter P1-000 ● 3: AI1 ● 4: AI2 ● 5: AI3 				
P1-036	The 1st step run time	0.0	0.0 ... 6553.5	s(h)	○
	Defines the first step run time, the first step speed reference is defined by parameter P1-035, and the first step acceleration and deceleration time are defined by parameter P1-037.				
P1-037	The 1st step ACC/DEC time selection	0	0 ... 3	/	×
	<p>Selects the first step active acceleration/deceleration time pair.</p> <ul style="list-style-type: none"> ● 0: Acceleration time 0 and deceleration time 0 are used (P2-001 and P2-002). ● 1: Acceleration time 1 and deceleration time 1 are used (P2-003 and P2-004). ● 2: Acceleration time 2 and deceleration time 2 are used (P2-005 and P2-006). ● 3: Acceleration time 3 and deceleration time 3 are used (P2-007 and P2-008). 				
P1-038	The 2nd step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-039	The 2nd step ACC/DEC time selection	0	0 ... 3	/	×
P1-040	The 3rd step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-041	The 3rd step ACC/DEC time selection	0	0 ... 3	/	×
P1-042	The 4th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-043	The 4th step ACC/DEC time selection	0	0 ... 3	/	×
P1-044	The 5th step run time	0.0	0.0 ... 6553.5	s(h)	○

Parameter	Name	Default	Range	Unit	Attribute
P1-045	The 5th step ACC/DEC time selection	0	0 ... 3	/	×
P1-046	The 6th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-047	The 6th step ACC/DEC time selection	0	0 ... 3	/	×
P1-048	The 7th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-049	The 7th step ACC/DEC time selection	0	0 ... 3	/	×
P1-050	The 8th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-051	The 8th step ACC/DEC time selection	0	0 ... 3	/	×
P1-052	The 9th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-053	The 9th step ACC/DEC selection	0	0 ... 3	/	×
P1-054	The 10th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-055	The 10th step ACC/DEC time selection	0	0 ... 3	/	×
P1-056	The 11th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-057	The 11th step ACC/DEC time selection	0	0 ... 3	/	×
P1-058	The 12th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-059	The 12th step ACC/DEC time selection	0	0 ... 3	/	×
P1-060	The 13th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-061	The 13th step ACC/DEC time selection	0	0 ... 3	/	×
P1-062	The 14th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-063	The 14th step ACC/DEC time selection	0	0 ... 3	/	×
P1-064	The 15th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-065	The 15th step ACC/DEC time selection	0	0 ... 3	/	×
P1-066	The 16th step run time	0.0	0.0 ... 6553.5	s(h)	○
P1-067	The 16th step ACC/DEC time selection	0	0 ... 3	/	×
See parameters P1-036 and P1-037.					
P1-068	Simple PLC run time unit	0	0 ... 1	/	×
	Defines the simple PLC run time unit. ● 0: Simple PLC run time in second. ● 1: Simple PLC run time in hour.				
P1-069	Simple PLC cycle times	1	1 ... 65535	/	×
	Defines the number of cycle operation when parameter P1-033 = 3. The drive will stop automatically after the cycles are finished.				

5.3 ACC/DEC Time (P2)

Parameter	Name	Default	Range	Unit	Attribute
P2-000	ACC and DEC mode selection	0	0 ... 2	/	×

Three user-selectable acceleration and deceleration modes are available.

If the speed reference increases / decreases faster than the set acceleration/deceleration rate, the motor speed will follow the acceleration / deceleration rate.

If the speed reference increases / decreases slower than the set acceleration / deceleration rate, the motor speed will follow the reference signal.

If the acceleration / deceleration time is set too short, the drive will automatically prolong the acceleration / deceleration time in order not to exceed the maximum current, maximum torque, maximum voltage, etc.

- 0: Linear ramp.**

Selects acceleration and deceleration time pairs in the drive through digital inputs.

For example, digital inputs X3 and X4 are used to select the acceleration and deceleration time pairs, set P3-003 = 22, P3-004 = 23.

X4 state	X3 state	Acceleration time	Deceleration time
0	0	P2-001	P2-002
0	1	P2-003	P2-004
1	0	P2-005	P2-006
1	1	P2-007	P2-008
- 1: Two linear ramp.**

Actual speed < value of P2-017, the acceleration time is P2-001, the deceleration time is P2-002.

Actual speed ≥ value of P2-017, the acceleration time is P2-003, the deceleration time is P2-004.
- 2: S curve ramp.**

When the setting acceleration / deceleration time higher than the S-curve time:

Total acceleration time = setting acceleration time + (P2-009 + P2-010)/2.

Total deceleration time = setting deceleration time + (P2-011 + P2-012)/2.

P2-001	Acceleration time 0	Model dependent	0.00 ... 655.35	s	○
P2-002	Deceleration time 0	Model dependent	0.00 ... 655.35	s	○
P2-003	Acceleration time 1	Model dependent	0.00 ... 655.35	s	○
P2-004	Deceleration time 1	Model dependent	0.00 ... 655.35	s	○
P2-005	Acceleration time 2	Model dependent	0.00 ... 655.35	s	○
P2-006	Deceleration time 2	Model dependent	0.00 ... 655.35	s	○
P2-007	Acceleration time 3	Model dependent	0.00 ... 655.35	s	○
P2-008	Deceleration time 3	Model dependent	0.00 ... 655.35	s	○
P2-009	S-curve time at acceleration start	Model dependent	0.00 ... 655.35	s	○
P2-010	S-curve time at acceleration end	Model dependent	0.00 ... 655.35	s	○
P2-011	S-curve time at deceleration start	Model dependent	0.00 ... 655.35	s	○
P2-012	S-curve time at deceleration end	Model dependent	0.00 ... 655.35	s	○
P2-013	Acceleration and deceleration time multiple	0	0 ... 2	/	×
	The parameter P2-013 defines the actual acceleration and deceleration time units. ● 0: *1 ● 1: *10 ● 2: *0.1				
The actual acceleration time = P2-001 * P2-013. The acceleration time i.e. the time required for the speed to change from zero to the maximum speed P0-012.					
The actual deceleration time = P2-002 * value of P2-013. The deceleration time i.e. the time required for the speed to change from the maximum speed (parameter P0-012) to zero.					
Note: If a short deceleration time is needed, the drive should be equipped with an electric braking option e.g. with a brake chopper and a brake resistor.					
Note: The default acceleration and deceleration time (P2-001 ... P2-008) depend on the power as follows:					
5.5 kW ... 15kW: 5.0s. 18.5 kW ... 30kW: 10.0s. 37kW: 15.0s.					
45kW: 25.0s. 55kW: 30.0s. 75 kW ... 93kW: 40.0s.					
110kW: 45.0s. 132 kW ... 250kW: 50.0s. 280 kW ... 400kW: 60.0s.					
450 kW ... 560kW: 70.0s. 630kW: 80.0s.					
P2-014	Emergency stop deceleration time	Model dependent	0.00 ... 655.35	s	○
	Defines the deceleration time when the drive receives an emergency stop command from a digital input.				
P2-015	Jog operation acceleration time	Model dependent	0.00 ... 655.35	s	○
	Defines the acceleration time when the jogging function is activated.				
P2-016	Jog operation deceleration time	Model dependent	0.00 ... 655.35	s	○
	Defines the deceleration time when the jogging function is activated.				
P2-017	ACC/DEC time switching speed	0.00	0 ... 655.35	Hz	×
		0	0 ... 65535	rpm	
	Actual speed < value of P2-017, the acceleration time is P2-001, the deceleration time is P2-002. Actual speed ≥value of P2-017, the acceleration time is P2-003, the deceleration time is P2-004. See the selection “1” in parameter P2-000 for more information.				

5.4 Digital Inputs and Outputs (P3)

Parameter	Name	Default	Range	Unit	Attribute
P3-000	Digital inputs filter time	10	0 ... 1000	ms	○
Defines a filtering time for digital inputs.					
P3-001	X1 input function	3	0 ... 63	/	×
P3-002	X2 input function	4	0 ... 63	/	×
P3-003	X3 input function	0	0 ... 63	/	×
P3-004	X4 input function	0	0 ... 63	/	×
P3-005	X5 input function	0	0 ... 63	/	×
P3-006	X6 input function	0	0 ... 63	/	×
P3-007	X7 input function	0	0 ... 63	/	×

The parameters P3-001 ... P3-007 are used to set the digital input functions.

- **0: No function**

The digital input ON or OFF only displays the terminal status but does not trigger any functions.

- **1: RUN**

Run command input when P0-004 = 2. For example, if digital input X1 is used to start and stop the drive, set P0-004 = 2, P3-001=1. Then start and stop through digital input X1, 0 = stop, 1 = start.

- **2: RUN direction invert**

The signal is used to invert the run command direction. The signal can invert all the run command direction; include keypad, digital input and communication. 0 = the motor operates in the rotate direction that keep consistent with the speed reference and run command, 1 = the motor operates in the rotate direction that opposite to the speed reference and run command.

Note: In general, this signal is used in conjunction with selection "1". For example, use X1 to start and X2 to invert the run direction, set P0-004 = 2, P3-001 = 1, P3-002 = 2, and speed reference is a positive value, then:

X2: invert direction	X1: start	Running direction
0	0	Stop
0	1	Forward
1	0	Stop
1	1	Reverse

- **3: Forward**

- **4: Reverse**

Forward and reverse run command when P0-004 = 2. For example, use X1 to start in forward direction and X2 to start in reverse direction, set P0-004 = 2, P3-001 = 3, P3-002 = 4, and speed reference is a positive value, then:

X2: reverse command	X1: forward command	Running direction
0	0	Stop
0	1	Forward
1	0	Reverse
1	1	Stop

Note: Other start mode refer to parameter P3-016 for more information.

Parameter	Name	Default	Range	Unit	Attribute
<ul style="list-style-type: none"> ● 5: External fault input External fault is given through digital input. 0 = No external fault. 1 = Fault trip and motor coasts to stop. ● 6: Fault reset The signal resets the drive after a fault trip if the cause of the fault no longer exists. ● 7: Spindle positioning When P0-004 = 2, the signal is used to start positioning according to the positioning method, refer to parameters in group B0 for more details. ● 8: Switch to position control When the signal is ON, the system control mode (P0-003) is changed to position loop. ● 9: Enabling zero servo function When the signal is ON, the drive enters to zero servo operation. ● 10: Clear input pulse When the signal is ON, the input pulses is cleared. ● 11: Change run command to Modbus communication The run command is changed to Modbus communication when the signal rising edge: 0→1. ● 12: Change run command to keypad The run command is changed to keypad when the signal rising edge: 0→1. ● 13: Change run command to digital input The run command is changed to digital input when the signal rising edge: 0→1. ● 14: Reserved ● 15: Emergency stop The drive immediately stops according to the stop mode after receive an emergency stop signal from digital input. ● 16: Constant speed reference input 1 ● 17: Constant speed reference input 2 ● 18: Constant speed reference input 3 ● 19: Constant speed reference input 4 When P0-005 = 9, it is possible to predefine 15 constant speeds in parameters P1-005 ... P1-020. The digital input can be used to select the predefined speeds, refer to parameters P1-005 ... P1-020 for more information. ● 20: Clear the accumulated time of Simple PLC The counter of Simple PLC is reset to zero when the signal is ON. ● 21: Reset Simple PLC step The counter PLC_T2 is reset to zero and stop counting; the simple PLC is reset to the first step. Note: If all the step run time is zero, the drive will run at the speed reference 1 after reset. ● 22: Multi-step ACC/DEC time input 1 ● 23: Multi-step ACC/DEC time input 2 Select the acceleration and deceleration time pairs through digital inputs. Refer to parameter P2-000 for more information. ● 24: Process PID integration pause The process PID integration is stop when the signal is ON. 					

Parameter	Name	Default	Range	Unit	Attribute
● 25: Process PID parameters switching	Select the second group PID parameters. 0 = Select the first group PID parameters. 1 = Select the second group PID parameters. Refer to parameter PC-030 for more information.				
● 26: Process PID output is forced to constant speed reference.	The PID controller speed output is forced to the value of parameter PC-040.				
● 27: UP, speed reference increase input	When P0-005 = 10, 1 = Speed reference increase. Refer to parameter P1-021 for more information.				
● 28: DN, speed reference decrease input	When P0-005 = 10, 1 = Speed reference decrease. Refer to parameter P1-021 for more information.				
● 29: Clear the terminal UP/DN value	When P0-005 = 10, 1 = reset the value adjusted by UP/DN to zero and the speed reference is changed to UP/DN initial value (defined by parameter P1-022).				
● 30: UP/DN adjust to reverse direction	When P0-005 = 10, 1 = the minimum speed for UP/DN is zero, and cannot invert the running direction.				
● 31: Forward jogging	Forward jogging is active when the signal is ON. 0 = inactive. 1 = active. Note: Jogging function is only effective when P0-004 = 2.				
● 32: Reverse jogging	Reverse jogging is active when the signal is ON. 0 = inactive. 1 = active. Note: Jogging function is only effective when P0-004 = 2.				
● 33: Three-wire control mode	Refer to parameter P3-016 for more information.				
● 34: Orientation position capture mode	The orientation position can be determined by two methods: manual setting and terminal acquisition. Manual setting: In stop state, manually rotate the motor shaft to the desired orientation position, read the encoder position value, and set it to the corresponding orientation position parameters. When orientation is active, the motor shaft will be positioned to the set position. Terminal acquisition: In stop state, set a digital input function to "34". When the terminal is ON, the drive will read the current position and set into corresponding position parameter automatically.				
● 35: Orientation position reference 1					
● 36: Orientation position reference 2					
● 37: Orientation position reference 3	It is possible to predefine 8 orientation positions in parameters B0-016, B0-022 ... B0-028 and the orientation positions can be selected by digital inputs. Refer to parameter B0-016 for more information.				
● 38: Run is prohibited	1 = drive start command is inhibited; switching the signal ON while the drive is running will coast to stop immediately. The drive is allowed to start only when this signal is OFF.				
● 39: Reserved					

Parameter	Name	Default	Range	Unit	Attribute
● 40: Activate torque control	Activate torque control through a digital input. 1 = torque control. 0 = speed control.				
● 41: Orientation after receive a stop command	When the signal is ON, the drive will start orientation after receive a stop command, after the orientation is completed, block the output.				
● 42 ... 46: Reserved					
● 47: PID speed reference is changed to open loop main reference.					
● 48: Force to master mode	When the drive in follower mode (C0-039 = 2, 3, 4, 5, 6), follower mode can be temporarily disabled through a digital input when the digital input function is set to "48". For example, P3-003 = 48, then X3 = 0 follower mode, X3 = 1 master mode. Refer to parameter C0-039 for more information.				
● 49: Change speed reference source to parameter P1-028	Select the second speed reference source. 0 = selected by P0-005. 1 = selected by P1-028.				
● 50: Acceleration and deceleration is prohibited	1 = the current output speed is locked (keep at current running speed); acceleration and deceleration is disabled, even if the reference speed and running speed are inconsistent, except a stop command comes.				
● 51: Change speed reference to maximum speed	Speed reference is changed to maximum speed when the signal is ON.				
● 52: Change speed reference to jogging speed	Speed reference is changed to jog speed when the signal is ON.				
● 53: Change speed reference to constant speed reference 1	Speed reference is changed to constant speed reference 1 (P1-005) when the signal is ON.				
● 54: Change speed reference to AI1	Speed reference is changed to AI1 when the signal is ON.				
● 55: Change speed reference to AI2	Speed reference is changed to AI2 when the signal is ON.				
● 56: Change speed reference to AI3	Speed reference is changed to AI3 when the signal is ON.				
● 57: Run is prohibited 1	1 = drive start command is inhibited, switching the signal ON while the drive is running will stop according the stop mode (defined by parameter P5-008). The drive is allowed to start only when this signal is OFF.				
● 58: Run forward is prohibited 1	1 = drive forward start command is inhibited, switching the signal ON while the drive is forward running will stop according the stop mode (defined by parameter P5-008). The drive is allowed to forward start only when this signal is OFF. Nevertheless, does not affect reverse start command.				
● 59: Run reverse is prohibited 1	1 = drive reverse start command is inhibited, switching the signal ON while the drive is reverse running will stop according the stop mode (defined by parameter P5-008). The drive is allowed to reverse start only when this signal is OFF. Nevertheless, does not affect forward start command.				

Parameter	Name	Default	Range	Unit	Attribute																																										
<ul style="list-style-type: none">● 60: Run is prohibited 2 1 = drive start command is inhibited, switching the signal ON while the drive is running will coast to stop immediately. The drive is allowed to start only when this signal is OFF.● 61: Run forward is prohibited 2 1 = drive forward start command is inhibited, switching the signal ON while the drive is forward running will coast to stop immediately. The drive is allowed to forward start only when this signal is OFF. Nevertheless, does not affect reverse start command.● 62: Run reverse is prohibited 2 1 = drive reverse start command is inhibited, switching the signal ON while the drive is reverse running will coast to stop immediately. The drive is allowed to reverse start only when this signal is OFF. Nevertheless, does not affect forward start command.● 63: Reserved● 64: External 1 selection. 1 = Activate EXTERNAL 1. Please refer to parameters P0-023 ... P0-027 for more information.● 65: External 2 selection. 1 = Activate EXTERNAL 2.● 66...79: Reserved.																																															
P3-008	Digital input invert	0000	0000 ... 03FF	/	×																																										
	The parameter is used to activate the inversion of digital inputs. The corresponding relationship of binary and digital inputs are shown in the following table. The value display on keyboard in hexadecimal.																																														
	<table><tr><td>Item</td><td>Reserved</td><td>AI3</td><td>AI2</td><td>AI1</td><td>X7</td><td>X6</td><td>X5</td><td>X4</td><td>X3</td><td>X2</td><td>X1</td></tr><tr><td>Default</td><td>0000 00</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>bit</td><td>bit15 to bit10</td><td>bit9</td><td>bit8</td><td>bit7</td><td>bit6</td><td>bit5</td><td>bit4</td><td>bit3</td><td>bit2</td><td>bit1</td><td>bit0</td></tr></table>											Item	Reserved	AI3	AI2	AI1	X7	X6	X5	X4	X3	X2	X1	Default	0000 00	0	0	0	0	0	0	0	0	0	0	bit	bit15 to bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
	Item	Reserved	AI3	AI2	AI1	X7	X6	X5	X4	X3	X2	X1																																			
Default	0000 00	0	0	0	0	0	0	0	0	0	0																																				
bit	bit15 to bit10	bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0																																				
<ul style="list-style-type: none">● 0: No inversion● 1: Inversion active																																															
P3-009	XI / VXI effectiveness selection	0	0 ... 2	/	×																																										
	We can define 5 virtual digital inputs through communication; virtual digital inputs can achieve the same functions as the actual digital inputs. We can also define the effective range.																																														
	<ul style="list-style-type: none">● 0: Only the actual digital inputs are effective (X1...X7).● 1: Both actual digital inputs and virtual digital inputs are effective (X1...X7, VX1...VX5).● 2: Only virtual digital inputs VXI are effective (VX1...VX5).																																														
P3-010	VXI virtual terminal reference	0000	0000 ... 001F	/	×																																										
	Defines whether the virtual digital inputs is ON or OFF.																																														
	<table><tr><td>Item</td><td>Reserved</td><td>X5</td><td>X4</td><td>X3</td><td>X2</td><td>X1</td></tr><tr><td>Default</td><td>0000 0000 000</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>Bit</td><td>bit15 to bit5</td><td>bit4</td><td>bit3</td><td>bit2</td><td>bit1</td><td>bit0</td></tr></table>						Item	Reserved	X5	X4	X3	X2	X1	Default	0000 0000 000	0	0	0	0	0	Bit	bit15 to bit5	bit4	bit3	bit2	bit1	bit0																				
	Item	Reserved	X5	X4	X3	X2	X1																																								
Default	0000 0000 000	0	0	0	0	0																																									
Bit	bit15 to bit5	bit4	bit3	bit2	bit1	bit0																																									
<ul style="list-style-type: none">● 0: Virtual digital input OFF.● 1: Virtual digital input ON.																																															


Parameter	Name	Default	Range	Unit	Attribute
P3-011	Virtual terminal VX1 function selection	0	0 ... 63	/	×
P3-012	Virtual terminal VX2 function selection	0	0 ... 63	/	×
P3-013	Virtual terminal VX3 function selection	0	0 ... 63	/	×
P3-014	Virtual terminal VX4 function selection	0	0 ... 63	/	×
P3-015	Virtual terminal VX5 function selection	0	0 ... 63	/	×

The function selections of VX1 ... VX5, same as X1 ... X7, see P3-001 ... P3-007 for the selections.

P3-016	Two-wire / three-wire control mode selection	0	0 ... 3	/	×
--------	--	---	---------	---	---


Selects the drive start and stop mode through digital inputs when P0-004 = 2.

- **0: Two wire control 1.** E.g. : Start, stop and direction commands through digital inputs X1 and X2.




Parameters setting:
P0-004 = 2
P3-001 = 03
P3-002 = 04

- **1: Two wire control 2.** E.g. : Start, stop and direction commands through digital inputs X1 and X2.




Parameters setting:
P0-004 = 2
P3-001 = 03
P3-002 = 04

- **2: Three wire control 1.** E.g.: Pulse start forward through X1, 0->1: start forward. Pulse start reverse through X2, 0->1: start reverse. Pulse stop through digital input X3: 1->0: stop.




Parameter settings:
P0-004 = 2
P3-001 = 03
P3-002 = 04
P3-003 = 33

- **3: Three wire control 2.** E.g.: Pulse start forward through X1, 0->1: start forward. Pulse start reverse through X2, 0->1: start reverse. Pulse stop through digital input X3: 1->0: stop.



Parameter settings:
P0-004 = 2
P3-001 = 03
P3-002 = 04
P3-003 = 33

- **4: Two wire control 3.** E.g.: Pulse start through X1, 0->1: start. Stop through X2, 1 = stop. **Note:** if X2 0 = stop is required, set the digital input invert in P3-008.



Parameter settings:
P0-004 = 2
P3-001 = 03
P3-002 = 04

Parameter	Name	Default	Range	Unit	Attribute
P3-017	Reserved	0	0 ... 65535	/	×
P3-018	Reserved	0	0 ... 65535	/	×
P3-019	Digital output terminal filter time	0	0 ... 500	ms	×
	Defines a filtering time for digital outputs.				
P3-020	Y1 terminal output function selection	3	0 ... 99	/	○
P3-021	Y2 terminal output function selection	9	0 ... 99	/	○
P3-022	Relay 1 output function selection	15	0 ... 99	/	○
P3-023	Relay 2 output function selection	0	0 ... 99	/	○
P3-024	Relay 3 output function selection	0	0 ... 99	/	○

Parameters P3-020 ... P3-024 are the digital and relay output function selection.

- **0: No function**

- **1: Ready**

When the power-on-self-test of is normal after power on and the drive has no fault.

- **2: Pre-charge OK**

The drive is normally powered, the main circuit pre-charge relay or contactor signal is enabled.

- **3: RUN**

The signal is enabled when the drive is running.

- **4: Speed reach maximum speed**

The signal is enabled if the actual speed reaches or higher than the maximum speed.

- **5: Speed reach minimum speed**

The signal is enabled if the actual speed reaches or lower than the minimum speed.

- **6: Acceleration**

The signal is enabled when the drive in accelerating process.

- **7: Deceleration**

The signal is enabled when the drive in decelerating process.

- **8: Zero speed**

The signal is enabled when the actual speed reaches the zero speed.

- **9: Speed reach reference speed**

The signal is enabled when the actual speed reaches the reference speed.

- **10: Position reach reference position**

When the position deviation between the actual position and the set position is less than the value of parameter B0-011 and the duration reach the time defined by parameter B0-029, the signal is enabled.

- **11: Orientation complete**

The signal output is enabled after the orientation is completed in position loop mode.


- **12: Brake chopper is working**

The signal output is enabled when the built-in brake chopper is in the working state.

- **13: Authorized**

When the drive is in the authorized state, it outputs a signal.

Parameter	Name	Default	Range	Unit	Attribute
<ul style="list-style-type: none"> ● 14: Application fault output Output a signal when there is an application fault. Application faults refer to fault code in F3-050. ● 15: Fault output Output a signal when the drive is in stop status due to fault output ● 16: Communication control Output a signal under communication control. ● 17: Simple PLC every step operation has been completed When the simple PLC completes each step, it outputs a signal with a signal width of 500ms. ● 18: Simple PLC all steps operation has been completed When the simple PLC runs for one cycle, it outputs a signal with a signal width of 500ms. ● 19: Reserved ● 20: RUN output but not jogging The signal is in running state but not in jogging state. ● 21: Stop status output continuously for a period of time Output a signal after the drive switch off the output, and the signal holding time is defined by parameter P3-033. ● 22...50: Reserved ● 51: Frequency reach output (FAR) Output a signal when the deviation between the output frequency and reference frequency is within the detection width setting range; Please refer to parameter P3-027 for more information. ● 52: Frequency level detection 1 output (FDT1) When the actual frequency is higher than FDT1 upper limit (P3-029), the signal is enabled. When the actual frequency is less than FDT1 lower limit (P3-030), the signal is disabled. Refer to parameters P3-029 ... P3-030 for details. ● 53: Frequency level detection 2 output (FDT2) When the actual frequency is higher than FDT2 upper limit (P3-031), the signal is enabled. When the actual frequency is less than FDT2 lower limit (P3-032), the signal is disabled. Refer to parameters P3-031 ... P3-032 for details. ● 54: Non-fault output Output a signal when the drive has no fault. ● 55: Torque reach output When the output torque exceeds the value of parameter P3-034 and lasts longer than P3-035 setting, the signal is enabled. When the output torque is lower than P3-034 setting, the signal is disabled. Refer to parameters P3-034 ... P3-036 for details. ● 56: Current reach output When the output current exceeds the value of parameter P3-037 and lasts longer than P3-038 setting, the signal is enabled. When the output current is lower than P3-037 setting, the signal is disabled. Refer to parameters P3-037 ... P3-039 for details. ● 57: Motor pre-overload output ● 58: Reserved 					



Parameter	Name	Default	Range	Unit	Attribute		
<ul style="list-style-type: none">● 59: Position out of tolerance In position loop mode, the signal is enabled when a position out of tolerance action occurs. Please refer to parameter B0-059 for details.● 60...99: Reserved							
P3-025	Digital output invert		0000	0000 ... 001F	/	×	
	Item	Reserved	RA3	RA2	RA1	Y2	Y1
	Default	0000 0000 000	0	0	0	0	0
	Bit	bit15 ... bit5	bit4	bit3	bit2	bit1	bit0
	<ul style="list-style-type: none">● 0: No inversion● 1: Inversion active						
P3-026	Virtual terminal output reference		0000	0000 ... 001F	/	×	
	Item	Reserved	RA3	RA2	RA1	Y2	Y1
	Default	0000 0000 000	0	0	0	0	0
	Bit	bit15 ... bit5	bit4	bit3	bit2	bit1	bit0
	<ul style="list-style-type: none">● 0: Virtual terminal output is OFF● 1: Virtual terminal output is ON						
P3-027	Frequency reach detect width		2.00	0.00 ... 655.35	Hz	○	
	<p>This parameter is used to detect the deviation between output frequency and reference frequency. If a output terminal function is set to “51: Frequency reach output”, the deviation between the output frequency and the reference frequency if is in the range of P3-027 setting, the output is enabled, as shown in the below figure.</p> <div></div>						
P3-028	Speed reach detection width		5	1 ... 65535	rpm	○	
	<p>This parameter is used to detect the deviation between output speed and reference speed. If a digital / relay output function is set to “4: Speed reach maximum speed” or “5: Speed reach minimum speed”, if the deviation between the output speed and the maximum / minimum speed is in the range of P3-028 setting, the output is enabled, as shown in the following figure.</p>						



Parameter	Name	Default	Range	Unit	Attribute
	<p>输出转速Output speed</p> <p>最大转速Maximum speed</p> <p>最小转速Minimum speed</p> <p>检测宽度Detection width</p> <p>输出信号Output signal</p> <p>时间time</p> <p>数字输出功能为【5】 Digital output function set to: 5</p> <p>数字输出功能为【4】 Digital output function set to: 4</p> <p>数字输出功能为【5】 Digital output function set to: 5</p>				
P3-029	FDT1 upper limit	3.00	0.00 ... 655.35	Hz	○
P3-030	FDT1 lower limit	2.50	0.00 ... 655.35	Hz	○
P3-031	FDT2 upper limit	3.50	0.00 ... 655.35	Hz	○
P3-032	FDT2 lower limit	3.00	0.00 ... 655.35	Hz	○
<p>FDT function is used for detecting whether the output frequency is within the setting range. If a digital / relay output function is set to "52" (Frequency level detection 1 output) or "53" (Frequency level detection 2 output), the digital / relay output will be enabled if the output frequency is in the FDT range.</p> <p>输出频率Output frequency</p> <p>FDT upper limit</p> <p>FDT lower limit</p> <p>Time</p> <p>Digital output</p>					
P3-033	Stop status output continuous time	2.00	0.00 ... 655.35	s	○
<p>Output a signal after the drive switch off the output, and the signal last for the time defined by parameter P3-033. Refer to the selection "21" in parameters P3-020 ... P3-024 for more information.</p>					
P3-034	Torque reach detection value	0.0	0.0 ... 6553.5	%	○
P3-035	Torque reach detection delay time	0.010	0.000 ... 65.535	s	○
P3-036	Torque reach detection range	0.0	0.0 ... 6553.5	%	○
<p>The difference between actual torque and torque reach detection value (P3-034) is lower than the value of P3-036, and remains for the duration of torque reach detection delay time (P3-035) the output is enabled. Refer to the selection "55" in parameters P3-020 ... P3-024 for more information.</p>					
P3-037	Current reach detection value	0.0	0.0 ... 6553.5	A	○
P3-038	Current reach detection delay time	0.010	0.000 ... 65.535	s	○
P3-039	Current reach detection range	0.0	0.0 ... 6553.5	%	○
<p>The difference between actual current and current reach detection value (P3-037) is lower than the value of P3-039, and remains for the duration of current reach detection delay time (P3-038) the output is enabled. Refer to the</p>					

Parameter	Name	Default	Range	Unit	Attribute
selection "56" in parameters P3-020 ... P3-024 for more information.					
P3-040	Fault output signal type	0000	0000 ... 0111	/	×
	Reserved.				

5.5 Analog Input and Output (P4)

Parameter	Name	Default	Range	Unit	Attribute
P4-000	AI1 filter time coefficient	20.0	0.0 ... 1000.0	ms	○
	Defines the analog input AI1 filtering time. The higher setting value, the smoother the analog input command, and the slower the command response, which can prevent analog input signal fluctuations caused by interference.				
P4-001	AI1 zero offset	0.00	-200.00 ... 200.00	%	○
	<p>Defines the minimum value for analog input AI1. 100.0% corresponds to 10.00V (20mA).</p> <p>When there is a zero bias in the analog input from the AI1 port, resulting in the input value (such as speed reference, torque reference, PID reference or PID feedback) not being 0, this parameter can be used to modify the corresponding reference value to 0.</p> <p>When used as a reference, the value corresponds to the reference minimum setting.</p> <p>Note: The parameter F0-023 is the AI1 scaled value, F0-024 is the AI2 scaled value and F0-025 is the AI3 scaled value.</p>				
P4-002	AI1 gain	100.00	0.00 ... 200.00	%	○
	<p>The correspondence between the AI1 analog input value and the specified reference can be adjusted through the AI1 gain. 100.0% corresponds to 10.00V (20mA).</p> <p>For example, default 10V = 1500 rpm, if 8V = 1500 rpm, set P4-002 = $10/8 * 100.00 = 125.00\%$</p>				
P4-003	AI2 filter time coefficient	20.0	0.0 ... 1000.0	ms	○
	See parameter P4-000.				
P4-004	AI2 zero offset	0.00	-200.00 ... 200.00	%	○
	See parameter P4-001.				
P4-005	AI2 gain	100.00	0.00 ... 200.00	%	○
	See parameter P4-002.				
P4-006	AI3 filter time coefficient	20.0	0.0 ... 1000.0	ms	○
	See parameter P4-000.				
P4-007	AI3 zero offset	0.00	-200.00 ... 200.00	%	○
	See parameter P4-001.				
P4-008	AI3 gain	100.00	0.00 ... 200.00	%	○
	See parameter P4-002.				

Parameter	Name	Default	Range	Unit	Attribute
P4-009	Analog input curve selection	4000	0000 ... 5999	/	×
<p>One position: AI1 curve selection</p> <ul style="list-style-type: none"> ● 0: Point-slope mode (P4-001 to P4-002) <p>In this mode, parameters P4-001 ... P4-002 for AI1 are effective.</p> <p>Example 1</p> <p>Analog input 0 ... 10V corresponds to 0 ... P0-012, or analog input -10V ... 10V corresponds to -P0-012 ... P0-012,</p> <p>Setting: P4-009=0000 P4-001=0.00 P4-002=100.00 P4-010=0.00 P4-011=0.00 P4-012=10.00 P4-013=100.00</p> <p>Note: first input the minimum analog input to set the analog zero offset, and then give the maximum analog input to set the analog gain</p>  <p>Example 2:</p> <p>Assume that the analog input 0 ... 10V corresponds to 20% of the maximum speed ... the maximum speed P0-012</p> <p>P4-009=000 P4-001=0.00 P4-002=100.00 P4-010=0.00 P4-011=20.00 P4-012=10.00 P4-013=100.00</p> <p>Note: first input the minimum analog input to set the analog zero offset, and then give the maximum analog input to set the analog gain</p> 					

Parameter	Name	Default	Range	Unit	Attribute
<p>Example 3:</p> <p>Assume that the analog input 2 ... 10V corresponds to 0 ... maximum speed P0-012</p> <p>P4-009=000 P4-001=0.00 P4-002=100.00 P4-010=2.00 P4-011=0.00 P4-012=10.00 P4-013=100.00</p> <p>Note: first input the minimum analog input to set the analog zero offset, and then give the maximum analog input to set the analog gain</p>  <p>Example 4:</p> <p>Assume that the analog input 2 ... 8V corresponds to 0 ... maximum speed P0-012</p> <p>P4-009=000 P4-001=0.00 P4-002=100.00 P4-010=2.00 P4-011=0.00 P4-012=8.00 P4-013=100.00</p> <p>Note: first input the minimum analog input to set the analog zero offset, and then give the maximum analog input to set the analog gain</p> 					


Parameter	Name	Default	Range	Unit	Attribute
<p>Example 5:</p> <p>Assume that the analog input 0 ... 10V corresponds to maximum speed P0-012 ... 0</p> <p>P4-009=000 P4-001=0.00 P4-002=100.00 P4-010=10.00 P4-011=0.00 P4-012=0.00 P4-013=100.00</p> <p>Note: first input the minimum analog input to set the analog zero offset, and then give the maximum analog input to set the analog gain</p> <div data-bbox="646 347 1449 898"> </div> <p>● 1: Multi-point mode (P4-010 to P4-017)</p> <p>In this mode, parameters P4-010 ... P4-017 are effective.</p> <p>Assume that 0v corresponds to zero speed, inflection point 1 corresponds to 40% of the maximum speed at 2v, inflection point 2 corresponds to 60% of the maximum speed at 8v, and 10v corresponds to the maximum speed P0-012.</p> <p>P4-009=001 P4-001=0.00 P4-002=100.00 P4-010=0.00 P4-011=0.00 P4-012=10.00 P4-013=100.00 P4-014=2.00 P4-015=40.00 P4-016=8.00 P4-017=60.00</p> <div data-bbox="550 1059 1433 1955"> </div> <p>Note: first input the minimum analog input to set the analog zero offset, and then give the maximum analog input to set the analog gain</p>					


Parameter	Name	Default	Range	Unit	Attribute
	Tens position: AI2 curve selection <ul style="list-style-type: none"> 0: Point-slope mode (P4-004 to P4-005), same as AI1. 1: Multi-point mode (P4-018 to P4-025), same as AI1. Hundreds position: AI3 curve selection <ul style="list-style-type: none"> 0: Point-slope mode (P4-007 to P4-008), same as AI1. 1: Multi-point mode (P4-026 to P4-033), same as AI1. Thousands position: negative analog input <ul style="list-style-type: none"> 0: AI1 ... AI3 all support positive and negative voltage. 1: AI1 input only support positive voltage, AI2 and AI3 input support positive and negative voltage. If AI1 receive a negative value, it will be considered as zero. 2: AI2 input only support positive voltage, AI1 and AI3 input support positive and negative voltage. If AI2 receive a negative value, it will be considered as zero. 3: AI3 input only support positive voltage, AI1 and AI2 input support positive and negative voltage. If AI3 receive a negative value, it will be considered as zero. 4: AI1 and AI2 input only support positive voltage, AI3 input support positive and negative voltage. If AI1 and AI2 receive a negative value, it will be considered as zero. 5: AI1, AI2 and AI3 all only support positive voltage. If AI1, AI2 and AI3 receive a negative value, it will be considered as zero. 				
P4-010	AI1 minimum input value	0.00	-10.00 ... 10.00	V	×
P4-011	Percentage corresponding to AI1 minimum input	0.00	-100.00 ... 100.00	%	×
P4-012	AI1 maximum input value	10.00	-10.00 ... 10.00	V	×
P4-013	Percentage corresponding to AI1 maximum input	100.00	-100.00 ... 100.00	%	×

Parameters P4-010 ... P4-013 are effective when ones position of parameter P4-009= "1". Whether the analog input is current (0...20mA) or voltage (0...10V) (select by jumper), expressed in voltage, 0...10V.

For example, 0...10V corresponds to 0...1500 rpm by default, require 2...10V corresponds 0...1500 rpm, set P4-010 = 2.00:

- ① Set the A1 jumper to the V side(default).
- ② P0-005 = 2(AI1 used as speed reference).
- ③ P4-009 = 4000 (default, AI1 no negative value).
- ④ **P4-010= 2.00** (AI1 min. input).
- ⑤ P4-011 = 0.00 (default, minimum speed is 0).
- ⑥ P4-012 = 10.00 (default, AI1 max input 10V).
- ⑦ P4-013 = 100.00 (default, maximum speed is 1500).



Parameter	Name	Default	Range	Unit	Attribute
P4-014	AI1 inflection 1 input	2.00	-10.00 ... 10.00	V	×
P4-015	Percentage corresponding to AI1 inflection 1 input	40.00	-100.00 ... 100.00	%	×
P4-016	AI1 inflection 2 input	8.00	-10.00 ... 10.00	V	×
P4-017	Percentage corresponding to AI1 inflection 2 input	60.00	-100.00 ... 100.00	%	×
Parameters P4-014 ... P4-017 see selection ones position = "1" in the parameter P4-009.					
P4-018	AI2 minimum input value	0.00	-10.00 ... 10.00	V	×
P4-019	Percentage corresponding to AI2 minimum input	0.00	-100.00 ... 100.00	%	×
P4-020	AI2 maximum input value	10.00	-10.00 ... 10.00	V	×
P4-021	Percentage corresponding to AI2 maximum input	100.00	-100.00 ... 100.00	%	×
<p>Parameters P4-018 ... P4-021 are effective when tens position of parameter P4-009= "1". Whether the analog input is current (0...20mA) or voltage (0...10V) (select by jumper), expressed in voltage, 0...10V.</p> <p>For example, 0...20mA corresponds to 0...1500 rpm by default, require 4...20mA corresponds 0...1500 rpm, set P4-018 = 2.00:</p> <ol style="list-style-type: none"> ① Set the AI2 jumper to the I side(default). ② P0-005 = 6 (AI2 used as speed reference). ③ P4-009 = 4000 (default, AI2 no negative value). ④ P4-018 = 2.00 (AI2 min. input is 4mA = 2V display). ⑤ P4-019 = 0.00 (default, minimum speed is 0). ⑥ P4-020 = 10.00 (default, AI2 max input is 20mA = 10V display). ⑦ P4-021 = 100.00 (default, maximum speed is 1500). 					
					
P4-022	AI2 inflection 1 input	2.00	-10.00 ... 10.00	V	×
P4-023	Percentage corresponding to AI2 inflection 1 input	40.00	-100.00 ... 100.00	%	×
P4-024	AI2 inflection 2 input	8.00	-10.00 ... 10.00	V	×
P4-025	Percentage corresponding to AI2 inflection 2 input	60.00	-100.00 ... 100.00	%	×
Parameters P4-022 ... P4-025 see selection tens position = "1" in the parameter P4-009.					
P4-026	AI3 minimum input value	0.00	-10.00 ... 10.00	V	×
P4-027	Percentage corresponding to AI3 minimum input	0.00	-100.00 ... 100.00	%	×
P4-028	AI3 maximum input value	10.00	-10.00 ... 10.00	V	×
P4-029	Percentage corresponding to AI3 maximum input	100.00	-100.00 ... 100.00	%	×
Parameters P4-026 ... P4-029 are effective when hundreds position of parameter P4-009= "1".					



Parameter	Name	Default	Range	Unit	Attribute
P4-030	AI3 inflection 1 input	2.00	-10.00 ... 10.00	V	×
P4-031	Percentage corresponding to AI3 inflection 1 input	40.00	-100.00 ... 100.00	%	×
P4-032	AI3 inflection 2 input	8.00	-10.00 ... 10.00	V	×
P4-033	Percentage corresponding to AI3 inflection 2 input	60.00	-100.00 ... 100.00	%	×
See selection hundreds position = "1" in the parameter P4-009.					
P4-034	Analog input AI1 to AI3 as digital input enable	0	0 ... 999	/	×
P4-035	AI1 used as digital input function selection	0	0 ... 63	/	×
P4-036	AI2 used as digital input function selection	0	0 ... 63	/	×
P4-037	AI3 used as digital input function selection	0	0 ... 63	/	×
	<p>AI1, AI2 and AI3 can be configured as digital inputs through parameter P4-034. When analog inputs AI1 / AI2 / AI3 are used as digital inputs, the functions are same as digital input X1 ... X7.</p> <p>When analog inputs AI1 / AI2 / AI3 are used as digital inputs, the digital input is ON when the analog input voltage higher than 7V and it is OFF when the analog input voltage less than 3V.</p> <p style="text-align: center;">Analog input voltage >7V: ON Analog input voltage <3V: OFF</p> <p>One position: AI1 used as digital input enable</p> <ul style="list-style-type: none"> ● 0: AI1 is used as analog input ● 1: AI1 is used as digital input <p>Tens position: AI2 used as digital input enable</p> <ul style="list-style-type: none"> ● 0: AI2 is used as analog input ● 1: AI2 is used as digital input <p>Hundreds position: AI3 used as digital input enable</p> <ul style="list-style-type: none"> ● 0: AI3 is used as analog input ● 1: AI3 is used as digital input <p>Note: When analog inputs AI1 / AI2 / AI3 are used as digital inputs, the common end must be independent, cannot share the common with digital inputs X1 ... X7.</p>				
P4-038	AO1 analog output function selection	0	0 ... 15	/	○
	<p>The parameter P4-038 / P4-041 are used to set the AO1 / AO2 output function.</p> <ul style="list-style-type: none"> ● 0: Reference speed. 10V/20mA = Maximum speed P0-012. ● 1: Running speed. 10V/20mA = Maximum speed P0-012. ● 2: Reserved ● 3: Current. 10V/20mA = Motor rated current P6-004 * 2. ● 4: DC bus voltage. 10V/20mA = 1400V. ● 5: Reserved ● 6: Ramp speed. 10V/20mA = Maximum speed P0-012. ● 7: Communication output. The value of communication address 0x8006, 10V/20mA = 10000. ● 8: Motor temperature. 0V/0mA = temperature value in parameter P4-048, 10V/20mA = temperature value in parameter P4-049. ● 9: Output AI1. 0V/0mA ... 10V/20mA corresponds to AI1 0V/0mA ... 10V/20mA. 				



Parameter	Name	Default	Range	Unit	Attribute
	<ul style="list-style-type: none"> ● 10: Output AI2. 0V/0mA ... 10V/20mA corresponds to AI2 0V/0mA ... 10V/20mA. ● 11: Output AI3. 0V/0mA ... 10V/20mA corresponds to AI3 0V ... 10V. ● 12: Torque. 10V/20mA = Motor rated torque * 2. ● 13: Communication output 2. The value of communication address 0x8007. 10V/20mA =10000. ● 14: Output power. 10V/20mA = Motor rated power. ● 15: Reserved 				
P4-039	AO1 zero offset	0.00	-100.00 ... 100.00	%	○
	<p>Defines the minimum value of the analog output signal AO1. The parameters P4-039 and P4-040 will change the AO1 output timely. AO1 and AO2 are identical.</p> <p>Take AO1 as an example: If maximum speed is 1500 rpm, AO1 is used to output actual running speed: The requirements is AO1 output 4...20mA corresponds to 0 ... 1500 RPM, then set the parameters as follow:</p> <p>P3-038 = 1 P3-039 = 20.00% P3-040 = 80.00%</p> <p>The AO1 characteristics curve is as shown in the following figure.</p> <div style="text-align: center;"> </div>				
P4-040	AO1 gain	100.00	0.00 ... 200.00	%	○
	<p>Scales the analog output AO1 signal. If the value is 100.00%, the reference value of the drive signal corresponds to 10V/20 mA. For example, 10V/20mA = maximum speed P0-012 when AO1 output function is actual speed under default parameters. If 10V/20 mA = 200% of maximum speed P0-012, then set P4-040 = 200.00.</p> <div style="text-align: center;"> </div>				
P4-041	AO2 analog output function selection	0	0 ... 15	/	○
P4-042	AO2 zero offset	0.00	-100.00 ... 100.00	%	○
P4-043	AO2 gain	100.00	0.00 ... 200.00	%	○
Parameters P4-041 ... P4-043 please see parameters P4-038 ... P4-040.					

Parameter	Name	Default	Range	Unit	Attribute
P4-044	AI disconnection detection value	1.500	0.000 ... 10.000	V	○
When the AI detection function is activated (parameter P4-047), the analog input voltage is lower than the value of parameter P4-044, and stays continuously for the defined detection time (P4-046), the drive trips on a fault and the motor coasts to stop.					
P4-045	AI out of range detection value	12.000	0.000 ... 15.000	V	○
P4-046	AI disconnection detection time	3	0 ... 65535	S	○
P4-047	AI disconnection and out of range detection enable	0	0...3	/	○
<p>When the AI detection function is activated (parameter P4-047) and the analog input voltage is higher than the value of parameter P4-045 for the time P4-046, the drive trips on a fault and the motor coasts to stop.</p> <ul style="list-style-type: none"> ● 0: AI1 ... AI3 disconnection and out of range detection are prohibited. AI1, AI2 and AI3 disconnection and out of range detection function are disabled. ● 1: Enables AI1 disconnection and out of range detection. AI1 disconnection and out of range detection function is activated. ● 2: Enables AI2 disconnection and out of range detection. AI2 disconnection and out of range detection function is activated. ● 3: Enables AI3 disconnection and out of range detection. AI3 disconnection and out of range detection function is activated. 					
P4-048	AO output temperature start value	0	-40 ... 140	°C	○
P4-049	AO output temperature end value	130	0 ... 140	°C	○
<p>See the selection of parameter P4-038 = "8".</p> <p>When it is necessary to output the motor temperature through analog output terminal:</p> <p>We should define the temperature value (defined by parameter P4-048) at 0V/0mA (minimum analog output).</p> <p>In addition, we should define the temperature value (defined by parameter P4-049) at 10V/20mA (maximum analog output).</p> <div style="text-align: center;"> </div>					
P4-050	Analog input one-button measurement	0	0 ... 65535	/	○
<p>The parameter is used to measure the minimum and maximum value of analog inputs.</p> <p>Ones position: AI1</p> <ul style="list-style-type: none"> ● 1: AI1 one-button measure minimum input. When start the measurement, please confirm the current AI1 input is in the minimum input. ● 2: AI1 one-button measure maximum input. When start the measurement, please confirm the current AI1 input is in the maximum input. <p>Tens position: AI2</p> <ul style="list-style-type: none"> ● 1: AI2 one-button measure minimum input. See selection = "1" in ones position. ● 2: AI2 one-button measure maximum input. See selection = "2" in ones position. 					

Parameter	Name	Default	Range	Unit	Attribute
	Hundreds position: AI3 <ul style="list-style-type: none"> ● 1: AI3 one-button measure minimum input. See selection = "1" in ones position. ● 2: AI3 one-button measure maximum input. See selection = "2" in ones position. Note: After the measurement is complete, the value reverts back to 0 automatically.				
P4-051	AO output motor current minimum frequency	0.0	0.0 ... 50.0	Hz	○
P4-052	AO output current delay time	0	0 ... 2000	ms	○
<p>When the AO output function is set to "3" (current):</p> <p>If the actual frequency is lower than the value of P4-051, the AO output voltage is forced to zero.</p> <p>If the actual frequency is higher than the value of P4-051 and continuously for the delay time (defined by parameter P4-052), the AO output voltage according to actual current signal.</p> <div style="text-align: center;"> <p>The graph shows two signals over time. The top signal is 'Output frequency' which ramps up linearly, then levels off at a constant value. The bottom signal is 'AO output' which remains at zero until the frequency reaches a threshold labeled 'P4-051'. Once the frequency exceeds this threshold, the AO output ramps up linearly with a delay labeled 'P4-052'.</p> </div>					
P4-053	AI zero speed offset	10	10 ... 1000	RPM	○
<p>If an analog input is used as speed reference and the speed reference is lower than the value of P4-053, the speed reference is forced to zero speed. This function is very useful in applications where zero drift is avoided or where it is desired not to operate at too low speed.</p>					
P4-054	AO1 filter factor	200	0 ... 1000	/	○
P4-055	AO2 filter factor	200	0 ... 1000	/	○
<p>Defines a first order low-pass filter for analog outputs. The higher the filter factor setting, the slower the dynamic response of the analog output; Conversely, the lower the filter factor setting, the faster the dynamic response of the analog output, but there may be fluctuations due to unstable output.</p> <div style="text-align: center;"> <p>The graph shows the response of a first-order low-pass filter. The y-axis is 'Output' (0 to 100%) and the x-axis is 'Time (t)'. A step function labeled 'Unfiltered Signal' rises from 0 to 100%. The 'Filtered Signal' is a smooth curve that starts at 0 and asymptotically approaches 100%. At time 'T', the filtered signal reaches 70.7% of the final value.</p> <div style="position: absolute; top: 10%; right: 10%;"> $y(n) = ax(n) + (1-a)y(n-1)$ <p> $y(n)$: filtered signal $x(n)$: unfiltered signal a: filter time constant, $a = 1/T$ T: filter time </p> </div> </div>					
P4-056	AO zero offset mode	1	0 ... 1	/	○
<p>Define whether the analog output zero offset is on the Y-axis or X-axis. The examples in this manual are based on the Offset in Y-axis.</p> <ul style="list-style-type: none"> ● 0: Offset in X-axis. ● 1: Offset in Y-axis. 					

5.6 Start and Stop (P5)

Parameter	Name	Default	Range	Unit	Attribute
P5-000	Asynchronous motor sensor-less control start mode	0	0 ... 2	/	×
<ul style="list-style-type: none"> 0: Normal start <p>For VF control, the drive start to run from the start frequency (parameter P5-001) for the time defined by parameter P5-002, and then accelerate to the reference speed.</p> <p>For vector control, the drive pre-magnetizes the motor before start. The pre-magnetizing time is defined by parameter P5-003, and then accelerate to reference speed from zero speed. If the motor is in free rotating (flying) state, the motor will be decelerated to low speed before the acceleration.</p> 1: Start after DC injection (only effective when VF control) <p>DC current (parameter P5-004) is injected to the motor for the time defined by parameter P5-005. After the DC injection is completed, start to run from the start frequency (parameter P5-001) for the time defined by parameter P5-002, then accelerate to reference speed.</p>  2: Flying start <p>The drive injects AC current (parameter P5-006) into the motor to identify the motor flying speed and start from the identified speed, and the start direction is defined by parameter P5-007. The current and voltage are smooth without any impact during the start.</p>  <p>Notes:</p> <ul style="list-style-type: none"> ➤ The start mode for synchronous motor sensor-less control is defined by parameter P8-000. ➤ The parameter P5-017 is run signal delay time. After receiving a start command, the drive will not start until the delay time defined by parameter P5-017 has elapsed. 					

Parameter	Name	Default	Range	Unit	Attribute
P5-001	Start frequency	0.50	0.00 ... 30.00	Hz	×
P5-002	Start frequency holding time	0.0	0.0 ... 300.0	s	○
The parameters P5-000 and P5-001 are effective only when VF control, see selections of parameter P5-000 = "0" and "1".					
P5-003	Pre-magnetization time	0.3	0.0 ... 300.0	s	○
Effective only under vector control, see selection of parameter P5-000 = "0".					
P5-004	DC inject current	50.0	0.0 ... 120.0	%	○
P5-005	DC inject time	0.0	0.0 ... 300.0	s	○
The parameters P5-004 and P5-005 are effective only under VF control. 100% corresponds to the motor rated current. See selection of parameter P5-000 = "1".					
P5-006	Flying start measuring current	4.5	1.0 ... 6553.5	A	×
P5-007	Flying start direction	0	0 ... 2	/	×
<p>When P5-000 = 2, the drive injects AC current (parameter P5-006) into the motor to identify the motor flying speed and start from the identified speed, and the start direction is defined by parameter P5-007.</p> <ul style="list-style-type: none"> ● 0: From motor forward rotating direction. ● 1: From motor reverse rotating direction. ● 2: From current motor flying direction. 					
P5-008	Stop mode	0	0 ... 2	/	×
<p>Selects the stop mode applied when the run signal is switched off.</p> <ul style="list-style-type: none"> ● 0: Deceleration to stop <p>Stop the drive along the deceleration ramp. When the actual motor speed is less than the value of "P5-013" for the time defined by parameter "P5-014", the drive cut off the motor power supply.</p>  ● 1: Coast to stop <p>Stop by cutting of the motor power supply. The motor coast to stop and rotates freely to zero speed.</p> ● 2: Deceleration to stop + DC braking <p>First, decelerate to stop according to deceleration time, when the output frequency is lower than DC braking start frequency (parameter P5-009), inject the DC braking current (parameter P5-010), for the DC braking time (parameter P5-011), the drive cut off the motor supply.</p> <p>Note: P5-008 = 2 only effective when asynchronous motor VF control.</p>  					



Parameter	Name	Default	Range	Unit	Attribute
P5-009	DC braking start frequency	0.50	0.00 ... 30.00	Hz	×
P5-010	DC braking current	50.0	0.0 ... 120.0	%	○
P5-011	DC braking time	5.0	0.0 ... 300.0	s	○
Parameters P5-009 ... P5-011 are for DC braking logic. See selection "2" in parameter P5-008.					
P5-012	DC current ramp-up time	500	0 ... 65535	ms	○
	DC current ramp-up time, both DC injection and DC braking are available.				
P5-013	Cut off output speed	60	1 ... 65535	rpm	○
P5-014	Cut off output delay time	0.5	0.0 ... 60.0	S	○
	Parameters P5-013 and P5-014 are for cut off the output delay time. See selection "1" in parameter P5-008.				
P5-015	Run signal delay time	0.000	0.000 ... 10.000	S	×
	When the drive receive a start signal for the time difined by parameter P5-015, and then start according the start mode (parameter P5-000). See parameter P5-000.				

5.7 Motor Parameters (P6)

Parameter	Name	Default	Range	Unit	Attribute
P6-000	Motor rated power	Model dependent	0.1 ... 6553.5	kW	×
	Defines the motor rated power. Must be equal to the value on the motor nameplate.				
P6-001	Motor rated voltage	380	1 ... 65535	V	×
	Defines the motor rated voltage. Must be equal to the value on the motor nameplate.				
P6-002	Motor rated frequency	50.0	0.1 ... 6553.5	Hz	×
	Defines the motor rated frequency. Must be equal to the value on the motor nameplate. Note: The parameter is only used for asynchronous motor.				
P6-003	Motor rated speed	Model dependent	0 ... 65535	rpm	×
	Defines the motor rated speed. Must be equal to the value on the motor nameplate.				
P6-004	Motor rated current	Model dependent	0.0 ... 6553.5	A	×
	Defines the motor rated current. Must be equal to the value on the motor nameplate.				
P6-005	Motor pole pairs	2	1 ... 200	/	×
	Defines the motor pole pairs. Must be equal to the value on the motor nameplate.				
P6-006	Motor inertia	Model dependent	0.001 ... 65.535	kg. m ² *10	×
	The larger the motor inertia setting, the faster the speed response. However, excessive motor inertia can cause vibration. In closed-loop control mode, the motor inertia can be obtained through the inertia auto-tune. However, when the motor shaft is loaded, the motor inertia auto-tune cannot be performed, otherwise the machine may be damaged or the motor inertia obtained from inertia auto tune may be inaccurate. Note: Generally, it is set based on the inertia provided by the motor, or the user does not need to adjust this parameter. If the speed loop gain is insufficient, this value can be used to enhance the speed loop gain.				
P6-007	Motor no-load current	Auto-tune	0.0 ... 6553.5	A	×
	Parameters P6-007 to P6-013 are the main motor parameters that affect the vector control mode. They are automatically obtained after auto-tune and stored in the memory until the next manual modification or auto-tune. Note: The parameter is only used for asynchronous motor.				
P6-008	Stator resistance	Auto-tune	0.000 ... 65.535	Ω	×
	Parameters are automatically obtained after auto tune.				
P6-009	Rotor resistance	Auto-tune	0.000 ... 65.535	Ω	×
	Note: The parameter is only used for asynchronous motor.				
P6-010	D-axis inductance (PMSM) Stator leakage inductance (ACIM)	Auto-tune	0.00 ... 655.35	mH	×
	For synchronous motor is D-axis inductance, for asynchronous motor is stator leakage inductance.				
P6-011	Q-axis inductance (PMSM) Mutual inductance (ACIM)	Auto-tune	0.00 ... 655.35	mH	×
	Note: For synchronous motor is Q-axis inductance, for asynchronous motor is mutual inductance.				
P6-012	Motor flux linkage	Auto-tune	0.000 ... 65.535	mWb	×
	Note: The parameter is only used for synchronous motor.				
P6-013	Maximum D-axis current	Auto-tune	0.0 ... 6553.5	A	×
	Note: The parameter is only used for synchronous motor.				

Parameter	Name	Default	Range	Unit	Attribute
P6-014	Inertia auto tune selection	0	0 ... 1	/	×
	<p>Inertia auto tune function only enabled for sensor vector control, it can't be realized under sensor-less control</p> <ul style="list-style-type: none"> ● 0: No action ● 1: Inertia tune <p>Under closed-loop vector control, when the parameter is set to "1" and the "RUN" key is pressed, will start motor inertia auto-tune according to the inertia auto tune parameters set in P6-015 and P6-016.</p> <p>Notes:</p> <ul style="list-style-type: none"> ➤ Before inertia auto-tune, it is necessary to ensure that the motor can operate normally after motor parameters auto-tune, and check the forward and reverse rotating are allowed on the motor shaft side. ➤ After start inertia auto-tune, the motor will rotate for the set number of turns P6-015 within the time period P6-16 and then stop. 				
P6-015	No. of motor rotation for inertia auto tune	1	1 ... 10	/	×
	See parameter P6-014 for more information.				
P6-016	Inertia auto tune time	0.1	0.1 ... 300.0	s	×
	See parameter P6-014 for more information.				
P6-017	Motor parameters auto tune selection	0	0 ... 2 / 0 ... 4	/	×
	<p>The range is 0 ... 2 for asynchronous motor and 0 ... 2 for synchronous.</p> <p>For asynchronous motor:</p> <ul style="list-style-type: none"> ● 0: No action ● 1: Static tune ● 2: Rotate tune <p>For synchronous motor:</p> <ul style="list-style-type: none"> ● 0: No action ● 1: Static tune 1 ● 2: Rotate tune 1 ● 3: Static tune 2 ● 4: Rotate tune 2 <p>Notes:</p> <ul style="list-style-type: none"> ➤ The static auto-tune can be used when the motor is loaded and it is not possible to remove the load from the motor shaft. ➤ The motor must be free from load for the rotate auto-tune. A rotate auto-tune first performs a static auto-tune, and start rotating the motor at 70% of rated speed in the forward direction for several seconds, please be careful. ➤ If there is any emergency, press the M and STOP keys simultaneously to stop the drive in coast to stop mode. 				

5.8 V/F Control (P7)


Parameter	Name	Default	Range	Unit	Attribute
P7-000	V/F curve selection	0	0 ... 2	/	×
	<p>Proper curve should be selected according to the actual situation.</p> <ul style="list-style-type: none"> 0: Linear VF curve Applicable to the constant torque load situation.  1: Multi-point V/F curve Multi-point VF curve setting by user, applicable to sectional constant torque load. $F_0 < F_1 < F_2 < F_3 < f_b$ f_b is the motor rated frequency $V_0 \leq V_1 \leq V_2 \leq V_3 \leq 100\%$ V_0, V_1, V_2, V_3 are the percentage of motor rated voltage P6-001  2: Power of 2 V/F curve Applicable to the variable torque loads such as fan and pump. See the selection "0" for the curve. 				
P7-001	Low frequency torque boost	0.0	0.0 ... 30.0	%	×
P7-002	Torque boost cut-off frequency	10.0	1.0 ... 50.0	Hz	×

The parameters P7-001 and P7-002 are used to set at a required value for the motor to run reliably at low speed.

However, excessive value can cause the motor over-current and/or overheat.

100% of P7-001 corresponds to the motor rated voltage.

- **P7-001 = 0: Auto torque boost**
- **P7-001 = 0.1...30.0: Manual torque boost**






Note: The parameters P7-001 and P7-002 are effective only in V/F control (P0-003 = 3)

P7-003	V/F control slip compensation gain	100.0	0.0...300.0	%	○
<p>The function is used to keep the motor speed constant if load fluctuation or under heavy load in VF control. 100% means full slip gain; 0% means no slip gain.</p>					
P7-004	Multi-point V/F frequency 1	10.0	0.1 ... 6553.5	Hz	×
P7-005	Multi-point V/F voltage 1	20.0	0.1 ... 100.0	%	×
P7-006	Multi-point V/F frequency 2	20.0	0.1 ... 6553.5	Hz	×
P7-007	Multi-point V/F voltage 2	40.0	0.1 ... 100.0	%	×
P7-008	Multi-point V/F frequency 3	30.0	0.1 ... 6553.5	Hz	×
P7-009	Multi-point V/F voltage 3	60.0	0.1 ... 100.0	%	×
P7-010	Multi-point V/F frequency 4	50.0	0.1 ... 6553.5	Hz	×
P7-011	Multi-point V/F voltage 4	100.0	0.1 ... 100.0	%	×
Parameters P7-004 ... P7-011 are effective when parameter P7-000 = "1". See the selection "1" in parameter P7-000.					
P7-012					
...	Reserved	0	0 ... 65535	/	×
P7-016					

P7-017	Oscillation suppression enable	1	0 ... 1	/	×
	<ul style="list-style-type: none"> ● 0: Oscillation suppression is disabled ● 1: Oscillation suppression is enabled 				
P7-018	Oscillation suppression mode selection	0	0 ... 2	/	×
	<ul style="list-style-type: none"> ● 0: Mode 0 ● 1: Mode 1 ● 2: Mode 2 				
P7-019	Oscillation suppression factor	40	0 ... 200	/	×
	Only when the motor oscillates significantly, it is necessary to appropriately increase the gain. The higher the factor, the more obvious the suppression effect on oscillation.				
P7-020	Oscillation suppression gain	100	0 ... 500	%	○
	The higher the parameter setting, the stronger the Oscillation suppression effect.				
P7-021	Slip compensation under regeneration	1	0 ... 1	/	○
	<ul style="list-style-type: none"> ● 0: Slip compensation under regeneration is not effective ● 1: Slip compensation under regeneration is effective 				
P7-022	Torque boost coefficient	100	0 ... 600	%	○
	<p>The parameter is used with parameter P7-001, this parameter is multiplied by P7-001 to obtain the final torque boost.</p> <p>100% corresponds to the setting value of P7-001.</p>				

5.9 PMSM Sensor-less Control (P8)

Parameter	Name	Default	Range	Unit	Attribute
P8-000	Synchronous motor sensor-less control start mode	0	0 ... 2	/	×
<p>The parameter is used to set the start mode of synchronous motor sensor less control</p> <ul style="list-style-type: none"> 0: Start from zero speed <p>Start from zero speed, due to the lack of speed and magnetic pole position feedback, it is impossible to determine the initial magnetic pole position during this startup mode, so slight reverse rotation may occur randomly during startup. If the motor does not allow reverse rotation or the requirement is relatively strict, please select high frequency injection start mode.</p> 1: Flying start <p>The drive will automatically identify the motor speed and rotating direction and directly start from the identified speed. The current and voltage are smooth without any impact during the start.</p>  2: High frequency injection start <p>After receive a start signal, the drive first injects high frequency signals to identify the initial magnetic pole position of the motor, and then starts it smoothly. It is applicable when the equipment requires that reverse rotation is not allowed during the startup.</p> <p>Note: About the start mode of asynchronous motor, refer to the parameter P5-000.</p>  					

P8-001	Synchronous motor torque boost coefficient	30.0	0.0 ... 50.0	%	×
	<p>100% corresponds to motor rated current.</p> <p>The motor torque boost is defined by parameters P8-001, P8-006 and P8-007. The actual torque boost curve is shown in the figure.</p> <p>The value of torque boost cut off frequency should not set too small for occasions with heavy load. If the value is too small, it may lead to stall operation after start; If the value setting too high, the output current may increase even cause overcurrent trip.</p> 				
P8-002	High frequency voltage injection gain	3.00	0.10 ... 60.00	%	×
	The parameter is effective when P8-000 = 2. The injection gain represents the intensity of the injection.				
P8-003	Synchronous motor start compensation coefficient	1.5	0.0 ... 3.0	%	×
	Reserved.				
P8-004	MTPA enable	0	0 ... 1	/	×
	<p>Maximum torque per ampere</p> <ul style="list-style-type: none"> ● 0: MTPA function is inactive. ● 1: MTPA function is active. 				
P8-005	Inductance tune pulse width	0	0 ... 65535	/	○
	This parameter is obtained by auto-tune and does not need to be modified manually.				
P8-006	PM torque boost cut off frequency	30.0	10.0 ... 50.0	%	×
	See parameter P8-001. 100% corresponding to the motor rated speed (P6-003).				
P8-007	PM torque boost offset	0.0	0.0 ... 60.0	%	×
	Minimum limit value of torque boost. If it is a non-zero value, the minimum torque boost is limit by this parameter throughout the speed range.				


5.10 Vector Control (P9)

Parameter	Name	Default	Range	Unit	Attribute
P9-000	Speed regulator Kp 1	40.0	0.0 ... 6553.5	Hz	○

Speed regulator Kp should be adjust according to rotating inertia of machines connecting with motor. For machines with large rotating inertia, please increase Kp value; for machines with small rotating inertia, please decrease Kp value. When Kp is greater than inertia, although the control response become quickly, but may cause speed oscillation. Reversely, if Kp setting is smaller than inertia, the control response will get slower and the time taken to adjust the speed to the stable value will longer.



Speed regulator Ki defines the rate at which the speed controller output changes. The shorter the Ki setting, the faster the system responses. Too short Ki value may cause the system unstable.

- When parameter P9-025 = 0, the speed regulator Kp and Ki are defined by parameters P9-001 ... P9-005.



Note: When parameter P9-004 = 0, only speed regulator Kp1 and Ki1 are effective. (P9-000 and P9-001).

- When parameter P9-025 = 1, the speed regulator Kp and Ki are defined by parameters P9-000 ... P9-004 and P9-018 ... P9-024.



P9-001	Speed regulator Ki 1	60.0	0.0 ... 6553.5	ms	○
	Refer to parameter P9-000 for more information.				
P9-002	Speed regulator Kp 2	40.0	0.0 ... 6553.5	Hz	○

	Refer to parameter P9-000 for more information.				
P9-003	Speed regulator Ki 2	60.0	0.0 ... 6553.5	ms	○
	Refer to parameter P9-000 for more information.				
P9-004	ASR switch frequency 0	5.0	0.0 ... 6553.5	Hz	○
	Refer to parameter P9-000 for more information.				
P9-005	Speed regulator output filter coefficient	1.0	0.0 ... 5.0	/	○
	Defines speed regulator output filter, The higher the parameter setting, the smoother the speed loop output, and the slower the response to sudden speed changes.				
P9-006	Current regulator Kp	0.10	0.00 ... 655.35	V/A	○
P9-007	Current regulator Ki	10.0	0.0 ... 6553.5	ms	○
P9-008	High speed current regulator Kp	0.10	0.00 ... 655.35	V/A	○
P9-009	High speed current regulator Ki	10.0	0.0 ... 6553.5	ms	○
P9-010	High speed current regulator PI switch enable	1	0 ... 1	/	○
<p>Defines the current regulator Kp and Ki. Vector control will control the motor output current and keep track the current. Usually the value can be obtained after auto-tune.</p> <ul style="list-style-type: none"> ● P9-010 = 0: Current regulator Kp (P9-007) and Ki (P9-008) is effective in the entire speed range. ● P9-010 = 1: Current regulator Kp and Ki are changed to the parameters P9-008 and P9-009 at high speed. 					
P9-011	High speed current regulator PI coefficient	100	50 ... 200	%	○
	The higher the parameter setting, the stronger the high-speed current regulator PI is.				
P9-012	Asynchronous motor slip compensation gain	100.0	0.0 ... 300.0	%	○
	<p>The function is used to keep the motor speed constant if load fluctuation or under heavy load.</p> <div style="text-align: center;"> </div> <p>Note: Only valid under sensor/sensor-less vector control.</p>				
P9-013	ACI slip limit (motoring status)	600	0 ... 900	rpm	×
	The parameter P9-013 limits the maximum slip compensation of the motor in motoring state.				
P9-014	ACI slip limit (regenerating status)	300	0 ... 900	rpm	×
	The parameter P9-014 limits the maximum slip compensation of the motor in regenerating state.				
P9-015	Field weakening gain	300	0 ... 1000	/	×
	Defines the field weakening gain when the motor speed running in field weakening state.				
P9-016	U phase current zero offset	5086	-32768 ... 32767	/	×
P9-017	V phase current zero offset	5092	-32768 ... 32767	/	×
	Reserved.				
P9-018	Speed regulator Kp 3	40.0	0.0 ... 6553.5	Hz	○

P9-019	Speed regulator Ki 3	60.0	0.0 ... 6553.5	/	○
P9-020	Speed regulator Kp 4	40.0	0.0 ... 6553.5	Hz	○
P9-021	Speed regulator Ki 4	60.0	0.0 ... 6553.5	/	○
P9-022	ASR switch frequency 1	0	0 ... 65535	rpm	○
P9-023	ASR switch frequency 2	0	0 ... 65535	rpm	○
P9-024	ASR switch frequency 3	0	0 ... 65535	rpm	○
P9-025	ASR switch enable	0	0 ... 1	/	×
<p>When parameter P9-025 = 0, the speed regulator Kp and Ki are defined by parameters P9-001 ... P9-005.</p> <p>When parameter P9-025 = 1, the speed regulator Kp and Ki are defined by parameters P9-000 ... P9-004 and P9-018 ... P9-024.</p> <p>See the parameter P9-000 for more information.</p>					
P9-026	Current regulator decoupling gain	0	0 ... 100	%	○
	Decoupling gain of current regulator.				
P9-027	Field-weakening integration time	100	0 ... 100	/	×
	Defines the field-weakening integration time, together with parameter P9-015, constitute a PI regulator for field-weakening control.				
P9-028	Acceleration compensation	0.00	0.00 ... 655.35	s	×
	<p>Defines the derivation time for acceleration compensation. In order to compensate inertia during acceleration, a derivative of the reference is added to the output of the speed regulator. As shown in the figure below, a large inertia load changes without compensation or with compensation during acceleration along a slope.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>无加速度补偿 Without acceleration compensation</p> </div> <div style="text-align: center;"> <p>有加速度补偿 With acceleration compensation</p> </div> </div>				
P9-029	Speed regulator Ki delay time	0	0 ... 65535	ms	○
	When the operation time exceeds the delay time (P9-029), the speed loop integration begins to take effect.				
P9-030	Observer optimization	0	0 ... 1	/	×
	<ul style="list-style-type: none"> ● 0: Inactive. ● 1: Active. 				
P9-031	Field-weakening voltage filter time	0.000	0.000 ... 1.000		×
	For the high speed applications, when the DC bus voltage fluctuates, set appropriate filter time to make the motor speed control more stable.				

5.11 Torque Control (PA)

Parameter	Name	Default	Range	Unit	Attribute
PA-000	Torque reference and direction selection	0000	0000 ... 0047	/	×
	<p>One position: Torque reference source selection</p> <ul style="list-style-type: none"> 0: Modbus 1: Parameter PA-002 2 ... 3: Reserved 4: AI1 5: AI2 6: AI3 7: Reserved <p>Tens position: Torque direction</p> <ul style="list-style-type: none"> 0: Follow the torque reference direction 1: Invert the torque reference direction. 2: Follow the RUN command direction <p>Example: When P0-004 = 2, digital input X1 and X2 are used as forward and reverse input. Set P3-001 = 03 and P3-002 = 04, then:</p> <p style="padding-left: 40px;">If X1 = 1 and X2 = 0, torque direction is positive (FWD).</p> <p style="padding-left: 40px;">If X1 = 0 and X2 = 1, torque direction is negative (REV).</p> <ul style="list-style-type: none"> 3: Opposite to the RUN command direction. <p>Example: When P0-004 = 2, digital input X1 and X2 are used as forward and reverse input. Set P3-001 = 03 and P3-002 = 04, then:</p> <p style="padding-left: 40px;">If X1 = 1 and X2 = 0, torque direction is negative (REV).</p> <p style="padding-left: 40px;">If X1 = 0 and X2 = 1, torque direction is positive (FWD).</p> <ul style="list-style-type: none"> 4: Follow or Invert torque reference direction by digital input. <p>Example: When P0-004 = 2, digital input X1 and X2 are used as forward and reverse input. Set P3-001 = 03 and P3-002 = 04, then:</p> <p style="padding-left: 40px;">If X1 = 1 and X2 = 0, torque direction follow the torque reference direction.</p> <p style="padding-left: 40px;">If X1 = 0 and X2 = 1, torque direction is opposite to the torque reference direction.</p> <ul style="list-style-type: none"> 5: Torque reference direction is defined by communication. <p>① When P0-004 = 0:</p> <p style="padding-left: 40px;">If bit1 of address 0x8000 is 0, torque direction follow the torque reference direction.</p> <p style="padding-left: 40px;">If bit1 of address 0x8000 is 1, torque direction is opposite to the torque reference direction.</p> <p>② When P0-004 = 4:</p> <p style="padding-left: 40px;">If bit1 of receive message 1 is 0, torque direction follow the torque reference direction.</p> <p style="padding-left: 40px;">If bit1 of receive message 1 is 1, torque direction is opposite to the torque reference direction.</p> <p>③ When P0-004 = 5:</p> <p style="padding-left: 40px;">If bit1 of PZD1 is 0, torque direction follows the torque reference direction.</p> <p style="padding-left: 40px;">If bit1 of PZD1 is 1, torque direction is opposite to the torque reference direction.</p>				
PA-001	AI maximum input corresponding torque	100.0	-300.0 ... 300.0	%	○

Parameter	Name	Default	Range	Unit	Attribute
	100.0 % = 100.0% of motor rated torque.				
PA-002	Torque reference value	0.0	-300.0 ... 300.0	%	○
	Torque reference when ones position of PA-000 is [1]. 100.0% = 100.0% of motor rated torque.				
PA-003	Torque acceleration time	0.00	0.00 ... 655.35	s	○
PA-004	Torque deceleration time	0.00	0.00 ... 655.35	s	○
	Torque acceleration time: The accelerate time that the torque from zero accelerate to maximum torque. Torque deceleration time: The decelerate time that the torque from maximum torque decelerate to zero				
PA-005	Torque control forward max. speed selection	0	0 ... 3	/	○
	PA-005 and PA-006 are used to set the forward/reverse maximum speed limit in torque control. In torque control mode, when the torque command is higher than the load, the motor speed will accelerate to the maximum speed limit to prevent the motor continues acceleration. <ul style="list-style-type: none"> ● 0: Parameter setting (PA-007) ● 1: AI1 ● 2: AI2 ● 3: AI3 				
PA-006	Torque control reverse max. speed selection	0	0 ... 3	/	○
	<ul style="list-style-type: none"> ● 0: Parameter setting (PA-008) ● 1: AI1 ● 2: AI2 ● 3: AI3 				
PA-007	Torque control forward max. speed	100.0	0.0 ... 100.0	%	○
	Forward maximum speed when PA-005 = 0. 100.0% = Maximum speed P0-012.				
PA-008	Torque control reverse max. speed	100.0	0.0 ... 100.0	%	○
	Reverse maximum speed when PA-006 = 0. 100.0% = Maximum speed P0-012.				
PA-009	Torque control stop mode	0	0 ... 2	/	×
	Selects stop mode for torque control. <ul style="list-style-type: none"> ● 0: Coast to stop ● 1...2: Reserved 				
PA-010	Torque control start compensation	5.0	0.0 ... 10.0	/	○
	This parameter is effective in the current type open loop vector control mode of asynchronous motors and is used to compensate for the stator resistance of asynchronous motors. This parameter can effectively prevent the asynchronous motor from stalling when starting at low frequency. Note: Only effective when parameter P0-002 = 5.				
PA-011	Speed control torque feed forward enable	0	0 ... 1	/	○
	<ul style="list-style-type: none"> ● 0: Disable ● 1: Enable <p>The drive operates under speed control, but a torque value can be added to the output of the speed controller. This can be used to improve the regulation of systems where the speed loop gains need to be low for stability.</p>				

5.12 Advanced Parameter (PB)



Parameter	Name	Default	Range	Unit	Attribute
PB-000	Carrier frequency	0.75 ... 2.2kW: 8	1 ... 16	kHz	×
		3.7 ... 11kW: 6	1 ... 16		
		15kW: 6	1 ... 12		
		18.5 ... 30kW: 4	1 ... 12		
		37 ... 45kW: 4	1 ... 8		
		55kW: 3	1 ... 6		
		75 ... 90kW: 3	1 ... 5		
		110 ... 160kW: 2	1 ... 4		
		185 ... 500kW: 2	1 ... 2		
	Carrier frequency has an important impact on operations of drive and motor. When carrier frequency increases, the motor loss, motor temperature rising and motor noise will be decreased. If carrier frequency decreases, the drive temperature rising, the leakage current of motor and external radiation interference will be decreased.				
Warning: Generally, users are not recommended to change this parameter, as it may cause accidental damage.					
PB-001	Carrier frequency automatic adjustment	0	0 ... 2	/	×
	<ul style="list-style-type: none">0: Carrier frequency automatic adjustment function is disabled.1: Carrier frequency is adjusted automatically according to temperature.2: Random carrier frequency.				
	Note: Only effective when P0-002 = 3 (V/F control mode).				
PB-002	Carrier frequency random depth	0	0 ... 10	/	×
	<ul style="list-style-type: none">0: No adjustment1...10: Carrier frequency random depth				
PB-003	Voltage utilization	100	50 ... 120	%	○
	The maximum allowed voltage utilization for the motor control. Do not change this value without consulting technical support. Higher values may result in control instability or over-current trip.				
PB-004	DC over voltage control enable	1	0 ... 1	/	×
PB-005	DC over voltage control voltage	700	300 ... 800	V	×
PB-006	DC over voltage control Kp	200	0 ... 65535	/	×
PB-007	DC over voltage control Ki	1000	0 ... 65535	/	×

Parameter	Name	Default	Range	Unit	Attribute
<ul style="list-style-type: none"> ● PB-004 = 0: Disable DC over voltage control ● PB-004 = 1: Enable DC over voltage control <p>If the DC bus voltage reaches or exceeds the value defined by parameter PB-005, the drive decreases the braking torque, prolong deceleration time even controlling the motor speed higher than the reference speed. When the DC bus voltage is lower than the value defined by parameter PB-005, restore to normal operation. DC over voltage control use PI regulation, proportional gain and integration time are defined parameters PB-006 and PB-007.</p> <p>Note: If an external brake chopper or a brake resistor (if built-in brake chopper) is connected to the drive, must set PB-004 = 0.</p>					
PB-008	Dynamic braking enable	0	0 ... 1	/	×
PB-009	Dynamic braking voltage	680	300 ... 760	V	×
<p>The parameter of PB-008 enables the dynamic braking function.</p> <ul style="list-style-type: none"> ● PB-008 = 0: Dynamic braking is disabled ● PB-008 = 1: Dynamic braking is enabled. <p>The brake chopper working voltage is defined by parameter PB-009. For large rotating inertia applications and when rapid stop by braking is required, select matched brake chopper, brake resistor and set PB-008 to 1.</p> <p>Note: If an external brake chopper is installed, should set PB-008 = 1 too.</p>					
PB-010	Flux braking enable	1	0 ... 1	/	×
PB-011	Flux braking control Kp	100	0 ... 65535	%	○
PB-012	Flux braking control Ki	50	0 ... 65535	/	×
<ul style="list-style-type: none"> ● PB-010 = 0: Disable ● PB-010 = 1: Enable <p>When the motor decreases, the motor can be rapidly decelerated if magnetic flux braking is selected. The energy of the mechanical system is changed to thermal energy in the motor during the braking process. However, if the function is activated, the output current will become higher. Flux braking use PI regulation, proportional gain and integration time are defined by parameters PB-011 and PB-012.</p>					
PB-013	DC under voltage control	0	0 ... 1	/	○
PB-014	DC under voltage control voltage	460	0 ... 65535	V	○
PB-015	DC under voltage control Kp	200	0 ... 65535	/	○
PB-016	DC under voltage control Ki	1000	0 ... 65535	/	○
<ul style="list-style-type: none"> ● PB-013 = 0: Disable ● PB-013 = 1: Enable <p>The function of DC under voltage control is use to decrease the motor speed, the load inertial energy feedback to DC bus to keep DC voltage higher than the under voltage, avoid trip by under voltage.</p> <p>When the DC bus voltage is lower than the value defined by parameter PB-014, the drive decrease the motor speed to keep the DC voltage higher than the under voltage value (defined by parameter PB-014); During the control process, if the DC bus voltage returns to normal, the drive returns to normal operation mode. DC under voltage use PI regulation, proportional gain and integration time are defined by parameters PB-015 and PB-016.</p>					



Parameter	Name	Default	Range	Unit	Attribute
PB-017	Automatic restart	0	0 ... 1	/	×
PB-018	Automatic restart delay time	0	0 ... 65535	s	×
<ul style="list-style-type: none"> ● PB-017 = 0: Disable ● PB-017 = 1: Enable <p>When automatic restart function is active and the start signal is valid, if the drive is powered up and last the time defined by parameter PB-018, the drive will start automatically without the need for the personal to intervene. This function should be used judiciously.</p> <p>Note: Generally, it is not recommended to activate the automatic restart function. Because the motor will start automatically after powered. If the device is not ready or other unqualified operators are unclear about the situation, it may cause an accident.</p>					
PB-019	Output voltage correction factor	2000	100 ... 65535	/	×
PB-020	Maximum sampling output voltage	115	115 ... 65535	/	×
PB-021	UV line voltage zero offset	12187	0 ... 32767	/	×
PB-022	UW line voltage zero offset	12222	0 ... 32767	/	×
PB-023	Load type	0	0 ... 1	/	×
	<ul style="list-style-type: none"> ● PB-023 = 0: G type, constant torque / heavy load application ● PB-023 = 1: L type, variable torque / light load application 				
PB-024	Dead-time compensation prediction	1200	0 ... 65535	/	×
PB-025	Dead-time compensation	100	0 ... 200	%	×
<p>The parameters PB-024 and PB-025 generally do not require modification, only when there are special requirements for the output voltage waveform under specific circumstances, or when abnormal fluctuations in the motor occur due to output voltage waveform, commissioning can be through the guidance of the manufacturer.</p>					
PB-026	Reserved				
PB-027	Reserved				
PB-028	Reserved				
PB-029	Reserved				
PB-030	Drooping rate	0.00	0.00 ... 100.00	%	
	<p>When several drives drive one load, the function can distribute the load automatically between drives and make them work cooperatively. For example, for assembly line, this function can be used to balance loads, allocate loads between drives at different power levels in proportion to the power, and thus ensure the assembly line operate properly. Each drive adjusts output speed automatically according to its load condition and drooping rate setting.</p>				
PB-031	Brake chopper continuous working fault time	0.00	0.00 ... 600.00	s	×
	<p>When the continuous brake chopper working time is longer than the value of PB-031, the drive trips on a fault. When the set value is 0.00s, it indicates that the protection function is turned off.</p>				
PB-032	PM motor sensor control over speed protection	0	0 ... 1	/	×
PB-033	PM motor sensor control over speed detect time	0.050	0.050 ... 0.500	s	○


Parameter	Name	Default	Range	Unit	Attribute
<ul style="list-style-type: none"> ● PB-032 = 0: Inactive. ● PB-032 = 1: Active. <p>When PB-032=1 and P0-002=0 (synchronous motor closed-loop vector control), the drive trips on a fault when motor over speed for the time defined by parameter PB-033.</p>					
PB-034	Input phase loss	1	0 ... 1	/	×
	<p>Activates/deactivates input phase loss detection.</p> <ul style="list-style-type: none"> ● 0: Inactive. ● 1: Active. The drive trips on a fault if detects missing power supply voltage phase. 				
PB-035	Output phase loss	0	0 ... 1	/	×
	<p>Activates/deactivates motor phase loss detection.</p> <ul style="list-style-type: none"> ● 0: Inactive. ● 1: Active. The drive trips on a fault if detects any of the motor phases is not connected. 				

5.13 Process PID Control (PC)


Parameter	Name	Default	Range	Unit	Attribute
PC-000	Process open loop and process close loop calculation formula	0	0 ... 3	/	×
	<p>The parameters in group PC are effective when P0-005 = 5 [PID].</p> <ul style="list-style-type: none"> ● 0: Speed reference is open loop main reference and auxiliary reference calculation. Refer to PC-003 for more information. The reference is defined by main reference, auxiliary reference and calculation, is shown below:  <ul style="list-style-type: none"> ● 1: Speed reference is PID The Frequency reference is defined by process PID output. Refer to PC-004 for more information. ● 2: Speed reference is open loop main reference and auxiliary reference calculation + PID. ● 3: Speed reference is open loop main reference and auxiliary reference calculation – PID. 				
PC-001	Open loop main reference selection	0	0 ... 11	/	○
	See parameter P0-005 for more information.				
PC-002	Limit selection and auxiliary reference selection	0000	0000 ... 1113	/	○
	<p>Ones position: Auxiliary reference channel selection:</p> <ul style="list-style-type: none"> ● 0: None ● 1: AI1 ● 2: AI2 ● 3: AI3 <p>Tens position: Auxiliary reference maximum limit selection</p> <ul style="list-style-type: none"> ● 0: Auxiliary reference 100% = maximum speed P0-012. ● 1: Auxiliary reference 100% = main reference. <p>Hundreds position: Main reference limit selection</p> <ul style="list-style-type: none"> ● 0: Both positive and negative values are valid. ● 1: Take positive values only. <p>Thousands position: PID output limit selection</p> <ul style="list-style-type: none"> ● 0: PID output upper limit and lower limit (PC-017 and PC-018), 100.00 % = maximum speed P0-012. ● 1: PID output upper limit and lower limit (PC-017 and PC-018), 100.00 % = main reference. 				

Parameter	Name	Default	Range	Unit	Attribute
PC-003	Open loop main reference and auxiliary reference calculation formula	0	0 ... 5	/	○
<p>The main reference value f_m can be added with an auxiliary reference value f_a, and it results process open loop reference f_{com}. Such calculations as “add”, “subtract”, “bias”, “max” and “min” are available for main reference value f_m and auxiliary reference value f_a.</p> <div style="text-align: center;"> </div> <ul style="list-style-type: none"> 0: Main + Auxiliary The auxiliary frequency reference value is superimposed on the main reference, the function is “add”. 1: Main – Auxiliary The auxiliary frequency reference value is superimposed on the main reference, the function is “subtract”. <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div> <ul style="list-style-type: none"> 2: Auxiliary-50% The auxiliary reference value subtracts the bias equal to 50% of the auxiliary reference full range value. The main reference value is disable at this calculation formula. 3: Main + Auxiliary-50% Main reference + auxiliary reference-50%: The auxiliary reference value subtracts the bias equal to 50% of the auxiliary reference full range value and then superimposes on the main reference. <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div> <ul style="list-style-type: none"> 4: Take maximum value Get the maximum value of the main reference f_m and the auxiliary reference f_a. 5: Take minimum value Get the minimum value of the main reference f_m and the auxiliary reference f_a. <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div>					

Parameter	Name	Default	Range	Unit	Attribute
PC-004	PID main reference selection	1	0 ... 3	/	○
	<p>Defines the main reference source selection. The PID reference is defined by main reference, auxiliary reference and calculation.</p> <ul style="list-style-type: none"> ● 0: Parameter setting (PC-010) ● 1: AI1 ● 2: AI2 ● 3: AI3  <pre> graph LR PC004[PC-004 main reference] --> PC006((PC-006)) PC005[PC-005 auxiliary reference] --> PC006 PC006 --> Out[Reference sent to PID controller] </pre>				
PC-005	PID auxiliary reference selection	0	0 ... 3	/	○
	<p>Defines the auxiliary reference source selection.</p> <ul style="list-style-type: none"> ● 0: None ● 1: AI1 ● 2: AI2 ● 3: AI3 				
PC-006	PID main reference and auxiliary reference calculation	0	0 ... 5	/	○
	<ul style="list-style-type: none"> ● 0: Main + Auxiliary. ● 1: Main – Auxiliary. ● 2: Auxiliary–50%. ● 3: Main + Auxiliary–50%. ● 4: Take maximum value. ● 5: Take minimum value. <p>Refer to parameter PC-003 for more selection and calculation information.</p>				
PC-007	PID main feedback selection	2	0 ... 3	/	○
	<p>Defines the main feedback source selection. The PID actual feedback is defined by main feedback, auxiliary feedback and calculation.</p> <ul style="list-style-type: none"> ● 0: None ● 1: AI1 ● 2: AI2 ● 3: AI3  <pre> graph LR PC007[PC-007 main feedback] --> PC009((PC-009)) PC008[PC-008 auxiliary feedback] --> PC009 PC009 --> Out[Actual feedback sent to PID controller] </pre>				
PC-008	PID auxiliary feedback selection	0	0 ... 3	/	○
	<p>Defines the feedback reference source selection.</p> <ul style="list-style-type: none"> ● 0: None ● 1: AI1 ● 2: AI2 ● 3: AI3 				
PC-009	PID main feedback and auxiliary feedback calculation	0	0 ... 5	/	○
	<ul style="list-style-type: none"> ● 0: Main + Auxiliary. ● 1: Main – Auxiliary. ● 2: Auxiliary–50%. ● 3: Main + Auxiliary–50%. ● 4: Take maximum value. ● 5: Take minimum value. <p>Refer to parameter PC-003 for more selection and calculation information.</p>				

Parameter	Name	Default	Range	Unit	Attribute														
PC-010	PID reference	20.00	-100.00 ... 100.00	%	○														
	Defines the PID reference value when PC-004 = 0. 100.00% = 100.00% feedback value.																		
PC-011	Proportional gain P1	10.00	0.00 ... 655.35	/	○														
	<p>As shown in the PID schematic block diagram, the proportional gain part output of PID $P_{out} = K_p * \epsilon$.</p> <div></div> <p>ϵ refers to this time error ϵ' refers to previous time error</p> <p>Assuming that the error is 30% and the maximum speed is 1500rpm, the following table lists the relationship between K_p output and error.</p> <table><thead><tr><th>PID Gain</th><th>Gain part output P_{out}</th><th>Calculation process</th></tr></thead><tbody><tr><td>1.0(Default)</td><td>450 rpm</td><td>$1.0 * 1500 * 30\%$</td></tr><tr><td>0.5</td><td>225 rpm</td><td>$0.5 * 1500 * 30\%$</td></tr><tr><td>2.0</td><td>900 rpm</td><td>$2.0 * 1500 * 30\%$</td></tr><tr><td>20.0</td><td>1500(Max speed)</td><td>$20.0 * 1500 * 30\%$</td></tr></tbody></table> <p>The Gain part is to react and adjust the error immediately in proportion. The larger the gain K_p, the stronger the adjustment effect. However, excessive adjustment is easy to cause output oscillation, and K_p cannot eliminate the error.</p>					PID Gain	Gain part output P_{out}	Calculation process	1.0(Default)	450 rpm	$1.0 * 1500 * 30\%$	0.5	225 rpm	$0.5 * 1500 * 30\%$	2.0	900 rpm	$2.0 * 1500 * 30\%$	20.0	1500(Max speed)
PID Gain	Gain part output P_{out}	Calculation process																	
1.0(Default)	450 rpm	$1.0 * 1500 * 30\%$																	
0.5	225 rpm	$0.5 * 1500 * 30\%$																	
2.0	900 rpm	$2.0 * 1500 * 30\%$																	
20.0	1500(Max speed)	$20.0 * 1500 * 30\%$																	
PC-012	Integration time I1	5.00	0.00 ... 655.35	s	○														
	<p>The integration part output of PID $I_{out} = K_p * 1/T_i * \sum \epsilon$.</p> <p>The integration time defines the rate at which the PID controller output changes when the error value is constant. The shorter the integration time, the faster the continuous error value is corrected. Too short an integration time makes the control unstable.</p>																		
PC-013	Derivative time D1	0.00	0.00 ... 655.35	s	○														
	<p>The derivation part output of PID $D_{out} = T_d * (\epsilon - \epsilon')$.</p> <p>Derivative action boosts the PID controller output if the error value changes. The longer the derivation time, the more the PID controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances.</p>																		
PC-014	Sampling time	1	1 ... 65535	2ms	○														
	<p>Defines the sampling time of the feedback signal. The lower the value is, the faster system response to the deviation between the reference and the feedback, but if the sampling time is too fast, the associate requirement for the system PID regulation will be higher, which may result in system vibration.</p>																		

Parameter	Name	Default	Range	Unit	Attribute
PC-015	PID deviation limit	0.10	0.00 ... 655.35	%	○
	Defines a certain deviation between the feedback and the reference to stop the internal PID regulation and maintain stable output. Only when the deviation between the feedback and the reference exceeds the deviation limit of PC-015, the output will be updated. Setting the deviation limit needs to take the system control precision and stability into consideration.				
PC-016	PID adjustment polarity selection	0	0 ... 1	/	×
	<ul style="list-style-type: none"> ● 0: Positive polarity When the PID feedback is higher than the PID reference, decrease the PID output. ● 1: Negative polarity When the PID feedback is higher than the PID reference, increase the PID output. 				
PC-017	PID output upper limit	100.00	PC-018 ... 100.00	%	○
	Defines the PID output upper limit. When thousands position of PC-002 is 0, the PID output upper limit is limited to PC-017* maximum speed P0-012. When thousands position of PC-002 is 1, the PID output upper limit is limited to PC-017* main reference.				
PC-018	PID output lower limit	0.00	-100.00 ... PC-017	%	○
	Defines the PID output lower limit. When thousands position of PC-002 is 0, the PID output lower limit is limited to PC-017* maximum speed P0-012. When thousands position of PC-002 is 1, the PID output lower limit is limited to PC-017* main reference.				
PC-019	PID feedback disconnection detection threshold	0.00	0.00 ... 100.00	%	○
PC-020	PID feedback disconnection detection time	0.0	0.0 ... 6553.5	s	○
	<ul style="list-style-type: none"> ● PC-019 = 0.00: PID feedback disconnection detection is disabled. ● PC-019 = 0.01...100.00: PID feedback disconnection detection is enabled. When PC-019 is a non-zero value, when the PID feedback is lower than the value of PC-019 for the detection time defined by parameter PC-020. The drive trips on a fault. 				
PC-021	PID adjustment selection	0	000 ... 111	/	×
	Ones position: Integration pause through digital input. <ul style="list-style-type: none"> ● 0: Invalid ● 1: Valid Tens position: Integration stop when the output reaches the limit value <ul style="list-style-type: none"> ● 0: Stop ● 1: Do not stop Hundreds position: PID output change to FWD / REV direction <ul style="list-style-type: none"> ● 0: Not allowed ● 1: Allowed 				
PC-022	PID reference feedback range	1000	1 ... 65535	/	×
	The parameter of PID reference feedback range is used for PID reference display and PID feedback display. 100.00% of the reference and feedback = PID reference feedback range (PC-022).				
PC-023	Differential limitation	5.00	0.00 ... 100.00	%	○
	In PID regulators, differential action is relatively sensitive and prone to system oscillation. This parameter limits the differential value to PC-023.				

Parameter	Name	Default	Range	Unit	Attribute
PC-024	PID reference change time	0.00	0.00 ... 655.35	s	○
	Defines the time required for the PID reference value change from 0.0% to 100.0% (PID reference ramp time). When a reference PID value changes, the reference does not immediately respond, but changes linearly according to the time (PC-024) to prevent the reference sudden changes.				
PC-025	PID feedback filter time	0.00	0.00 ... 655.35	s	○
	Defines the filter time constant for PID feedback, which can reduce the influence of interference signals on the PID feedback.				
PC-026	PID output filter time	0.00	0.00 ... 655.35	s	○
	Defines the filter time constant for PID output.				
PC-027	Proportional gain P2	20.00	0.00 ... 655.35	/	○
PC-028	Integration time I2	1.00	0.00 ... 655.35	s	○
PC-029	Derivative time D2	0.00	0.00 ... 655.35	s	○
PC-030	PID parameter switching condition	0	0 ... 2	/	○
PC-031	PID parameter switching deviation 1	20.00	0.00 ... 100.00	%	○
PC-032	PID parameter switching deviation 2	80.00	0.00 ... 100.00	%	○
<p>In some applications, a group of PID parameters (Proportional gain, Integration time, Derivative time) cannot meet the entire process control requirements. The parameters PC-027 to PC-029 are the second PID parameters for PID control. Selects the first group PID parameters (PC-011...PC-013) or the second group PID parameters (PC-027...PC-029) is defined by parameter PC-030.</p> <ul style="list-style-type: none"> ● PC-030 = 0: Not select. The first group PID parameters (PC-011...PC-013) are effective. ● PC-030 = 1: Digital input When a digital input terminal function is set to [25]: <ul style="list-style-type: none"> ① When the digital input = 0: The first group PID parameters (PC-011...PC-013) are effective. ② When the digital input = 1: The second group PID parameters (PC-027...PC-029) are effective. ● PC-030 = 2: According the deviation PID deviation (PID error) = abs (PID reference – PID feedback). <ul style="list-style-type: none"> ① If PID deviation < PC-031, the first group PID parameters (PC-011...PC-013) are effective. ② If PID deviation > PC-032, the second group PID parameters (PC-027...PC-029) are effective. ③ PC-031 < PID deviation < PC-032, the PID parameter for PID controller changes linearly according to the first group and the second group PID parameters. 					
					
PC-033	PID initial value	0.00	0.00 ... 100.00	%	○

Parameter	Name	Default	Range	Unit	Attribute
PC-034	PID initial value hold time	0.00	0.00 ... 655.35	s	○
When receive a start signal when the speed reference is PID, the speed first operates at a constant speed (defined by parameter PC-033) for the time defined by parameter PC-034, then enter to the normal PID adjustment process.					
PC-035	Output deviation FWD max. value	20.00	0.01 ... 100.00	%	○
PC-036	Output deviation REV max. value	20.00	0.01 ... 100.00	%	○
PC-035 is used to define the PID maximum output deviation within 4ms for forward direction. PC036 is used to define the PID maximum output deviation within 4ms for reverse direction.					
PC-037	PID operation in stop status	0	0 ... 1	/	×
	<ul style="list-style-type: none"> ● 0: PID continue calculation in stop status. ● 1: PID stop calculation in stop status. 				
PC-038	PID feedback out of range value	100.00	50.00 ... 100.00	%	○
PC-039	PID feedback out of range detection time	0	0 ... 65535	s	○
If the PID feedback value is higher than the value defined by PC-038 for the time defined by PC-039, the drive will trips on a fault "PID feedback out of range". Note: When PC-039 = 0, PID feedback out of range detection is disabled.					
PC-040	PID switching speed	0.00	0.00 ... 100.00	%	○
	<p>This function is available for some applications when the process PID may not meet requirements and it is necessary to change to a constant speed by a digital input. When the digital input function is set to [26]:</p> <p>When the digital input = 1, the speed reference is changed to a constant speed (PC-040).</p> <p>When the digital input = 0, the speed reference is changed to PID regulation.</p> <p>100.00% corresponds to maximum speed P0-012.</p>				

5.14 Encoder Parameters (A0)

Parameter	Name	Default	Range	Unit	Attribute
A0-000	Encoder type selection	2	0 ... 2	/	×
	<p>Selects the encoder type when a speed feedback signal (encoder or resolver) from the motor.</p> <ul style="list-style-type: none"> ● 0: Resolver Resolver is used as motor speed feedback. The default ratio of resolver is about 0.5. If the ratio is about 0.25, please specify it when ordering. The resolver pole pairs must be divisible by motor pole pairs. For example. If motor pole pairs is 6, then the resolver pole pairs can be 1, 2, 3 and 6, cannot select other pole pairs resolver. ● 1: Reserved ● 2: Incremental encoder Incremental encoder is used as motor speed feedback. Support open collector, voltage type, push pull (complementary) type HTL and differential type TTL encoder. 				
A0-001	Speed feedback filter coefficient	20	1 ... 500	/	×
	Defines the speed feedback signal filtering time constant.				
A0-002	Encoder 1 pulses per revolution	1024	1 ... 65535	ppr	×
A0-003	Encoder 1 direction	0	0 ... 1	/	×
A0-004	Encoder 1 electronic gear ratio numerator	1	1 ... 65535	/	×
A0-005	Encoder 1 electronic gear ratio denominator	1	1 ... 65535	/	×
<p>A0-002 is used to define the encoder PPR when A0-000 = 2. The value should read the correct value from the encoder.</p> <p>A0-003 is the encoder direction; This value can be obtained by motor parameters rotate auto tune. If cannot start motor parameter rotate auto tune (P6-017), this parameter can be changed manually.</p> <p>A0-004 and A0-005 are used to define the ratio between motor shaft and encoder.</p> <p>Note: Parameters A0-002 ... A0-005 are only available for incremental encoder.</p>					
A0-006	Resolver pole pairs	1	1 ... 65535	/	×
	Defines the number of pole pairs of the resolver. The resolver pole pairs must be divisible by motor pole pairs. For example. If the pole pairs of motor is 6, then the pole pairs of resolver can be 1, 2, 3 and 6, cannot select other pole pairs resolver.				
A0-007	SinCos signal alarm value	10000	0 ... 65535	/	×
	<p>When the measured sine / cosine signal (F0-075) is lower than the alarm value (A0-007), the drive trips on a fault "E-dL1".</p> <p>When a resolver is used as motor speed feedback, see the value of F0-075 to check if the resolver is properly installed or correct wiring. When the resolver installation is not good, it will cause the value of parameter F0-075 too low, may cause the drive trips on a fault.</p>				
A0-008	Reserved	0	0 ... 1	/	×
A0-009	Incremental encoder start mode	0	0 ... 1	/	×
	<ul style="list-style-type: none"> ● 0: Open loop start ● 1: Start with initial position identification 				

A0-010	SinCos compensation coefficient	4000	4000 ... 12000	/	×															
	Defines sine and cosine signal compensation coefficient.																			
A0-011	Synchronous motor initial angle	0	0 ... 65535	/	×															
	Synchronous motor initial angle is obtained after synchronous motor rotate auto tune.																			
A0-012	Sine signal zero offset	0	-32768 ... 32767	/	×															
	Synchronous motor sine signal zero offset is obtained after synchronous motor rotate auto tune.																			
A0-013	Cosine signal zero offset	0	-32768 ... 32767	/	×															
	Synchronous motor cosine signal zero offset is obtained after synchronous motor rotate auto tune.																			
A0-014	Sine cosine signal amplitude correction	16384	0 ... 65535	/	×															
	When the sine and cosine signal amplitude received deviates significantly from the ideal value, this parameter can be modified. Generally, it is not necessary to change this parameter. In special cases, please contact the manufacturer.																			
A0-015	Resolver excitation amplitude coefficient	6999	3499 ... 8399	/	×															
	When the amplitude deviation of the excitation signal of the resolver is large, this parameter can be modified for correction, generally it is not necessary to modify it.																			
A0-016 ... A0-021	Reserved	0	-32768 ... 32767	/	×															
A0-022	PM motor incremental encoder find Z signal frequency	1.0	0.1 ... 5.0	/	×															
	PM motor incremental encoder find Z signal frequency.																			
A0-023	Encoder input filter setting	0007	0000 ... 0FFF	/	×															
	<p>The value of this parameter is displayed as a hexadecimal number and the actual function is used in binary.</p> <ul style="list-style-type: none">● Ones position: Filtering of B signal The sampling frequency of input TI1 and the digital filter bandwidth applicable to TI1 can be defined. The digital filter consists of event counters, and every N events are considered a valid edge. <table><tr><td>0000: No filter, sampling at fDTS</td><td>1000: fSAMPLING=fDTS/8, N=6</td></tr><tr><td>0001: fSAMPLING=fCK_INT, N=2</td><td>1001: fSAMPLING=fDTS/8, N=8</td></tr><tr><td>0010: fSAMPLING=fCK_INT, N=4</td><td>1010: fSAMPLING=fDTS/16, N=5</td></tr><tr><td>0011: fSAMPLING=fCK_INT, N=8</td><td>1011: fSAMPLING=fDTS/16, N=6</td></tr><tr><td>0100: fSAMPLING=fDTS/2, N=6</td><td>1100: fSAMPLING=fDTS/16, N=8</td></tr><tr><td>0101: fSAMPLING=fDTS/2, N=8</td><td>1101: fSAMPLING=fDTS/32, N=5</td></tr><tr><td>0110: fSAMPLING=fDTS/4, N=6</td><td>1110: fSAMPLING=fDTS/32, N=6</td></tr><tr><td>0111: fSAMPLING=fDTS/4, N=8</td><td>1111: fSAMPLING=fDTS/32, N=8</td></tr></table>● Tens position: Filtering of A signal See selection “Ones position”.● Hundreds position: Filtering of Z signal See selection “Ones position”.					0000: No filter, sampling at fDTS	1000: fSAMPLING=fDTS/8, N=6	0001: fSAMPLING=fCK_INT, N=2	1001: fSAMPLING=fDTS/8, N=8	0010: fSAMPLING=fCK_INT, N=4	1010: fSAMPLING=fDTS/16, N=5	0011: fSAMPLING=fCK_INT, N=8	1011: fSAMPLING=fDTS/16, N=6	0100: fSAMPLING=fDTS/2, N=6	1100: fSAMPLING=fDTS/16, N=8	0101: fSAMPLING=fDTS/2, N=8	1101: fSAMPLING=fDTS/32, N=5	0110: fSAMPLING=fDTS/4, N=6	1110: fSAMPLING=fDTS/32, N=6	0111: fSAMPLING=fDTS/4, N=8
0000: No filter, sampling at fDTS	1000: fSAMPLING=fDTS/8, N=6																			
0001: fSAMPLING=fCK_INT, N=2	1001: fSAMPLING=fDTS/8, N=8																			
0010: fSAMPLING=fCK_INT, N=4	1010: fSAMPLING=fDTS/16, N=5																			
0011: fSAMPLING=fCK_INT, N=8	1011: fSAMPLING=fDTS/16, N=6																			
0100: fSAMPLING=fDTS/2, N=6	1100: fSAMPLING=fDTS/16, N=8																			
0101: fSAMPLING=fDTS/2, N=8	1101: fSAMPLING=fDTS/32, N=5																			
0110: fSAMPLING=fDTS/4, N=6	1110: fSAMPLING=fDTS/32, N=6																			
0111: fSAMPLING=fDTS/4, N=8	1111: fSAMPLING=fDTS/32, N=8																			
A0-024	SinCos encoder decoding switch enable	0	0 ... 1	/	×															
	<ul style="list-style-type: none">● 0: Not switch● 1: Switch																			

5.15 Position Controller (B0)

Parameter	Name	Default	Range	Unit	Attribute
B0-000	Position loop encoder selection	0	0 ... 1	/	×
	<ul style="list-style-type: none"> ● 0: Encoder 1 (Motor shaft) The first encoder refers to the motor shaft encoder selected by parameter A0-000. ● 1: Reserved. 				
B0-001	Position loop reference selection	0	0 ... 1	/	×
	<ul style="list-style-type: none"> ● 0: Pulse input ● 1: Reserved. 				
B0-002	Position loop gain P 1	5.0	0.0 ... 6553.5	1/s	○
<p>Position loop gain directly influences the response level of the position loop. If the mechanical system does not vibrate or produce noises, you can increase the value of position loop gain so that the response level can be increased and positioning time can be shortened.</p> <p>Two position loop gains in total are available.</p> <ul style="list-style-type: none"> ● When B0-033 = 0, only position loop gain B0-002 is effective. ● When B0-033 = 1, position loop gain is defined by parameters B0-002, B0-034, B0-035 and B0-036. <div style="text-align: center;"> </div>					
B0-003	Position loop maximum speed	1500	0 ... 65535	rpm	×
	Defines the maximum output speed when working in the position control mode. When the speed reference is higher than the value of B0-003, the actual speed will be limited to the value of B0-003.				
B0-004	Position loop acceleration time	0.00	0.00 ... 655.35	s	×
B0-005	Position loop deceleration time	0.00	0.00 ... 655.35	s	×
<p>The position loop acceleration time is the time from zero speed accelerate to the position loop maximum speed when working in the position control mode.</p> <p>The position loop deceleration time is the time from position loop maximum speed decelerate to zero speed when working in the position control mode.</p>					

Parameter	Name	Default	Range	Unit	Attribute
B0-006	Position loop gear ratio numerator 1	1	1 ... 65535	/	×
B0-007	Position loop gear ratio denominator 1	1	1 ... 65535	/	×

The parameters B0-007 and B0-008 are used to define the pulse input gear ratio in position loop (P0-003).

Let **B** represents the pulse input frequency multiplier.

When pulse input type is AB phase, then **B** = 4.

When pulse input type is pulse + direction (or direction + pulse), then **B** = 2.

When pulse input type is single-phase pulse, then **B** = 1.

Let **n** represents motor speed.

Let **N** represents motor number of rotations.

Let **C** represents motor encoder pulse per revolution (for incremental encoder).

Let **F** represents input pulses frequency.

Let **P** represents input pulses.

Let **G** represents gear ratio.

● **When the speed feedback signal is incremental encoder(defined by parameter A0-000)**

The relationship between the speed and input pulses:

$$n = B \times 60 \times F \times G / (C \times 4) \quad \& \quad G1 = B0-006:B0-007$$

Example: the pulse input is 50KHz from host controller, the motor encoder PPR is 2500:

$$n = B \times 60 \times F \times G / (C \times 4) = B \times 60 \times 50000 \times G / (2500 \times 4)$$

$$\text{When } B0-006:B0-007=1:2, n = B \times 60 \times 50000 \times 0.5 / (2500 \times 4) (\text{ppr})$$

The relationship between the position and input pulses:

$$B \times P \times G = N \times C \times 4$$

Example: AB phase input pulses is 10000, require to rotate the motor for 2 revolutions and the motor encoder PPR is 2500: **N=2, C=2500, P=10000.**

$$G = N \times C \times 4 / (B \times P) = 2 \times 2500 \times 4 / (B \times 10000) = 20000 / 40000 = 1/2$$

Then: **B0-006 = 1 and B0-007 = 2.**

● **When the speed feedback signal is resolver (defined by parameter A0-000)**

The relationship between the speed and input pulses:

$$n = B \times 60 \times F \times G / 65536 \quad \text{and} \quad G = B0-006/B0-007$$

Example: input pulses is 10000, require to rotate the motor for 2 revolutions and the motor encoder is resolver, then:

$$n = B \times 60 \times F \times G1 / 65536 = B \times 60 \times 50000 \times G1 / 65536$$

$$\text{when } G = B0-006:B0-007=4:1$$

$$\text{Then } n = 1 \times 60 \times 50000 \times 4 / 65536 \text{ PPR}$$

The relationship between the position and input pulses:

$$B \times P \times G = N \times 65536$$

Example: input pulses is 10000, require to rotate the motor for 2 revolutions and the motor encoder is resolver, then: **N=2, P=10000**

$$G = N \times 65536 / (B \times P) = 2 \times 65536 / (B \times 10000)$$

$$\text{Then } G = B0-006:B0-007 = 8192:625$$

Parameter	Name	Default	Range	Unit	Attribute
B0-008	Position loop feed forward gain	0.00	0.00 ... 200.00	%	○
B0-009	Position loop feed forward filter time	0.000	0.000 ... 2.000	s	○
With position loop feed forward gain, the responsiveness level can be increased. If the position loop feed forward gain is too big, motor speed can have overshoots. You can slowly adjust the position loop feed forward gain. The effect of feed forward function is not obvious if the position loop gain is too big.					
B0-010	Position reference filter	0	0 ... 65535	/	×
	Defines the filter time constant of position reference. If filter constant setting too big will reduces the position dynamic response, but will not cause a loss of pulses.				
B0-011	Position reach detect width	50	0 ... 65535	pulse	○
	When the deviation between the actual position and the reference position is less than value of parameter B0-011 (Position reach detect width) and continues to reach the set time of B0-029 (Position reach detect time), the position reach signal output is ON.				
B0-012	Speed feed forward gain in position control	0.00	0.00 ... 250.00	%	○
B0-013	Speed feed forward filter time in position control	0.00	0.00 ... 100.00	s	○
Parameter B0-012 is used to define the feed forward gain of speed control in position loop. Parameter B0-013 is used to define the feed forward filter time of speed control in position loop.					
B0-014	Digital input switch to position loop with enable signal	0	0 ... 1	/	×
	Selects digital input switch to position loop whether with enable signal. For example, digital input X3 is used to switch to position loop from speed loop, set P3-003 = 8. <ul style="list-style-type: none"> ● 0: Without enabled signal. ● 1: With enabled signal. 				
B0-015	Switching mode from speed loop to position loop	0	0 ... 1	/	○
	Defines the switching mode from speed loop to position loop. <ul style="list-style-type: none"> ● 0: Switch to position loop at the speed defined by parameter P3-028. In speed loop mode, when the drive receives a command of switching to position loop, the drive will switch to position loop after the speed is decelerated to the value defined by parameter P3-028. ● 1: Switch to position loop directly. In speed loop mode, the drive switch to position loop directly after receives a command of switch to position loop. 				
B0-016	Orientation position references 1	0	0 ... 65535	pulse	○
	Defines the orientation position references, see parameter B0-028 for more information.				
B0-017	Orientation start speed	300	0 ... 65535	rpm	○
	<ul style="list-style-type: none"> ● 0: Direct orientation, orientating from current speed If the actual speed is lower than the value of B0-003, orientating from current speed. If the actual speed is higher than the value of B0-003, decelerate to the value of B0-003 before start the orientation. ● 1...65535: Orientation start speed. If the actual speed is lower than the value of B0-017, orientating from current speed. If the actual 				








Parameter	Name	Default	Range	Unit	Attribute																																				
	speed is higher than the value of B0-017, decelerate to the value of B0-017 before start the orientation.																																								
B0-018	Orientation deceleration time	2.00	0.00 ... 655.35	s	○																																				
	The time from position loop maximum speed (B0-003) to 0 during orientating process.																																								
B0-019	Orientation gain	5.0	0.0 ... 6553.5	/	○																																				
	Orientation gain directly influences the response level when orientating. If the mechanical system does not vibrate or produce noises, you can increase the gain so that the system rigidity can be increased.																																								
B0-020	Direct orientation enable speed	500	0 ... 1500	rpm	○																																				
	If a motor running speed is lower than the value of B0-020, the direct orientation function is enabled and allow shortest distance orientating. Note: When parameter B0-020 setting too high, there may be overshoot and shock due to the planned distance too short.																																								
B0-021	Orientation direction	0	0 ... 2	/	○																																				
	<ul style="list-style-type: none">● 0: Motor running rotation● 1: Forward● 2: Reverse																																								
B0-022	Orientation position references 2	0	0 ... 65535	pulse	○																																				
B0-023	Orientation position references 3	0	0 ... 65535	pulse	○																																				
B0-024	Orientation position references 4	0	0 ... 65535	pulse	○																																				
B0-025	Orientation position references 5	0	0 ... 65535	pulse	○																																				
B0-026	Orientation position references 6	0	0 ... 65535	pulse	○																																				
B0-027	Orientation position references 7	0	0 ... 65535	pulse	○																																				
B0-028	Orientation position references 8	0	0 ... 65535	pulse	○																																				
It is possible to predefine 8 orientation position reference and selected by digital inputs. For example, X3, X4 and X3 are used to select the predefine reference, set P3-003 = 35, P3-004 = 36, P3-005 = 37, then:																																									
<table><tr><th>Orientation position reference</th><th>X5</th><th>X4</th><th>X3</th></tr><tr><td>Orientation position references 1 (B0-016)</td><td>0</td><td>0</td><td>0</td></tr><tr><td>Orientation position references 2 (B0-022)</td><td>0</td><td>0</td><td>1</td></tr><tr><td>Orientation position references 3 (B0-023)</td><td>0</td><td>1</td><td>0</td></tr><tr><td>Orientation position references 4 (B0-024)</td><td>0</td><td>1</td><td>1</td></tr><tr><td>Orientation position references 5 (B0-025)</td><td>1</td><td>0</td><td>0</td></tr><tr><td>Orientation position references 6 (B0-026)</td><td>1</td><td>0</td><td>1</td></tr><tr><td>Orientation position references 7 (B0-027)</td><td>1</td><td>1</td><td>0</td></tr><tr><td>Orientation position references 8 (B0-028)</td><td>1</td><td>1</td><td>1</td></tr></table>						Orientation position reference	X5	X4	X3	Orientation position references 1 (B0-016)	0	0	0	Orientation position references 2 (B0-022)	0	0	1	Orientation position references 3 (B0-023)	0	1	0	Orientation position references 4 (B0-024)	0	1	1	Orientation position references 5 (B0-025)	1	0	0	Orientation position references 6 (B0-026)	1	0	1	Orientation position references 7 (B0-027)	1	1	0	Orientation position references 8 (B0-028)	1	1	1
Orientation position reference	X5	X4	X3																																						
Orientation position references 1 (B0-016)	0	0	0																																						
Orientation position references 2 (B0-022)	0	0	1																																						
Orientation position references 3 (B0-023)	0	1	0																																						
Orientation position references 4 (B0-024)	0	1	1																																						
Orientation position references 5 (B0-025)	1	0	0																																						
Orientation position references 6 (B0-026)	1	0	1																																						
Orientation position references 7 (B0-027)	1	1	0																																						
Orientation position references 8 (B0-028)	1	1	1																																						
Note: The encoder PPR limits the range of B-016, B-022 ... B-028.																																									
B0-029	Position reach detection time	1	0 ... 65535	ms	×																																				
	When the deviation between the actual position and the reference position is less than B-011 (Position																																								

Parameter	Name	Default	Range	Unit	Attribute
	reach detection width) and continues to reach the set time of B-029 (Position reach detection time), the position reach signal output is ON.				
B0-030 ... B0-032	Reserved	5	1 ... 65535	/	○
B0-033	Position loop gain switching mode	0	0...1	/	×
B0-034	Position loop gain P 2	5.0	0.0 ... 6553.5	/	○
B0-035	Position loop gain switching deviation 1	0	1 ... 65535	/	×
B0-036	Position loop gain switching deviation 2	0	1 ... 65535	/	×
Position loop gain 2 can be defined and active by parameters B0-033 ... B0-036, refer to B0-002 for more information.					
B0-037	Auto switch encoder	0	0 ... 1		
	● 0 ... 1: Reserved.				
B0-038	Total pulses high order byte of simple positioning	0	0...65535	/	○
B0-039	Total pulses lower order byte of simple positioning	0	0...65535	/	○
	<p>Defines the total pulses high order byte. The relationship between the total pulses and the value of B0-038 and B0-039 is as follows:</p> $\text{Total pulses} = (\text{B0-038} \ll 16) + \text{B0-039}.$ <p>When speed reference source is [12] (P0-005 = 12), the speed reference is defined by parameters B0-038...B0-046, use this function to achieve simple positioning function under speed loop. The speed reference is defined by the total pulses (B0-038 and B0-039), the executed pulses (B0-040 and B0-041), the stop pulses (B0-042 and B0-043), the speed reference 1(P1-005) and speed reference 2 (P1-006). The actual speed reference is shown in the following figure:</p> <p>定长总脉冲数 Total pulses: $((\text{B0-038}) \ll 16) + (\text{B0-039})$ 停机位置 Stop pulses: $((\text{B0-042}) \ll 16) + (\text{B0-043})$ 第二段速切换位置 Pulses for speed reference 2 switching: $((\text{B0-040}) \ll 16) + (\text{B0-041})$</p> <p>第一段速 Speed reference 1 (P1-005) 第二段速 Speed reference 2 (P1-006)</p> <p>第一段速 Speed reference 1 (P1-005) 第二段速 Speed reference 2 (P1-006)</p> <p>B0-045的十位: 0: 不切位置环 1: 切位置环 Tens position of B0-045 = 0: Not switch to position loop at zero speed. = 1: Switch to position loop at zero speed.</p>				
B0-040	Executed pulses high order byte of speed reference 2	0	0...65535	/	○
B0-041	Executed pulses low order byte of speed reference 2	0	0...65535	/	○

Parameter	Name	Default	Range	Unit	Attribute
When executed pulses reaches the pulses defined by parameters B0-046 and B0-041, the speed reference change to speed reference 2. Executed pulse of speed reference 2 = (B0-040<<<16)+B0-041					
B0-042	Stop pulses high order byte	0	0...65535	/	○
B0-043	Stop pulses lower order byte	0	0...65535	/	○
The stop pulses is defined by the value of B0-042 and B0-043 is as follows: Stop pulses = (B0-042<<<16)+B0-043					
B0-044	Pulse reference source				
<ul style="list-style-type: none"> 0: Pulse input. 1: The first encoder. 2: The second encoder. 					
B0-045	Simple positioning control function	0000	0000...0011	/	×
Ones position: Automatically adjust the stop pulses <ul style="list-style-type: none"> 0: Stop pulses not automatically adjusted. 1: Stop pulses automatically adjusted. Tens position: zero speed switching position loop <ul style="list-style-type: none"> 0: No automatic switch to position loop at zero speed. 1: Automatic switch to position loop at zero speed. 					
B0-046	Simple positioning arrive delay time	1	1...65534	s	×
Reserved.					
B0-047	Initial position 0	0000	0000...FFFF	/	○
B0-048	Initial position 1	0000	0000 ... FFFF	/	○
B0-049	Initial position 2	0000	0000 ... FFFF	/	○
B0-050	Initial position 3	0000	0000 ... FFFF	/	○
B0-047 ... B0-050 are used to set the feed initial position, representing bit63 ... bit48, bit47 ... bit32, bit31 ... bit16, and bit15 ... bit0, respectively. The specific calculation formula is as follows: Feed initial position=(B0-047<<48)+(B0-048<<32)+(B0-049<<16)+(B0-050) When running to the initial position, when a rising edge from a digital input (set the digital input terminal function to 42) comes, it triggers the acquisition of the current position and automatically save the position values to the parameters B0-047 ... B0-050.					
B0-051	Feed number of rotations	0000	0000 ... 65535	/	○
B0-052	Feed number of pulses	0000	0000 ... 65535	/	○
The parameter B0-051 and B0-052 define the feed number of rotations and pulses. The relationship is as follows: Feed number of pulses for single cycle feed = (B0-051) * motor encoder PPR + (B0-052)					
B0-053	Feed direction	0	0 ... 1	/	
<ul style="list-style-type: none"> 0: Forward 1: Reverse 					
B0-054	Forward feed to reverse delay time	0.0	0.0 ... 6553.5	s	
Defines the delay time from forward feed completed to reverse, as shown in the following figure:					

Parameter	Name	Default	Range	Unit	Attribute
B0-055	Feed control word maintain	0000	0000 ... 0001		
	<ul style="list-style-type: none"> ● 0: Not maintain at stop state Not maintain current feed control word after stop. ● 1: Maintain at stop state Maintain current feed control word during stop state. 				
B0-056 ... B0-059	Reserved	0	0 ... 65535	/	○

5.16 Pulse Input and Output (B1)

Parameter	Name	Default	Range	Unit	Attribute	
B1-000	Pulse input mode	0	0 ... 2	/	×	
	Selects pulse input mode from the host controller.					
	Pulse input mode	正转 Forward running	反转 Reverse running			
	AB正交脉冲 Quadrature pulse AB phase	A 	A 			
	A脉冲+B方向 A pulse + B direction	A 	A 			
	B脉冲+A方向 B pulse + A direction	B 	B 			
	单路脉冲 Single phase	A 				
	<ul style="list-style-type: none">● 0: Quadrature pulse Quadrature pulse input from X6 and X7 digital input terminal.● 1: A pulse + B direction X7 is used as pulse input, X6 is used as direction input.● 2: B pulse + A direction Not support.● 3. Single-phase pulse X7 is used as pulse input.					
	Note: Since digital input X6 and X7 default are used as digital inputs do not have pulse input function, if X6 and X7 are required as pulse input functions, please confirm with the manufacturer before ordering.					
	B1-001	Pulse input direction invert	0	0 ... 1	/	×
Selects the inversion of the pulse input. 0: OFF 1: ON						

B1-002	Speed control pulse input gear ratio numerator	1	1 ... 65535	/	○
B1-003	Speed control pulse input gear ratio denominator	1	1 ... 65535	/	○
<p>B1-002 and B1-003 are used to define the pulse input gear ratio in speed control mode.</p> <p>Let B represents the pulse input frequency multiplier.</p> <p>When pulse input type is AB phase (B1-000 = 0), then B = 4.</p> <p>When pulse input type is pulse + direction (or direction + pulse) (B1-000 = 1/2), then B = 2.</p> <p>When pulse input type is single-phase pulse (B1-000 = 3), then B = 1.</p> <p>Let n represents motor speed.</p> <p>Let C represents motor encoder pulse per revolution (for incremental encoder).</p> <p>Let F represents pulse input frequency.</p> <p>Let G₁ represents gear ratio.</p> <ul style="list-style-type: none"> • When motor speed feedback is incremental encoder (defined by parameter A0-000) $n = B \times 60 \times F \times G_1 / (C \times 4) \quad \& \quad G_1 = B1-002:B1-003$ <p>For example: the pulse input is 50Khz from host controller, the motor encoder PPR is 2500, then:</p> $n = B \times 60 \times F \times G_1 / (C \times 4) = B \times 60 \times 50000 \times G_1 / (2500 \times 4)$ <p>When B1-002:B1-003=2:1, $n = B \times 60 \times 50000 \times 2 / (2500 \times 4)$ (ppr)</p> • When motor speed feedback is resolver or SinCos encoder (defined by parameter A0-000) $n = B \times 60 \times F \times G_1 / 65536 \quad \& \quad G_1 = B1-002:B1-003$ <p>For example: the pulse input is 50Khz from host controller, the motor encoder is resolver, then</p> $n = B \times 60 \times F \times G_1 / 65536 = B \times 60 \times 50000 \times G_1 / 65536$ <p>when B1-002:B1-003=2:1, $n = B \times 60 \times 50000 \times 2 / 65536$ (ppr)</p> • When the motor control without encoder (defined by parameter P0-002) $n = B \times 60 \times F \times G_1 / 1000 \quad \& \quad G_1 = B1-002:B1-003$ 					
B1-004	Speed control pulse input filter	10	0 ... 65535	/	○
	<p>Defines the pulse input filter constant. Higher filter will make the input smoother, but will increase response time. Lower filter will make the response faster, but may cause speed instability.</p>				
B1-005	Encoder output pulses per revolution	1024	4 ... 65535	ppr	×
B1-006	Reserved	0	0 ... 65535	/	×
B1-007	Encoder selection for output	0	0 ... 1	/	×
	<p>Defines which encoder is used for output</p> <ul style="list-style-type: none"> • 0: Encoder 1 (Motor shaft) • 1: Encoder 2 (Spindle shaft) 				
B1-008	Pulse input filter configuration	0	0 ... 002F	/	×
	<p>Defines the sampling frequency of TI1 and the bandwidth of the digital filter applicable to TI1. The digital filter is composed of an event counter, and every N event are regarded as a valid edge.</p> <p>0000: No filter, sampling according to f_{DTS} frequency</p> <p>0001: $f_{SAMPLING} = f_{CK_INT}$, N=2 0010: $f_{SAMPLING} = f_{CK_INT}$, N=4 0011: $f_{SAMPLING} = f_{CK_INT}$, N=8</p> <p>0100: $f_{SAMPLING} = f_{DTS}/2$, N=6 0101: $f_{SAMPLING} = f_{DTS}/2$, N=8</p> <p>0110: $f_{SAMPLING} = f_{DTS}/4$, N=6 0111: $f_{SAMPLING} = f_{DTS}/4$, N=8</p> <p>1000: $f_{SAMPLING} = f_{DTS}/8$, N=6 1001: $f_{SAMPLING} = f_{DTS}/8$, N=8</p>				

	1010: $f_{\text{SAMPLING}}=f_{\text{DTS}}/16$, N=5	1011: $f_{\text{SAMPLING}}=f_{\text{DTS}}/16$, N=6	1100: $f_{\text{SAMPLING}}=f_{\text{DTS}}/16$, N=8		
	1101: $f_{\text{SAMPLING}}=f_{\text{DTS}}/32$, N=5	1110: $f_{\text{SAMPLING}}=f_{\text{DTS}}/32$, N=6	1111: $f_{\text{SAMPLING}}=f_{\text{DTS}}/32$, N=8		
B1-009	Y2 pulse output source selection	0	0 ... 4	/	×
B1-010	Y2 minimum output frequency	0.00	0.0 ... 50.00	KhZ	×
B1-011	Y2 maximum output frequency	10.00	0.01 ... 50.00	KhZ	×
B1-012	Constant Y2 pulse output frequency	1.000	0.001 ... 50.000	KhZ	×
<p>Parameters B1-009 ... B1-012 are used to select Y2 high-speed pulse output source when Y2 is use as high-speed pulse output terminal.</p> <ul style="list-style-type: none"> ● B1-009 = 0: Running speed. The speed range from 0 ... P0-012 corresponds to parameter B1-010 ... B1-011. ● B1-009 = 1: AI1 The analog input AI1 range from 0 ... 10V/20mA corresponds to parameter B1-010 ... B1-011. ● B1-009 = 2: AI2 The analog input AI2 range from 0 ... 10V/20mA corresponds to parameter B1-010 ... B1-011. ● B1-009 = 3: AI3 The analog input AI3 range from 0 ... 10V corresponds to parameter B1-010 ... B1-011. <p>B1-012 is used to define the Y2 constant pulse output frequency when Y2 is use as high-speed pulse output terminal. The function can be active by a digital input terminal. For example, if digital input X3 is used to active the Y2 constant pulse output frequency, set digital input X3 terminal function to "60" (P3-003 = 60):</p> <ul style="list-style-type: none"> ● When X3 = 0, Y2 output pulse frequency source selected by parameter B1-009. <div style="text-align: center;"> <p>Y2 actual output frequency curve</p> </div> <ul style="list-style-type: none"> ● When X3 = 1, Y2 output pulse frequency defined by parameter B1-012. 					

5.17 Modbus (C0)

Parameter	Name	Default	Range	Unit	Attribute
C0-000	Modbus address	1	1 ... 255	/	○
	Defines the Modbus address. Two units with the same address are not allowed on-line.				
C0-001	Modbus baud rate	3	0 ... 5	/	○
	Selects the Modbus baud rate. <ul style="list-style-type: none"> ● 0: 4800bps ● 1: 9600 bps ● 2: 19200 bps ● 3: 38400 bps ● 4: 57600 bps ● 5: 115200 bps 				
C0-002	Modbus-RTU data format	0000	0000 ... 0121	/	○
	Sets the Modbus-RTU data format. One position: Data bits <ul style="list-style-type: none"> ● 0: 8 data bits ● 1: 7 data bits Tens position: Parity <ul style="list-style-type: none"> ● 0: No parity ● 1: Odd parity ● 2: Even parity Hundreds position: Stop bit (s) <ul style="list-style-type: none"> ● 0: 1 stops bit ● 1: 2 stops bits 				
C0-003	Communication response delay	0	0 ... 65535	/	○
	Defines the Modbus communication response time. Note that if the value of C0-003 is higher than the value of C0-004 (when C0-004 is a non-zero value), the drive trips on a fault even communication is normal.				
C0-004	Communication break detect time	0	0 ... 65535	/	○
	The drive trips on a fault if the Modbus communication break lasts longer than the time defined by parameter C0-004. Note that if C0-004 = 0 will disable the communication loss detection.				
C0-005	Data save to memory	0	0 ... 1	/	○
	<ul style="list-style-type: none"> ● 0: Parameters modified through Modbus communication are not save to memory after power off. ● 1: Parameters modified through Modbus communication not save to memory after power off. Note: The life of memory is about 100000 times, if change parameter frequently via communication, please do not set C0-005 to 1, otherwise, the memory service life will be reduced quickly.				
C0-006	Communication break power on delay time	0	0 ... 65535	/	○
	After the drive is powered, the communication break detect function is disabled (but communication itself can be active) for the time set by parameter C0-006. After the delay time, the communication break time count starts according parameter C0-004 (if non-zero value).				

Parameter	Name	Default	Range	Unit	Attribute
C0-007	User address 0	0000	0000 ... FFFF	/	○
C0-008	Mapping address 0	0000	0000 ... FFFF	/	○
C0-009	User address 1	0000	0000 ... FFFF	/	○
C0-010	Mapping address 1	0000	0000 ... FFFF	/	○
C0-011	User address 2	0000	0000 ... FFFF	/	○
C0-012	Mapping address 2	0000	0000 ... FFFF	/	○
C0-013	User address 3	0000	0000 ... FFFF	/	○
C0-014	Mapping address 3	0000	0000 ... FFFF	/	○
C0-015	User address 4	0000	0000 ... FFFF	/	○
C0-016	Mapping address 4	0000	0000 ... FFFF	/	○
C0-017	User address 5	0000	0000 ... FFFF	/	○
C0-018	Mapping address 5	0000	0000 ... FFFF	/	○
C0-019	User address 6	0000	0000 ... FFFF	/	○
C0-020	Mapping address 6	0000	0000 ... FFFF	/	○
C0-021	User address 7	0000	0000 ... FFFF	/	○
C0-022	Mapping address 7	0000	0000 ... FFFF	/	○
C0-023	User address 8	0000	0000 ... FFFF	/	○
C0-024	Mapping address 8	0000	0000 ... FFFF	/	○
C0-025	User address 9	0000	0000 ... FFFF	/	○
C0-026	Mapping address 9	0000	0000 ... FFFF	/	○
C0-027	User address 10	0000	0000 ... FFFF	/	○
C0-028	Mapping address 10	0000	0000 ... FFFF	/	○
C0-029	User address 11	0000	0000 ... FFFF	/	○
C0-030	Mapping address 11	0000	0000 ... FFFF	/	○
C0-031	User address 12	0000	0000 ... FFFF	/	○
C0-032	Mapping address 12	0000	0000 ... FFFF	/	○
C0-033	User address 13	0000	0000 ... FFFF	/	○
C0-034	Mapping address 13	0000	0000 ... FFFF	/	○
C0-035	User address 14	0000	0000 ... FFFF	/	○
C0-036	Mapping address 14	0000	0000 ... FFFF	/	○

There are 14 pairs addresses in hexadecimal. The user can change the Modbus communication address according to the actual communication requirements. Such as: place multiple discontinuous addresses to one continuous address, so that the addresses be read continuously by Modbus 0x03 command and written continuously by Modbus 0x10 command, which can reduce communication commands. When the address of the host controller is different from the drive, this function can be used to enable direct communication between the host controller and the drive.

For example, the host controller writes the speed by address 0x2000, reads the speed by address 0x3000. The Modbus address of the drive for speed reference is 0x8001, the Modbus address of the drive for running speed is 0x6041, and they cannot communicate directly with each other because of the different communication addresses. Address mapping allows direct communication between them without changing software of the host controller or VFD:

C0-007 = 2000 (User address), C0-008 = 8001 (Mapping address),
C0-009 = 3000 (User address), C0-010 = 6041 (Mapping address).

Parameter	Name	Default	Range	Unit	Attribute
C0-037	Communication frequency reference ratio numerator	1	1 ... 65535	/	○
C0-038	Communication frequency reference ratio denominator	1	1 ... 65535	/	○
<p>The parameter C0-037 and C0-038 are used to set the communication data factor receive from the host controller.</p> <p>Actual communication speed reference = communication speed reference * C0-037 / C0-038</p>					
C0-039	Master follower mode selection	0000	0000 ... 1006	/	○
<p>Sets the master and follower mode when two motors require following function via Modbus communication.</p> <p>Ones position: Master and follower selection.</p> <ul style="list-style-type: none"> 0: Normal mode Modbus default mode. Please keep this value as default when does not require two motors master-follower following through Modbus communication. 1: Master mode In this mode, the drive as master and actively sends data to the follower. 2: Follower operates in speed following mode (Note: Effective when P0-003 = 2 and P0-005 = 0). The follower operates in speed control, the speed output follows the master speed, the resulting result is directly executed without the acceleration and deceleration process: $\text{Follower speed output} = \text{Speed from master} * \text{C0-37/C0-38} + \text{C0-043}.$ 3: Follower operates in current following mode (Note: Effective when P0-003 = 2 and P0-005 = 0). The follower operates in speed control, the speed output follows the master speed and current, the resulting result is directly executed without the acceleration and deceleration process: $\text{Follower speed output} = \text{Speed from master} + \text{PID}(\text{master current, follower current})$ 4: Follower operates in torque following mode (Note: Effective when P0-003 = 3 and P0-002 != 3). The follower operates in torque control mode and the torque reference follows the master torque, the speed limit follows the master speed. $\text{Follower torque reference} = \text{Torque from master} \quad \text{Follower speed limit} = \text{Speed from master}$ 5: Follower operates in current loop following mode (Note: Effective when P0-003 = 3 & P0-002 != 3). The follower operates in current loop following mode. Current loop reference follows the master current loop output. In this control mode, without the participation of the speed loop, the speed can not be controlled. Therefore, the speed will continue to increase until the motor torque balance is achieved. Applicable to the applications that the motor shafts of the master and the follower are rigidly coupled by gearing, chain, etc. $\text{Follower current loop reference} = \text{Master current loop output}$ 6: Follower operates in speed following mode (Note: Effective when P0-003 = 2 and P0-005 = 0). The follower operates in speed control, the speed reference follows the master speedx, the resulting result is just a reference speed, the acceleration and deceleration process are is required: $\text{Follower speed rERENCE} = \text{Speed from master} * \text{C0-37/C0-38} + \text{C0-043}.$ <p>Notes:</p> <ul style="list-style-type: none"> ➤ For follower, if start command need follow the master, please set P0-004 = 0. ➤ If the parameter C0-039 is set to follower mode, follower mode can be temporarily disabled through a 					

Parameter	Name	Default	Range	Unit	Attribute
	<p>digital input when the digital input function is set to "48". For example, P3-003 = 48, then X3 = 0 follower mode, X3 = 1 master mode.</p> <p>➤ For follower mode, the results in selection "2" (C0-039 = 2) are directly output without a accelerating and decelerating process, while the results in selection "6" (C0-039 = 6) require a accelerating and decelerating process.</p>				
C0-040	Follower follow proportional gain	0.100	0.000 ... 60.000	/	○
C0-041	Follower follow integration time	0.010	0.000 ... 60.000	s	○
C0-042	Follower follow adjust upper limit	100	0 ... 400	rpm	○
<p>When C0-039 = 3:</p> <p>The proportional gain of the PID controller is defined by parameter C0-040.</p> <p>The integration time of the PID controller is defined by parameter C0-041.</p> <p>The upper limit of the PID output is defined by parameter C0-042.</p>					
C0-043	Follower follow torque / frequency offset	0.00	-50.00 ... 50.00	%	○
	<p>When parameter C0-039 = 4 or 5, C0-043 is torque offset.</p> <p>When parameter C0-039 = 2 or 5, C0-043 is frequency offset.</p>				
C0-044	Send / Receive speed	0	-32767 ... 32767	Rpm	*
C0-045	Send / Receive torque	0.00	-300.00 ... 300.00	%	*
C0-046	Send / Receive flag	0x0000	0x0000 ... 0xFFFF	/	*
The parameters C0-044 ... C0-046 are read only parameter. Data between master and slave communication.					

5.18 CAN (C1)

Reserved.

5.19 EtherCAT (C2)

Reserved.

5.20 Keypad Parameters (D0)

Parameter	Name	Default	Range	Unit	Attribute
D0-000	User password	0	0 ... 65535	/	○
	<ul style="list-style-type: none"> ● Setting password: Enter new user password (non-zero values) through parameter D0-000, and repeat this operation once again, and then the password is set successfully. ● Change password: Enter correct password through parameter D0-000, then set D0-000=***** (new password) and repeat set the password once again, , the new password is successfully set. ● Clear password: Enter correct user password to enter the parameter editing status, check if d0-000 is 00000. Press PRG key for confirmation, and set D0-000=00000 again, then the password is cleared. <p>Make password take effect:</p> <ul style="list-style-type: none"> ➤ Press the ESC + PRG + ▲(UP) key at the same time. ➤ No key operation for 5 minutes. ➤ Repower on. 				
D0-001	Random code	0	0 ... 10000	/	×
	Used by the manufacturer to check parameters under special circumstances.				
D0-002	Parameter restore	0	0 ... 4	/	×
	<ul style="list-style-type: none"> ● 0: Disabled ● 1: Save all the parameters to memory. The function is used to store values changed by communication. ● 2: All parameter values are restored to default values except parameters in Group P6. ● 3: All parameter values are restored to default values except parameters in Group P6 and F. ● 4: All parameter values are restored to default values except parameters in Group F. <p>Note: After the operation is completed, the value will automatically revert to 0.</p>				
D0-003	Parameters upload and download enable	0	0 ... 11	/	×
	<p>Ones position: Upload parameter values to keypad</p> <ul style="list-style-type: none"> ● 0: Enabled ● 1: Disabled <p>Tens position: Download parameter values to drive</p> <ul style="list-style-type: none"> ● 0: Enabled ● 1: Disabled <p>Note: Only effective for LED keypad.</p>				
D0-004	Parameters upload and download	0	0 ... 20	/	×
	<ul style="list-style-type: none"> ● 00: No action ● 01: Save parameter values to keypad. ● 11: Download parameter values to drive. <p>Notes:</p> <ul style="list-style-type: none"> ➤ Only effective for LED keypad, the upload and download function can be disabled by parameter D0-003. ➤ After the operation is completed, the value will automatically revert to 0. 				

Parameter	Name	Default	Range	Unit	Attribute
D0-005	M Key function selection	0000	0000 ... FFFF	/	×
	<ul style="list-style-type: none">Press and hold the M key and ▼(DOWN) key for 3s at the same time to achieve switching between remote control and keypad control. In addition, the speed reference command is changed to keypad too, only valid in the speed loop.Press M and STOP keys at the same time an immediately cut off the drive output. Note: M + STOP key can immediately cut off the drive output is very usefull when commissioning.				
D0-006	Reserved	0	0 ... 65535	/	×
	Reserved				
D0-007	Keypad lock Key function selection	0	0 ... 2	/	○
	<ul style="list-style-type: none">0: Unlock1: Lock all keys2: Lock all keys except RUN key and STOP key				
D0-008	Password protection range	0	0 ... 2	/	×
	Defines the protect method when the user password (d0-000) is effective. After modification, the parameter is effective after repower on.				
	<ul style="list-style-type: none">0: After the user password take effect, all editable parameters are invisible.1: After the user password take effect, parameter groups defined by parameters D0-009 ... D-010 are invisible.2: After the user password take effect, all the parameters are read-only and cannot be changed.				
D0-009	Hidden parameter group selection	0000	0000 ... FFFF	/	×
	Selects the parameter groups hidden for P0, P1, P2, P3, P4, P5, P6, P7, P8, P9, PA, PB, PC, A0, B0 and B1, 0 = visible, 1 = invisible.				
	bit0: P0 bit1: P1 bit2: P2 bit3: P3				
	bit4: P4 bit5: P5 bit6: P6 bit7: P7				
	bit8: P8 bit9: P9 bit10: PA bit11: PB				
	bit12: PC bit13: A0 bit14: B0 bit15: B1				
D0-010	Hidden parameter group selection	0000	0000 ... FFFF	/	×
	Selects the parameter groups hidden for C0, C1, C2, D0, E0, F0, F1, F2, and F3. 0 = visible, 1 = invisible.				
	bit0: C0 bit1: C1 bit2: C2 bit3: D0				
	bit4: E0 bit5: F0 bit6: F1 bit7: F2				
	bit8: F7 bit9...bit15: reserved				
D0-011	LCD backlight setting	0	0 ... 2	/	×
	Selects the backlight display mode.				
	<ul style="list-style-type: none">0: Turn off the backlight after 30s of inactivity1: Always turn on the backlight2: Always turn off the backlight				
D0-012	LCD contrast setting	24	14 ... 34	/	×
	Defines contrast setting for LCD keypad.				

Parameter	Name	Default	Range	Unit	Attribute										
D0-013	Keypad default display setting 0	0806	0000 ... FFFF	/	○										
	All the status monitoring parameters in Group F0 has a unique keypad display address. The keypad address is the low byte of the Modbus address. For example, the Modbus address of output current is 0x6008 (The Modbus address of F0-008 is shown in the right column of the parameter list, please refer to parameter F0-008 for more information); the low byte is 08, so the display address of the keypad is “08”.														
	<div><div>D0-013 = 08 06</div><div><div>The Modbus address of output current is 6008, the low byte is 08</div><div>The Modbus address of running speed is 6006, the low byte is 06</div></div></div>														
	<ul style="list-style-type: none">For LED keypad, we can define 5 parameters to be monitored on the main menu of the keypad, use shift right or shift left key to cyclic switching.For LCD keypad, we can define 3 parameters to be monitored for each page; total 5 pages can define 15 parameters to be monitored on the main menu of the keypad. Use shift right or shift left key to cyclic switching the pages.														
	The parameters D0-013 ... D0-020 are used to select which parameters are displayed on the keypad for easy monitoring. Take D0-013 as an example. If we want to set the output frequency, output current and output voltage on the page 1 of LCD keypad, then set D0-013 = 0806, D0-014 = **0A. Then the first monitored parameter on page 1 of the LCD keypad is output frequency, the second monitored parameter on page 1 of the LCD keypad is output current and the third monitored parameter on page 1 of the LCD keypad is output voltage.														
	<table><tr><td rowspan="2">LED</td><td>Tens position and Ones position</td><td>The 1st monitored parameter</td></tr><tr><td>Thousands position and Hundreds position</td><td>The 2nd monitored parameter</td></tr><tr><td rowspan="2">LCD</td><td>Tens position and Ones position</td><td>The 1st page the 1st monitored parameter</td></tr><tr><td>Thousands position and Hundreds position</td><td>The 1st page the 2nd monitored parameter</td></tr></table>					LED	Tens position and Ones position	The 1st monitored parameter	Thousands position and Hundreds position	The 2nd monitored parameter	LCD	Tens position and Ones position	The 1st page the 1st monitored parameter	Thousands position and Hundreds position	The 1st page the 2nd monitored parameter
	LED	Tens position and Ones position	The 1st monitored parameter												
		Thousands position and Hundreds position	The 2nd monitored parameter												
	LCD	Tens position and Ones position	The 1st page the 1st monitored parameter												
		Thousands position and Hundreds position	The 1st page the 2nd monitored parameter												
<div><div><div>V&T3210150.00Hz</div><div>Output Freq50.00Hz</div><div>Output Cur5.0A</div><div>Output Volt380V</div><div>[Gene]537V [Menu]</div></div><div><div>ESC</div><div>PRG</div><div>▲</div><div>◀▶</div><div>◊M</div><div>▼</div><div>RUN</div><div>STOP</div></div></div>															
D0-014	Keypad default display setting 1	000A	0000 ... FFFF	/	○										
	<table><tr><td rowspan="2">LED</td><td>Tens position and Ones position</td><td>The 3rd monitored parameter</td></tr><tr><td>Thousands position and Hundreds position</td><td>The 4th monitored parameter</td></tr><tr><td rowspan="2">LCD</td><td>Tens position and Ones position</td><td>The 1st page the 3rd monitored parameter</td></tr><tr><td>Thousands position and Hundreds position</td><td>The 2nd page the 1st monitored parameter</td></tr></table>					LED	Tens position and Ones position	The 3rd monitored parameter	Thousands position and Hundreds position	The 4th monitored parameter	LCD	Tens position and Ones position	The 1st page the 3rd monitored parameter	Thousands position and Hundreds position	The 2nd page the 1st monitored parameter
	LED	Tens position and Ones position	The 3rd monitored parameter												
		Thousands position and Hundreds position	The 4th monitored parameter												
	LCD	Tens position and Ones position	The 1st page the 3rd monitored parameter												
		Thousands position and Hundreds position	The 2nd page the 1st monitored parameter												

Parameter	Name	Default	Range	Unit	Attribute
D0-015	Keypad default display setting 2		0705	0000 ... FFFF	/ ○
	LED	Tens position and Ones position	The 5th monitored parameter		
		Thousands position and Hundreds position	Reserved		
	LCD	Tens position and Ones position	The 2nd page the 2nd monitored parameter		
		Thousands position and Hundreds position	The 2nd page the 3rd monitored parameter		
D0-016	Keypad default display setting 3		1514	0000 ... FFFF	/ ○
	LCD	Tens position and Ones position	The 3rd page the 1st monitored parameter		
		Thousands position and Hundreds position	The 3rd page the 2nd monitored parameter		
D0-017	Keypad default display setting 4		1716	0000 ... FFFF	/ ○
	LCD	Tens position and Ones position	The 3rd page the 3rd monitored parameter		
		Thousands position and Hundreds position	The 4th page the 1st monitored parameter		
D0-018	Keypad default display setting 5		1918	0000 ... FFFF	/ ○
	LCD	Tens position and Ones position	The 4th page the 2nd monitored parameter		
		Thousands position and Hundreds position	The 4th page the 3rd monitored parameter		
D0-019	Keypad default display setting 6		1211	0000 ... FFFF	/ ○
	LCD	Tens position and Ones position	The 5th page the 1st monitored parameter		
		Thousands position and Hundreds position	The 5th page the 2nd monitored parameter		
D0-020	Keypad default display setting 7		0013	0000 ... FFFF	/ ○
	LCD	Tens position and Ones position	The 5th page the 3rd monitored parameter		
		Thousands position and Hundreds position	Reserved		
D0-021	Calibration coefficient		100.0	50.0 ... 150.0	% ○
	Reserved.				
D0-022	User-define display parameter selection		0	0 ... 75	/ ○
	Selects the drive variable scaled into a desired user-define value.				
D0-023	User-define display parameter percentage		100.0	0.0 ... 200.0	% ○
	Defines scaling factor for user-define value (source selected by parameter D0-022).				
D0-024	Power correction factor		100	30 ... 200	% ○
	Defines scaling factor for output power of the drive.				

5.21 Protection Configuration (E0)

Parameter	Name	Default	Range	Unit	Attribute
E0-000	Fault configuration 1	0000	0000 ... FFFF	/	×
E0-001	Fault configuration 2	0000	0000 ... FFFF	/	×
Parameters from E0-000 to E0-007 are key parameters for faults. In special cases, permission and guidance from the manufacturer must be obtained.					
bit0 ... bit 15, fault type corresponding to each binary bit:					
Parameter E0-000:					
bit0: External fault		bit1: IGBT overload	bit2: Motor overload	bit3: IGBT over temperature	
bit4: Motor over temperature		bit5: Encoder fault	bit6: Over current	bit7: Module protection	
bit8: Over voltage		bit9: Under voltage	bit10: Encoder CD phase	bit11: Output phase loss	
bit12: EEPROM fault		bit13: Unauthorized	bit14: PID feedback break	bit15: PID feedback too high	
Parameter E0-001:					
bit0: ECT break		bit1: CAN break	bit2: ECT not support	bit3: Rectifier over temperature	
bit4: Pre-charge fault		bit5: Modbus timeout	bit6: Encoder phase fault	bit7: Analog input break	
bit8: Analog input too high		bit9: Current detect fault	bit10: Encoder Z fault	bit11: Motor stall	
bit12: Brake chopper fault		bit13: Over speed fault	bit14:APP fault	bit15: Input phase loss	
<div>● 0: Fault is not shielded</div> <div>● 1: Fault is shielded</div>					
E0-002	Fault display configuration 1	0000	0000 ... FFFF	/	×
E0-003	Fault display configuration 2	0000	0000 ... FFFF	/	×
Fault display configuration. bit0 ... bit 15, fault type corresponding to each binary bit, please refer to parameters E0-000 and E0-002 for more information:					
<div>● 0: Fault displayed on the keypad.</div> <div>● 1: Fault displayed on the keypad is shielded.</div>					
E0-004	Fault lock configuration 1	FDFF	0000 ... FFFF	/	×
E0-005	Fault lock configuration 2	FFFF	0000 ... FFFF	/	×
Fault lock configuration. bit0 ... bit 15, fault type corresponding to each binary bit, please refer to parameters E0-000 and E0-002 for more information:					
<div>● 0: Fault Lock is disabled</div> <div>● 1: Fault Lock is enabled</div>					
E0-006	Fault trip configuration 1	0DE0	0000 ... FFFF	/	×
E0-007	Fault trip configuration 2	0DE0	0000 ... FFFF	/	×
Fault trip, motor coast to stop. bit0 ... bit 15, fault type corresponding to each binary bit, please refer to parameters E0-000 and E0-002 for more information:					
<div>● 0: Coast to stop</div> <div>● 1: Not coast to stop</div>					

Parameter	Name	Default	Range	Unit	Attribute
E0-008	No. of automatic reset attempts	0	0 ... 65535	/	×
E0-009	Automatic reset delay time	10.0	5.0 ... 6553.5	s	×
<p>E0-008 is used to define the maximum number of automatic resets.</p> <ul style="list-style-type: none"> ● E0-008 = 0: Automatic reset function is inactive. ● E0-008 = 1 ... 65535: the number of automatic reset times. <p>E0-009 is used to define the time that the drive will wait after a fault (or a previous reset attempt) before attempting an automatic reset.</p> <p>Note: The parameter E0-008 and E0-009 should be use with parameters E0-023, E0-024 and E0-025.</p>					
E0-010	Motor overload protection mode	0	0 ... 65535	/	×
	Reserved.				
E0-011	Motor overload protection coefficient	1.0	0.5 ... 3.0	/	×
	<p>The motor overload protection coefficient is the protection time constant set to prevent the motor from being damaged due to long-term operation of the motor in an overload state. When the overload protection point is reached, the drive trips on a fault and stops output. It can be set according to the actual overload capacity of the motor and the overload capacity of the drive.</p>				
E0-012	Motor temperature sensor	0	0 ... 6	/	×
	<p>Selects motor temperature sensor.</p> <ul style="list-style-type: none"> ● 0: No motor temperature sensor ● 1: PT100 For the control board with resolver (default control board for the power $\geq 11\text{kW}$), when PT100 is used as motor temperature sensor, set to "1". ● 2: KTY84-130 For the control board with resolver (default control board for the power $\geq 11\text{kW}$), when KTY84-130 is used as motor temperature sensor, set to "2". ● 3 ... 4: Reserved. ● 5: AI3 use as PT100 signal input For the control board without resolver (default control board for the power $\leq 7.5\text{kW}$), when PT100 is used as motor temperature sensor, set to "5". Note that set the AI3 jumper and AI3 DIP correctly. ● 6: AI3 use as KTY84-130 input For the control board without resolver (default control board for the power $\leq 7.5\text{kW}$), when KTY84-130 is used as motor temperature sensor, set to "6". Note that the AI3 jumper and the AI3 DIP should be set correctly. <p>Notes:</p> <ul style="list-style-type: none"> ➤ When a motor temperature sensor is used to detect motor temperature, please confirm the drive mode selected support the motor temperature sensor input. ➤ When using a motor temperature sensor to detect motor temperature, please note that E0-019 (Motor over temperature value) is set to the appropriate value. 				

Parameter	Name	Default	Range	Unit	Attribute
E0-013	Over speed detect value	0.0	0.0 ... 200.0	%	×
E0-014	Over speed detect time	0.100	0.000 ... 30.000	s	○
When the speed of the motor continues to exceed the over speed detect value (defined by parameter E0-013) for the time defined by parameter E0-014, the drive trips on a fault (F3-050 = 1).					
E0-015	Speed error detect value	0.00	0.00 ... 650.00	Hz	×
E0-016	Speed error detect time	0.100	0.000 ... 30.000	s	○
When the speed error of the motor continues to exceed the speed error detect value (defined by parameter E0-015) for the time defined by parameter E0-016, the drive trips on a fault (F3-050 = 2).					
E0-017	Zero current detect value	0.0	0.0 ... 200.0	%	×
E0-018	Zero current detect time	1.000	0.000 ... 30.000	s	○
When the output current of the motor continues to exceed the zero current detect value (defined by parameter E0-017) for the time defined by parameter E0-018, the drive trips on a fault (F3-050 = 3).					
Note: Zero current detect function is invalid when the drive is stopped.					
E0-019	Motor over temperature value	140	0 ... 140	°C	×
E0-020	Motor temperature correction value	0	-200 ... 200	°C	×
When the motor temperature exceeds the motor over temperature value (E0-019), the drive trips on a fault and stops output to protect the motor from overheating and damage.					
When there is a deviation between the measured temperature and actual motor temperature, using parameter E0-020 to correct the measured temperature to be consistent with the actual temperature.					
E0-021	Reserved.	0	0 ... 2	/	○
E0-022	Automatic reset configuration 1	0000	0000 ... FFFF	/	○
E0-023	Automatic reset configuration 2	0000	0000 ... FFFF	/	○
E0-024	Automatic reset enables	0	0 ... 1	/	×
<ul style="list-style-type: none"> E0-024 = 0: Disables automatic reset. Automatic reset function is inactive. E0-024 = 1: Enables automatic reset. The fault automatic reset function takes effect. When there is a fault can be automatic reset (defined by parameter E0-022 and E0-023), the fault will be automatically reset within the allowable automatic reset times (defined by parameter E0-008). 					
Parameter E0-022	Corresponding faults	Parameter E0-023	Corresponding faults		
bit0	External fault	bit0	ECT break		
bit1	IGBT overload	bit1	CAN break		
bit2	Motor overload	bit2	ECT not support		
bit3	IGBT over temperature	bit3	Rectifier over temperature		
bit4	Motor over temperature	bit4	Pre-charge fault		
bit5	Encoder fault	bit5	Modbus timeout		
bit6	Over current	bit6	Encoder phase fault		
bit7	Module protection	bit7	Analog input break		

Parameter	Name	Default	Range	Unit	Attribute
	bit8	Over voltage	bit8	Analog input too high	
	bit9	Under voltage	bit9	Current detect fault	
	bit10	Encoder CD phase	bit10	Encoder Z fault	
	bit11	Output phase loss	bit11	Motor stall	
	bit12	EEPROM fault	bit12	Brake chopper fault	
	bit13	Unauthorized	bit13	Over speed fault	
	bit14	PID feedback break	bit14	APP fault	
	bit15	PID feedback too high	bit15	Input phase loss	

Note: Currently, automatic resets are possible only for certain fault types and when the automatic reset function is activated for that fault type: external fault, IGBT overload, motor overload, motor over temperature, over current, over voltage, under voltage, Analog input break, Analog input too high. Automatic reset function has no effect for other faults.

E0-025	Continuous fault detection time	0	0 ... 65535	/	○
	Defined the minimum interval for automatic reset. If a fault automatic reset action is performed and a continuous fault occurs within this time, the fault cannot be reset by automatic reset function.				
E0-026	Hardware version	1	0 ... 1	/	○
	Reserved for manufacture.				
E0-027	Stall protection enable	0	0 ... 1	/	×
E0-028	Stall frequency limit	0.5	0.5 ... 50.0	Hz	×
E0-029	Stall time	1	0 ... 3000	s	×

Parameter E0-027 is used to activates or deactivates the motor stall protection.

● **E-027 = 0: Stall protection is disabled.**

● **E-027 = 1: Stall protection is enabled.**

It is possible to adjust the torque and speed when the motor in stall condition. When the following conditions are met simultaneously, the drive trips on a fault.

- ① Parameter E0-027 = 1.
- ② The output current continuously exceeds 95% of the maximum torque limit.
- ③ The reference frequency is above the level set by parameter E0-028.
- ④ The output frequency is below the level set by parameter E0-028.
- ⑤ The conditions above have been valid longer than the time set by parameter E0-029.

E0-030	Fault retention after power-off	0	0 ... 1	/	○
	<ul style="list-style-type: none"> ● 0: Fault is not locked. If cut off the power supply of the drive with a fault, the fault will be reset the next time the drive is powered up. ● 1: Fault is locked. If cut off the power supply of the drive with a fault, the trip does or occur the next time the drive is powered up, must RESET before start. 				

Parameter	Name	Default	Range	Unit	Attribute
E0-031	Motor pre-overload selection	0000	0000 ... 1111	/	○
E0-032	Motor pre-overload detect value	120.00	0.05 ... 600.00	%	○
E0-033	Motor pre-overload detect time	10	1 ... 65530	S	○

E0-031 ones position: Activates/deactivates pre-overload detection function

- **0: Inactive**

Motor pre-overload detect function deactivated.

- **1: Active**

Motor pre-overload detect function activated. When the output current continuously exceeds the motor pre overload detect value (E0-032) for the time defined by parameter (E0-033), the motor pre-overload alarm signal can be output by digital output (the digital output function = [57]).

If hundreds position of E0-031 = 1, the drive trips on a fault too.

E0-031 tens position: Pre-overload detection during acceleration

- **0: Detect only at constant speed**

The motor pre-overload detection is only active only when the drive running at steady speed.

- **1: Always detect**

The motor pre-overload detection is active when the drive in running status.

E0-031 hundreds position: Pre-overload fault / alarm selection

- **0: Generate an alarm signal but without trip.**

The drive generates an alarm signal but without trip when the output current continuously exceeds the motor pre overload detect value (parameter E0-032).

- **1: The drive trips on a fault.**

The drive trips on a fault when the output current continuously exceeds the motor pre overload detect value (parameter E0-032).

E0-031 thousands position: pre-overload output signal cleared selection

- **0: Cleared in stop status.**

- **1: Cleared after the load falls below the pre-overload level.**

5.22 Status Monitoring Parameters (F0)

Parameter	Name	Range	Unit	Modbus address in HEX																																
F0-000	Reference frequency	-327.67 ... 327.67	Hz	6000																																
F0-001	Reference speed	-32767 ... 32767	rpm	6001																																
F0-002	Reference torque	-6553.5 ... 6553.5	%	6002																																
F0-000 shows the reference frequency.																																				
F0-001 shows the reference speed.																																				
F0-002 shows the reference torque.																																				
F0-003	Reference position high order byte	0 ... 65535	pulse	6003																																
F0-004	Reference position low order byte	0 ... 65535	pulse	6004																																
Parameters F0-003 and F0-004 are used tp show the reference position.																																				
F0-005	DC bus voltage	0 ... 65535	V	6005																																
F0-006	Running frequency	-327.67 ... 327.67	Hz	6006																																
F0-007	Running speed	-32767 ... 32767	rpm	6007																																
F0-008	Output current	-3276.7 ... 3276.7	A	6008																																
F0-009	Output torque	0.0 ... 6553.5	%	6009																																
F0-010	Output voltage	0 ... 65535	V	600A																																
F0-011	Output power	-3276.8 ... 3276.7	kW	600B																																
F0-005 shows the measured DC bus voltage.																																				
F0-006 shows the running frequency.																																				
F0-007 shows the running speed.																																				
F0-008 shows the measured motor current.																																				
F0-009 shows the the calculated motor torque.																																				
F0-010 shows the calculated motor voltage.																																				
F0-011 shows the calculated output power.																																				
F0-012	System status	0000 ... FFFF	/	600C																																
Shows the drive status word 1.(parameter F0-104 shows the status word 2, please refer to F0-104 for more information)																																				
<table><tr><td>Bit 0</td><td>Ready</td><td>Bit 8</td><td>Speed reach reference</td></tr><tr><td>Bit 1</td><td>Pre-charge OK</td><td>Bit 9</td><td>Position reach</td></tr><tr><td>Bit 2</td><td>Running</td><td>Bit 10</td><td>Orientation complete</td></tr><tr><td>Bit 3</td><td>Speed reach upper limit</td><td>Bit 11</td><td>Brake chopper working</td></tr><tr><td>Bit 4</td><td>Speed reach lower limit</td><td>Bit 12</td><td>authorized</td></tr><tr><td>Bit 5</td><td>Accelerating</td><td>Bit 13</td><td>S curve shape finish</td></tr><tr><td>Bit 6</td><td>Decelerating</td><td>Bit 14</td><td>Super user</td></tr><tr><td>Bit 7</td><td>Zero speed</td><td>Bit 15</td><td>Reserved</td></tr></table>					Bit 0	Ready	Bit 8	Speed reach reference	Bit 1	Pre-charge OK	Bit 9	Position reach	Bit 2	Running	Bit 10	Orientation complete	Bit 3	Speed reach upper limit	Bit 11	Brake chopper working	Bit 4	Speed reach lower limit	Bit 12	authorized	Bit 5	Accelerating	Bit 13	S curve shape finish	Bit 6	Decelerating	Bit 14	Super user	Bit 7	Zero speed	Bit 15	Reserved
Bit 0	Ready	Bit 8	Speed reach reference																																	
Bit 1	Pre-charge OK	Bit 9	Position reach																																	
Bit 2	Running	Bit 10	Orientation complete																																	
Bit 3	Speed reach upper limit	Bit 11	Brake chopper working																																	
Bit 4	Speed reach lower limit	Bit 12	authorized																																	
Bit 5	Accelerating	Bit 13	S curve shape finish																																	
Bit 6	Decelerating	Bit 14	Super user																																	
Bit 7	Zero speed	Bit 15	Reserved																																	

Parameter	Name	Range	Unit	Modbus address in HEX
F0-013	Drive fault display 1	0000 ... FFFF	/	600D
F0-014	Drive fault display 2	0000 ... FFFF	/	600E

F0-013 and F0-014 when the corresponding bit=1, it indicates the drive has a fault in the corresponding bit.

Parameter F0-013	Corresponding faults	Parameter F0-014	Corresponding faults
Bit 0	External fault	Bit 0	ECT break
Bit 1	IGBT overload	Bit 1	CAN break
Bit 2	Motor overload	Bit 2	ECT not support
Bit 3	IGBT over temperature	Bit 3	Rectifier over temperature
Bit 4	Motor over temperature	Bit 4	Pre-charge fault
Bit 5	Encoder fault	Bit 5	Modbus timeout
Bit 6	Over current	Bit 6	Encoder phase fault
Bit 7	Module protection	Bit 7	Analog input break
Bit 8	Over voltage	Bit 8	Analog input too high
Bit 9	Under voltage	Bit 9	Current detect fault
Bit 10	Encoder CD phase	Bit 10	Encoder1 Z fault
Bit 11	Output phase loss	Bit 11	Motor stall
Bit 12	EEPROM fault	Bit 12	Brake chopper fault
Bit 13	Unauthorized	Bit 13	Over speed fault
Bit 14	PID feedback break	Bit 14	APP fault
Bit 15	PID feedback too high	Bit 15	Input phase loss

F0-015	Drive fault Code	0 ... 65535	/	600F
--------	------------------	-------------	---	------

Shows the fault code when the drive trips on a fault. When F0-015 = 0, means no fault.

F0-015	Fault name	F0-015	Fault name
1	External fault	17	ECT break
2	IGBT overload	18	CAN brea
3	Motor overload	19	ECT not support
4	IGBT over temperatur	20	Rectifier over temperature
5	Motor over temperature	21	Pre-charge fault
6	Encoder fault	22	Modbus timeout
7	Over current	23	Encoder phase fault
8	Module protection	24	Analog input break
9	Over voltage	25	Analog input too high
10	Under voltage	26	Current detect fault
11	Encoder CD phase loss	27	Encoder1 Z fault
12	Output phase loss	28	Motor stall
13	EEPROM fault	29	Brake chopper fault
14	Unauthorized	30	Over speed fault
15	PID feedback break	31	Application fault
16	PID feedback too high	32	Input phase loss

Parameter	Name	Range	Unit	Modbus address in HEX
F0-016	Current position high order byte	0 ... 65535	pulse	6010
F0-017	Current position low order byte	0 ... 65535	pulse	6011
F0-016 and F0-017 are used to show the current position high order byte and low order byte.				
F0-018	Position following error	-32768 ... 32767	pulse	6012
	Shows the deviation between the current position feedback and the current position reference.			
F0-019	Mechanical position 1	0 ... 65535	pulse	6013
	Shows the encoder 1 position (selected by parameter A0-000)			
F0-020	Digital inputs status	0000 ... FFFF	/	6014
	Status of digital inputs. Example: 0000001 = X1 is ON, X7...X2 are OFF. The corresponding relationship of each bit is as follows: <div style="display: flex; flex-wrap: wrap;"> <div style="width: 25%;">bit0: X1</div> <div style="width: 25%;">bit1: X2</div> <div style="width: 25%;">bit2: X3</div> <div style="width: 25%;">bit3: X4</div> <div style="width: 25%;">bit4: X5</div> <div style="width: 25%;">bit5: X6</div> <div style="width: 25%;">bit6: X7</div> <div style="width: 25%;">bit7: AI1</div> <div style="width: 25%;">bit8: AI2</div> <div style="width: 25%;">bit9: AI3</div> <div style="width: 25%;">bit10: virtual X1</div> <div style="width: 25%;">bit11: virtual X2</div> <div style="width: 25%;">bit12: virtual X3</div> <div style="width: 25%;">bit13: virtual X4</div> <div style="width: 25%;">bit14: virtual X5</div> <div style="width: 25%;">bit15: reserved</div> </div>			
F0-021	Digital outputs status	0000 ... FFFF	/	6015
	Status of digital outputs and relay outputs. Example: 10000 = Relay 3 is energized, Relay 1 and Relay 2 are de-energized, Y1 and Y2 are OFF. The corresponding relationship of each bit is as follows: <div style="display: flex; flex-wrap: wrap;"> <div style="width: 25%;">bit0: Y1</div> <div style="width: 25%;">bit1: Y2</div> <div style="width: 25%;">bit2: Relay1</div> <div style="width: 25%;">bit3: Relay2</div> <div style="width: 25%;">bit4: Relay3</div> <div style="width: 25%;">bit5 ... bit15: reserved</div> </div>			
F0-022	IGBT temperature	-1000 ... 10000	℃	6016
	Shows the measured IGBT temperature.			
F0-023	AI1 input value	-32.767 ... 32.767	V	6017
F0-024	AI2 input value	-32.767 ... 32.767	V	6018
F0-025	AI3 input value	-32.767 ... 32.767	V	6019
Parameters F0-023, F0-024 and F0-025 are used to display the value of analog input AI1, AI2 and AI3 after scaling. 10.00 = 10..00V/20mA.				
F0-026	PID reference	0.00 ... 655.35	%	601A
F0-027	PID feedback	0.00 ... 655.35	%	601B
F0-026 shows the process PID reference. 100.00 = maximum speed P0-012.				
F0-027 shows the process PID feedback. 100.00 = maximum speed P0-012.				
F0-028	Simple PLC_T1	0 ... 65535	s	601C
F0-029	Simple PLC_T2	0.0 ... 6553.5	s	601D
F0-030	Simple PLC current cycle times	0 ... 65535	/	601E
F0-031	Simple PLC current step	0 ... 65535	/	601F
Parameters F0-028 ... F0-031 show the simple PLC logic status display.				

Parameter	Name	Range	Unit	Modbus address in HEX
F0-032	Keypad UP/DN adjustment value	-327.67 ... 32767	Hz	6020
		-32767 ... 32767	rpm	
	Shows Keypad UP/DN adjustment value.			
F0-033	Terminal UP/DN adjustment value	-327.67 ... 32767	Hz	6021
		-32767 ... 32767	rpm	
	Shows terminal UP/DN adjustment value.			
F0-034	Accumulative power-on time (hours)	0 ... 65535	h	6022
F0-035	Accumulative power -on time (minutes)	0 ... 65535	min	6023
Show accumulative power-on time. Total power-on time = F0-035 + F0-035/60.				
F0-036	Accumulative running time (hours)	0 ... 65535	h	6024
F0-037	Accumulative running time (minutes)	0 ... 65535	min	6025
Show accumulative running time. Total running time = F0-036 + F0-037/60.				
F0-038	CPU utilization	0.0 ... 6553.5	%	6026
	Shows CPU utilization.			
F0-039	Pulse input low order byte	-32767 ... 32767	pulse	6027
F0-040	Pulse input high order byte	-32767 ... 32767	pulse	6028
Show pulse input low order byte and high order byte.				
F0-041	Motor temperature	-40 ... 140	℃	6029
	Shows measured motor temperature by motor sensor.			
F0-042 ... F0-045	Reserved	0000 ... FFFF	/	602A ... 602D
F0-046	Encoder phase Z position	0 ... 65535	/	602E
	Shows the encoder phase Z signal position.			
F0-047	Reserved	0 ... 65535	/	602F
F0-048	AI1 sampling value	-32.767 ... 32.767	V	6030
F0-049	AI2 sampling value	-32.767 ... 32.767	V	6031
F0-050	AI3 sampling value	-32.767 ... 32.767	V	6032
Parameters F0-048, F0-049 and F0-050 are used to display the value of actual analog input AI1, AI2 and AI3.				
F0-051	User define display value	0 ... 65535	/	6033
	Shows the user define display value. The value is defined by parameter D0-022 and D0-023.			
F0-052	Accumulative power consumption low order byte	0.0 ... 6553.5	kW.h	6034
F0-053	Accumulative power consumption high order byte	0 ... 65535	kW.h	6035
Show the accumulative power consumption low order byte and high order byte.				
F0-054	Accumulative power generation low order byte	0 ... 6553.5	kW.h	6036
F0-055	Accumulative power generation high order byte	0 ... 65535	kW.h	6037

Parameter	Name	Range	Unit	Modbus address in HEX
Show the accumulative power generation low order byte and high order byte.				
F0-056	Home position 1	0 ... 65535	/	6038
	Shows the home position for encoder 1.			
F0-057 ...	Reserved	0 ... 65535	/	6039 ...
F0-059				603B
F0-060	System status 1	0 ... 65535	/	603C
	Shows system status word 1.			
	bit0	Running	bit4	Keypad is locked
	bit1	reserved	bit6 ... bit5	Running command reference 00: keypad 01: digital input 10: RS485 11: other
	bit2	reserved	bit15 ... bit7	reserved
	bit3	reverse		
F0-061	Communication reference	-32767 ... 32767	/	603D
	Shows communication speed reference (address 0x8001).			
F0-062	Encoder 1 corresponds to motor rotation speed	-32767 ... 32767	rpm	603E
	Shows the incremental encoder speed for encoder 1. Measure at any control mode, even VF control, thus check whether the encoder wiring and installation are correct.			
F0-063	Application fault	0 ... 65535	/	603F
	Shows the fault that will be automatic reset.			
F0-064	Running frequency	0 ... 655.35	Hz	6040
F0-065	Running speed	0 ... 65535	rpm	6041
F0-066	Output current	-3276.8 ... 3276.7	A	6042
F0-067	Output voltage	0 ... 65535	V	6043
F0-068	Output power	0.0 ... 6553.5	kW	6044
F0-064 show the absolute running frequency.				
F0-065 show the absolute running speed.				
F0-066 show the measured output current after filtering.				
F0-067 show the measured output voltage after filtering.				
F0-068 show the measured output power after filtering.				
F0-069 ...	Reserved	0 ... 65535	/	6045 ...
F0-073				6049
F0-074	Encoder 1 Z signal position	0 ... 65535	/	604A
	Shows the encoder 1 Z signal position.			

Parameter	Name	Range	Unit	Modbus address in HEX
F0-075	SinCos signal amplitude	0 ... 65535	/	604B
	Shows the SinCos signal amplitude of resolver. Note: When the resolver installation is not good, may cause the value of F0-075 too low, may cause the drive trips on a fault.			
F0-076 ... F0-084	Transmission ratio coefficient	0.000 ... 65.535	/	604C ... 6054
F0-085	Output current	0 ... 6553.5	/	6055
	Shows the measured absolute output current after filtering.			
F0-086	Trip code saved before power cut-off	0 ... 65535	/	6056
	Shows trip code recorded before power supply is cut-off.			
F0-087	Total number of parameters	0 ... 65535	/	6057
	Reserved.			
F0-088	Speed controller output torque	0 ... 6553.5	%	6058
	Shows current speed controller output torque, 100.0% = motor rated torque.			
F0-089	Electrical angle	0 ... 65535	/	6059
	Mechanical angle: refers to the geometric angle of space occupied by each pole pair of the motor on the inner circle of the stator, i.e. $360^\circ/p$, where p is the number of pole pairs. Electrical angle: In a multi-pole motor, the mechanical angle occupied by each pair of poles is defined as an electrical angle of 360° , and the relationship between the electrical angle and the mechanical angle is: Electrical angle = mechanical angle \times pole pairs			
F0-090	Reserved	0 ... 65535	/	605A
F0-091	Current pulse reference high	0 ... 65535	/	605B
F0-092	Current pulse reference low	0 ... 65535	/	605C
Shows current pulse reference high order byte				
F0-093	Permanent magnet motor back EMF	0.00 ... 655.35	V	605D
	Shows permanent magnet motor back EMF			
F0-094	Frequency reference 1	0.00 ... 655.35	Hz	605E
	Shows absolute frequency reference.			
F0-095	Open loop main reference	-327.67 ... 327.67	%	605F
	Shows open loop main reference in %. $\pm 100\%$ = \pm maximum speed P0-012.			
F0-096	PID output	-327.67 ... 327.67	%	6060
	Shows the PID output, $\pm 100\%$ = \pm maximum speed P0-012.			
F0-097	Keypad potentiometer reference value	0 ... 65535	/	6061
	Reserved.			
F0-098	Modbus-CMD	0000 ... FFFF	/	6062
	Shows the Modbus control word (address 0x8000). Refer to Appendix A for more information.			

Parameter	Name	Range	Unit	Modbus address in HEX
F0-099	AO1 output display	0.00 ... 100.00	%	6063
F0-100	AO2 output display	0.00 ... 100.00	%	6064
F0-099 show the AO1 output, 100.00 = 10V/20mA. F0-100 show the AO2 output, 100.00 = 10V/20mA.				
F0-101	Orthogonal pulse	0 ... 6553.5	Khz	6065
F0-102	Single pulse 1	0 ... 6553.5	Khz	6066
F0-103	Single pulse 2	0 ... 6553.5	Khz	6067
F0-100 show the orthogonal pulse input frequency when B1-000=0. F0-101 show the single pulse input frequency when B1-000=1. F0-102 show the single pulse input frequency when B1-000=2.				
F0-104	System status word 2		0000 ... FFFF	6068
	Bit 0	Over voltage regulating	Bit4 ... Bit15	Reserved.
	Bit 1	Under voltage regulating		
	Bit 2	DC braking		
	Bit 3	Terminal Enable Lock Status		
F0-105	Communication torque reference	-32767 ... 32767		6069
	Shows communication torque reference.			
F0-106	Idref	-3276.7 ... 3276.7	/	606A
	Shows the reference value of d-axis current.			
F0-107	Udref	-3276.7 ... 3276.7	/	606B
	Shows the reference value of d-axis voltage.			

5.23 Software Version (F1, F2)

Parameter	Name	Range	Unit	Modbus address in HEX
F1-000	Software version 1	0000 ... FFFF	/	
	The parameters in group F1 are read-only.			
F1-001	Software version 2	0000 ... FFFF	/	
F1-002	Software version 3	0000 ... FFFF	/	
F1-003	Software version 4	0000 ... 65535	/	
F1-004	Keypad ID	0000 ... 65535	/	
F1-005	Reserved	0000 ... 65535	/	
F1-006	Y	0000 ... 65535	/	
F1-007	D	0000 ... 65535	/	
F1-008	T	0000 ... 65535	/	
F1-009	Drive power	0.0 ... 6553.5	kW	
F1-010	Prompt code	0000 ... 65535	/	
F2-000	Barcode information 0	0000 ... FFFF	/	
F2-001	Barcode information 1	0000 ... FFFF	/	
F2-002	Barcode information 2	0000 ... FFFF	/	
F2-003	Barcode information 3	0000 ... FFFF	/	

5.24 Trip History (F3)

Parameter	Name	Range	Unit	Modbus address in HEX
F3-000	Trip 0 code	0 ... 65000	/	
	<p>There are 5-group trip history in total.</p> <p>Trip 0 (the latest trip): F3-000 ... F3-009</p> <p>Trip 1(the 2nd latest trip): F3-010 ... F3-019</p> <p>Trip 2 (the 3rd latest trip): F3-020 ... F3-029</p> <p>Trip 3 (the 4th latest trip): F3-030 ... F3-039</p> <p>Trip 4 (the 5th latest trip): F3-040 ... F3-009</p> <p>Notes:</p> <ul style="list-style-type: none"> ➤ When the trip code is 31, it is an application trip, please check F3-050 for more details. ➤ Refer to "Chapter 6 Diagnostics" for the diagnostics. ➤ When the drive trips on a fault, the current trip code is display in the parameter F0-015. The Modbus address of F0-015 is 0x600F. The host controller can query this address to check whether the drive is in fault state and query the fault code. ➤ The reset signal can be given through keypad, external digital input and communication control word, the reset signal resets the drive after a fault trip if the cause of the fault no longer exists. 			
F3-001	Trip 0 running frequency	0.00 ... 650.00	Hz	
F3-002	Trip 0 reference frequency	0.00 ... 650.00	Hz	
F3-003	Trip 0 DC bus voltage	0 ... 60000	V	
F3-004	Trip 0 output current	0.0 ... 6553.5	A	
F3-005	Trip 0 digital inputs status	0000 ... FFFF	/	
F3-006	Trip 0 digital output status	0000 ... FFFF	/	
F3-007	Trip 0 heatsink temperature	0 ... 200	℃	
F3-008	Trip 0 accumulative power-ON Time	0 ... 65000	h	
F3-009	Trip 0 accumulative running Time	0 ... 65000	h	
F3-010	Trip 1 code	0 ... 65000	/	
F3-011	Trip 1 running frequency	0.00 ... 650.00	Hz	
F3-012	Trip 1 reference frequency	0.00 ... 650.00	Hz	
F3-013	Trip 1 DC bus voltage	0 ... 60000	V	
F3-014	Trip 1 output current	0.0 ... 6553.5	A	
F3-015	Trip 1 digital inputs status	0000 ... FFFF	/	
F3-016	Trip 1 digital output status	0000 ... FFFF	/	
F3-017	Trip 1 heatsink temperature	0 ... 200	℃	
F3-018	Trip 1 accumulative power-ON Time	0 ... 65000	h	
F3-019	Trip 1 accumulative running Time	0 ... 65000	h	
F3-020	Trip 2 code	0 ... 65000	/	
F3-021	Trip 2 running frequency	0.00 ... 650.00	Hz	

Parameter	Name	Range	Unit	Modbus address in HEX
F3-022	Trip 2 reference frequency	0.00 ... 650.00	Hz	
F3-023	Trip 2 DC bus voltage	0 ... 60000	V	
F3-024	Trip 2 output current	0.0 ... 6553.5	A	
F3-025	Trip 2 digital inputs status	0000 ... FFFF	/	
F3-026	Trip 2 digital output status	0000 ... FFFF	/	
F3-027	Trip 2 heatsink temperature	0 ... 200	℃	
F3-028	Trip 2 accumulative power-ON Time	0 ... 65000	h	
F3-029	Trip 2 accumulative running Time	0 ... 65000	h	
F3-030	Trip 3 code	0 ... 65000	/	
F3-031	Trip 3 running frequency	0.00 ... 650.00	Hz	
F3-032	Trip 3 reference frequency	0.00 ... 650.00	Hz	
F3-033	Trip 3 DC bus voltage	0 ... 60000	V	
F3-034	Trip 3 output current	0.0 ... 6553.5	A	
F3-035	Trip 3 digital inputs status	0000 ... FFFF	/	
F3-036	Trip 3 digital output status	0000 ... FFFF	/	
F3-037	Trip 3 heatsink temperature	0 ... 200	℃	
F3-038	Trip 3 accumulative power-ON Time	0 ... 65000	h	
F3-039	Trip 3 accumulative running Time	0 ... 65000	h	
F3-040	Trip 4 code	0 ... 65000	/	
F3-041	Trip 4 running frequency	0.00 ... 650.00	Hz	
F3-042	Trip 4 reference frequency	0.00 ... 650.00	Hz	
F3-043	Trip 4 DC bus voltage	0 ... 60000	V	
F3-044	Trip 4 output current	0.0 ... 6553.5	A	
F3-045	Trip 4 digital inputs status	0000 ... FFFF	/	
F3-046	Trip 4 digital output status	0000 ... FFFF	/	
F3-047	Trip 4 heatsink temperature	0 ... 200	℃	
F3-048	Trip 4 accumulative power-ON Time	0 ... 65000	h	
F3-049	Trip 4 accumulative running Time	0 ... 65000	h	
F3-050	Application trip code	0 ... 65535	/	
	When the trip code is “31”, it is an application trip; the cause of the fault needs to query through parameter F3-050. Refer to “Chapter 6 Diagnostics” for the diagnostics.			
	F3-050	Cause		
	1	Over speed		
	2	Speed error		
	3	Zero current detection		

Chapter 6 Diagnostics

6.1 Fault Indications

This chapter lists all the faults messages including the possible causes and corrective actions. If the drive faults, the drive output is disabled so that the drive stops controlling the motor, and the following fault code will be displayed on the keypad, the fault contact output operates too.

Even if a fault is the same, they are displayed differently on LCD keypad and LED keypad. These are all explained in the below table.

For details, refer to the following table to identify and correct the cause of the fault.

For damages on units or questions that can't be resolved, please contact with local distributors/agents, service centers or manufacturer for solutions.

LCD keypad	LED keypad	F0-015 value	Fault Name	Possible causes	Corrective actions
Err-01	E-PEr	1	External fault	Digital input fault is "ON"	Check the corresponding digital input
Err-02	E-oL1	2	Drive overload	Power supply voltage too low	Check the power supply voltage
				Start when the motor is spinning	Restart after the motor at standstill
				Overloading for a long time	Reduce overload time and reduce load
				Drive power selection is too small	Replace with a suitable drive
Err-03	E-oL2	3	Motor overload	Power supply voltage too low	Check the power supply voltage
				Motor stall or load suddenly changed	Check motor load and drive ratings
				V/F curve setting are not correct	Adjust V/F curve and torque boost
Err-04	E-oH1	4	IGBT over temperature	Ambient over-temperature	Check ambient conditions
				Fan failure	Check air flow and fan operation
				Blockage of air duct	Check heatsink fins for dust pick-up
				Output current too high	Check the load and parameter Check motor power and drive power
				Temperature detect circuit failure	Seek for technical support
Err-05	E-oH2	5	Motor over temperature	Motor temperature too high	Improve ventilation and heat dissipation
				Thermistor resistance is abnormal	Check the thermistor
				Setting motor sensor protection threshold is improper	Check the parameter setting
Err-06	E-dL1	6	Encoder fault	Encoder connection is incorrect	Change encoder wiring
				The encoder has no signal output	Check the encoder and power supply
				Encoder parameters are not correctly	Check the encoder parameters
Err-07	E-oC-	7	Over current	Power supply too low	Check the power supply voltage
				Load inertia is too high	Extended acceleration time
				Motor parameters are not correctly	Set motor parameters correctly
				Ramp-up time was set too short	Extended acceleration time
				The drive power mismatch	Replace with a suitable drive
				Current controller not correctly set	Set current controller parameters correctly

LCD keypad	LED keypad	F0-015 value	Fault Name	Possible causes	Corrective actions
Err-08	E-FAL	8	Module protection	Module failure	Seek for technical support
				U, V, W short-circuited to ground	Check whether the output wiring is short-circuited to ground
				DC bus voltage under voltage ($\geq 75\text{kW}$)	Check the input power supply
				Built-in brake chopper abnormal ($\geq 75\text{kW}$)	Seek for technical support
				Rectifier or module overheated ($\geq 75\text{kW}$)	Seek for technical support
				The pre-charged contactor closes abnormally ($\geq 185\text{kW}$)	Check the input power supply
				Poor contact of the internal connectors	Ask professional technicians for maintenance
Err-09	E-oU-	9	Over voltage	Motor short circuit to ground	Check the motor and motor wiring
				Start when the motor is spinning	Restart after the motor at standstill
				Load inertia is too large	Use appropriate dynamic braking unit
				Deceleration time is too short	Extend the deceleration time
				The input voltage is too high	Check the input power supply
Err-10	E-LU-	10	Under voltage	The input voltage is too low	Check the input power supply
				Abnormal switching power supply	Seek for technical support
Err-11	E-IPF	11	Encoder lost CD phase	CD signal connection is abnormal	Check the encoder and wiring
Err-12	E-oPF	12	Output phase loss	Motor failure	Replace a new motor
				Motor cable is broken	Replace a new motor cable
				Thermal relay failure (if is used)	Check thermal relay
				Output detection circuit failure	Seek for technical support
Err-13	E-EPr	13	EEPROM abnormal	EEPROM read/write abnormal	Seek for technical support
Err-14	E-LIC	14	Unauthorized	Unauthorized	Seek for technical support
Err-15	E-LoS	15	PID feedback disconnection	PID feedback disconnection detection setting is wrong or PID feedback disconnection	Check PID feedback disconnection value and detection time. Check the PID feedback cable
Err-16	E-oUt	16	PID feedback out of range	PID feedback exceeds the acceptable range	Check whether the actual feedback value exceeds the set acceptable range
Err-17	E-ECT	17	EtherCAT failed	ET1100 communication failed	Seek for technical support
Err-18	E-CAn	18	CAN failed	CAN communication failed	Seek for technical support
Err-19	E-ETE	19	EtherCAT is disabled	EtherCAT is disabled	Seek for technical support
Err-20	E-DPE	20	PROFIBUS DP failed	PROFIBUS DP Communication failed	Check PROFIBUS DP wiring and related parameter settings

LCD keypad	LED keypad	F0-015 value	Fault Name	Possible causes	Corrective actions
Err-21	E-unk	21	Reserved		
Err-22	E-ES-	22	Modbus communication time out	Incorrect baud rate setting	Set the baud rate correctly
				incorrect address setting	Check the parameter address and check the read and write time interval
				Communication timeout	Check the Modbus timeout time
				Modbus communication disconnection	Check the communication wiring
				Poor contact of keypad	Check the keypad port
Err-23	E-OSE	23	Encoder 1 direction is opposite to encoder 2	Encoder 1 direction is opposite to encoder 2	Check the encoder 1 direction and encoder 2 direction
Err-24	E-AIU	24	Analog input disconnection	The analog disconnection function is turned on, and the analog input value is less than the analog disconnection value	Check the analog input voltage is normal Check the analog disconnection value setting Check the analog gain and other related parameters setting
Err-25	E-AIO	25	Analog input has exceeded upper limit	The analog alarm function is turned on, and the analog input value is greater than the upper value	Check whether the analog input voltage is normal Check whether the analog upper limit is set properly Check whether the analog gain and other related parameters are set properly
Err-26	E-CUr	26	Current detection abnormal	The current detection abnormal	Seek for technical support
Err-27	E-Z1r	27	Encoder 1 phase Z capture failed	Abnormal z-phase pulse capture of the encoder 1	Check the encoder 1 Z phase wiring
Err-28	E-STL	28	Motor stall	Motor stall	Check the motor actual speed and load. Check motor parameters setting. Check the motor stall parameter setting. Check the speed feedback signal. Check the mechanical brake.
Err-29	E-BOT	29	Brake chopper	Braking chopper works too long	Check the DC voltage and chopper voltage.
Err-30	E-STA	30	Over speed	The motor actual speed too high.	Check the encoder Check the motor load. Check the control mode.
Err-31	E-APF	31	Application fault	Check F3-050	Check F3-050 and below Table for details

LCD keypad	LED keypad	F0-015 value	Fault Name	Possible causes	Corrective actions
Err-32	E-PER	32	Input phase loss	Abnormal connection, missing connection or disconnection at the power supply	Check input power supply. Check the power connections as per the operational regulations and eliminate the errors of missing connection and disconnection
				Serious imbalance of three phases power supply	Check whether the imbalance of three phases power comply with the requirements

When the drive has application fault "E-APF", the fault code can be read in parameter F3-050, the fault messages are listed in the below Table.

F3-050	Fault name	Possible causes	Corrective actions
1	Over speed	The motor speed exceeds the over speed detect value.	Check the over-speed detect value. Check the motor actual speed. Check the motor load.
2	Speed error	The deviation between the actual speed and the reference speed exceeds the speed error detect value.	Check the speed error detect value setting. Check the motor load. Check the motor speed whether is stable. Check the encoder PPR and cable.
3	Zero current detection	The output current lower than the zero current detect value.	Check the zero current detect value. Check the cable between the motor and the drive.

Note: The fault code is also displayed in the F0-013 and F0-014. We can use the two parameters to check if there are multiple faults at the same time. The relationships are shown as follows:

bit of F0-013	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
Value of F0-015	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
bit of F0-014	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
Value of F0-015	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17

Appendix A Modbus Communication

1 Support Protocol

Support Modbus protocol, RTU format, Broadcast address is 0, slave address is "1-247", and "248-255" for reservation.


2 Interface Mode

RS485: Asynchronous, half duplex, LSB sending priority. Low byte is after the high byte.

Communication port A (RJ45) default data format: 8-N-1, 38400 bps

Communication port B (terminal RS485+/-) default data format: 8-N-1,38400 bps.


It is recommended to adopt EIA/TIA T568B, the lead of port A is defined as:



Attached Figure 1 RJ45 interface

Port A pin	1	2	3	4	5	6	7	8
Port A signal	+5V	GND	485+	485-	485+	485-	GND	+5V
EIA/TIA T568A	White green	Green	White orange	Blue	White blue	Orange	White brown	Brown
EIA/TIA T568B	White orange	Orange	White green	Blue	White blue	Green	White brown	Brown

3 Protocol Format



Attached Figure 2 Protocol format

The ADU (Application Data Unit) check sum is the CRC16 checksum of the first three parts of the ADU obtained by exchanging the high and low bytes.

4 Function Interpretation

■ Function 0x03 reads parameters.

PDU Part Contents	Data Length (Byte)	Range
Request:		
Function code	1	0x03
Register start address	2	0x0000 ... 0xFFFF
Registers No.	2	0x0001 ... 0x0010
Response:		
Function code	1	0x03
Read bytes	1	2* Registers No.
Read contents	2* Registers No.	

■ Function 0x06 writes single parameter or control word

PDU Part Contents	Data Length (Byte)	Range
Request:		
Function code	1	0x06
Register address	2	0x0000 ... 0xFFFF
Register data	2	0x0000 ... 0xFFFF
Response:		
Function code	1	0x06
Register address	2	0x0000 ... 0xFFFF
Register data	2	0x0000 ... 0xFFFF

■ Function 0x10 writes multiple parameters or control word

PDU Part Contents	Data Length (Byte)	Range
Request:		
Function code	1	0x10
Register start address	2	0x0000 ... 0xFFFF
Registers No.	2	0x0001 ... 0x0010
Bytes of register contents	1	2* Registers No.
Register contents	2* Registers No.	
Response:		
Function code	1	0x10
Register start address	2	0x0000 ... 0xFFFF
Registers No.	2	0x0001 ... 0x0100

Notes:

- Function 0x10 can write up to 16 consecutive address parameters at a time
- The parameters' value changed by communication will not saved to memory after power-off.

5 Register Address

Address Space	Meaning
Control word register	0x8000, refer to "5.1 Control word register (Address: 0x8000)" for more information.
Speed reference register	0x8001
Torque reference register	0x800E
AO output register 1	0x8006
AO output register 2	0x8007
Status word	Parameters F0-000 to F0-200 corresponding to address 0x6000 to 0x60C8. The Modbus address of status monitoring parameters (Group F0) are listed in Chapter 5.
Parameters address	<p>The calculation method of the register address corresponding to the parameter: the high byte is the parameter group number, and the low byte is the number in the group, both expressed in hexadecimal.</p> <div style="text-align: center;"> </div> <p>High byte: P0 ... PF corresponds to 0x00 ... 0x0F A0 corresponds to 0x10 B0 ... B1 corresponds to 0x20 ... 0x21 C0 ... C2 corresponds to 0x30 ... 0x32 D0 corresponds to 0x40 E0 corresponds to 0x50 F0 ... F3 corresponds to 0x60 ... 0x63</p> <p>Low byte: 00 ... 255 corresponds to 0x00 ... 0xFF</p> <p>Example: The Modbus operation address of parameter PB-023 is 0x0b17, the calculation process is as follows, this calculation method is suitable for calculating the addresses of all parameters:</p> <div style="text-align: center;"> </div>

5.1 Control word register (Address: 0x8000)

Bit	Function	Bit	Function
0	0: Stop command 1: Start command	8	0: Relay1 – OFF 1: Relay1 – ON
1	0: Run forward 1: Run reverse		0: Relay2 – OFF 1: Relay2 – ON
2	0: Reset disabled 1: Reset enabled	10	0: Relay3 – OFF 1: Relay3 – ON
3	Reserved	11	0: No action 1: PID switch to constant speed
4	Reserved	12	Reserved
5	Reserved	13	Reserved
6	0: Y1 output OFF 1: Y1 output ON	14	Reserved
7	0: Y2 output OFF 1: Y2 output ON	15	Reserved

6 Modbus Communication Example

Run (The following is Hexadecimal data):							
	Address	Function code	Register address		Register contents		Checksum
Request	01	06	8000		0001		61CA
Response	01	06	8000		0001		61CA
Stop (The following is Hexadecimal data):							
	Address	Function code	Register address		Register contents		Checksum
Request	01	06	8000		0000		A00A
Response	01	06	8000		0000		A00A
Run and set speed reference to 50.00Hz (The following is Hexadecimal data):							
	Address	Function code	Register address	Number	Bytes	Register contents	Check sum
Request	01	10	8000	0002	04	0001 1388	CEFF
Response	01	10	8000	0004	-	-	E80A

Note: The parameters modified by communication will not be saved after power off. If you need to save them, perform a save operation (D0-002=1) before power off.

7 CRC16 Function


```

unsigned int crc16 (unsigned char *data, unsigned char length)
{
    unsigned int i, crc_result=0xffff;
    while (length--)
    {
        crc_result^=*data++;
        for (i=0;i<8;i++)
        {
            if (crc_result&0x01)
                crc_result= (crc_result>>1)^0xa001;
            else
                crc_result=crc_result>>1;
        }
    }
    return (crc_result= ( (crc_result&0xff)<<8)|(crc_result>>8)); //交换 CRC16 校验和高低字节
}

```


8 Network Construction

■ The Modbus connection for one drive



Appendix Figure 3 The connection of one drive

■ The Modbus connection for drives



Appendix Figure 4 The connection for multiple drives

Appendix B Speed Feedback Card

1 Introduction

Model	Encoder frequency division output	Technical specification	Power voltage of encoder
EX-PG01	No	Maximum current 200mA, up to 80K pulse input	+12V ... +24V
EX-PG02	No	Maximum current 150mA, up to 300K pulse input	+5V
EX-PG03	Yes	Maximum current 200mA, up to 80K pulse input	+12V ... +24V
EX-PG04	Yes	Maximum current 150mA, up to 300K pulse input	+5V

2 DIP Setting

No.1 jumper corresponds to bit 0 of binary system

No.2 jumper corresponds to bit 1 of binary system

No.3 jumper corresponds to bit 2 of binary system

.....


No.8 jumper corresponds to bit 7 of binary system

When the jumper is in ON status, the value of the corresponding bit is 1; otherwise, it is 0. The frequency division 1 to 510 can be realized through to remove the jumper.


The calculation formula of the number of the PG card frequency divisions is:

Number of frequency divisions = binary number indicated by jumper $\times 2$


For example, when the jumper is in the status shown in the figure, the corresponding number of frequency division is 1.



When the jumper is in the status shown in the figure, the corresponding number of frequency divisions is 2 (0b1 * 2 = 2, 0b represents that this number is a binary data).




When the jumper is in the status shown in the figure, the corresponding number of frequency divisions is 510 (0b11111111 * 2) = 255 * 2 = 510 (0b represents that this number is a binary data).




3 Wiring

◆ EX-PG01 Card and EX-PG03 Card


For the open collector, voltage, push pull (complementary) type encoder for motor speed feedback and power supply is +12V to +24V, should select EX-PG01 card. If the motor speed needs to send to other equipment for calculation or speed measurement, should select EX-PG03 card with frequency division output.



EX-PG01 card use internal power supply
(Jumper removed to ON side)



EX-PG01 card use external power supply
(Jumper removed to OFF side)




EX-PG03 card use internal power supply
(Not support external power supply)


◆ EX-PG02 Card and EX-PG04 Card

If the encoder is differential type and power supply is 5V, should select EX-PG02 card.


If the encoder signal needs to send to other equipment for calculation or speed measurement, should select EX-PG04 card with encoder division output.




EX-PG02 card use internal power supply



EX-PG02 card use external power supply



EX-PG04 card use internal power supply



EX-PG04 card use external power supply

Appendix C Communication Card



1 Introduction

Model	Installation mode	Protocol	Power supply
EX-CA04	Internal / external	CANopen DS301, DS303, DS305	+24VDC 100mA
EX-CA06	Internal / external	PROFIBUS DP DPV0	+24VDC 100mA
EX-CA13	Internal	PROFINET, it also has 5V incremental encoder interface, and encoder feedback output interface	+5VDC 150mA

2 Wiring



◆ EX-CA04

- EX-CA04 is a communication module of CANopen slave station, which can be used to connect CANopen configuration network, programmable controller and human-machine interface.
- EX-CA04 provides customer-define function, which is used to connect CANopen configuration network and Modbus protocol compliant custom devices;
- Support CAN2.0A protocol, support CANopen DS301 V4.02, DS303, DS305 protocol.




◆ EX-CA06

Ex-CA06 is a PROFIBUS DP bus adapter card. This adapter card provides PROFIBUS DP interface for users, which is suitable for various industrial automation occasions. The electrical interface and protocol fully comply with Siemens PROFIBUS DP bus standard, which is more convenient for users to configure.



◆ EX-CA13

- It is a PROFINET Industrial Ethernet communication adapter card with full duplex and adaptive 10 / 100M baud rate.
- Integrated dual port Fast Ethernet interface with switch function.
- The product status and fault are indicated by LED light, which is convenient for commissioning and maintenance
- Integrated a 5V incremental encoder card and encoder output. For the wiring and description of encoder part, please refer to EX-PG04 function description.



Fault indicator

Fault indicator	Fault reason
L1	BF indicator, Bus Failure. The indicator is ON when PN network error occurs. The indicator flashes during start-up. The indicator is OFF when PN network working normal.
L9	System Fail. The indicator is always on when the system is wrong, and it is off when it is normal.
L10	Device Ready, after the internal protocol stack is started correctly, this light is always on.
L11	Maintenance. Reserved.
D1	Power indicator, 3.3V normal, normally ON.
D4	The indicator flashes once when MODBUS message is sent.